LANDP



Master Index

Contents

Master Index Prefix Codes 1

Index 3

Master Index Prefix Codes

INCUST
Installation and Customization

INTPLA
Introduction and Planning

PRODET
Problem Determination

PROGDE
Programming Guide

PROGREF
Programming Reference

SERSYS
Servers and System Management

Index

Special Characters

_AE translation routine PROGREF–573
_EA translation routine PROGREF–573
? symbol, migration INCUST–233
(I) intervention errors, description of PRODET–6
(P) programming errors, description of PRODET–6
(U) device errors, description of PRODET–6
** (process disconnection) PROGDE–64
** (workstation disconnection) PROGDE–63
&& (process connection) PROGDE–66
&& (workstation connection) PROGDE–65
&W value INCUST–433
#, use of in server names PROGDE–12

Numerics

1000-mode, 4707 SERSYS–224
16-bit applications INCUST–139
16-bit programs PROGDE–16
16-bit support INTPLA–15
16-bit Windows LANDP applications INCUST–139
2000 INTPLA–16
2000-mode, 4707 SERSYS–224
3174 controller INTPLA–89
32-bit programs PROGDE–16
32-bit support INTPLA–15
3270 books INCUST–584, INTPLA–150, PRODET–296, PROGDE–224, PROGREF–704, SERSYS–276
3270 emulator SERSYS–31, SERSYS–34
3270 emulator API
  characteristics PROGREF–593
  invocation PROGREF–593
  services PROGREF–594
3270 emulator support INTPLA–11
3270 emulator
  alerts PRODET–236
  AUTOFBSS.BAT modifications, DOS INCUST–195
  color attribute table INCUST–310, INCUST–497
  common codes SERSYS–40
  CONFIG.SYS modifications INCUST–195
  configuration definitions INCUST–496
  COUNTRY command INCUST–195
  cryptography INCUST–496
  DEVICE command INCUST–195
  display SERSYS–35
  display translation table INCUST–497
  displaying the emulation screen SERSYS–35
  ending SERSYS–35
  enter hot key SERSYS–35
  exit hot key SERSYS–35
3270 emulator *(continued)*
  extended 3270 keyboard table INCUST–362
  extended color attributes INCUST–311
  extended keyboard table INCUST–362
  FBSS3270.SCN file SERSYS–42
  HLLAPI INCUST–496
  host application session ID INCUST–498
  hot key definitions SERSYS–35
  key assignments INCUST–358
  key definition INCUST–360, INCUST–363
  keyboard table INCUST–357
  keyboard translation table INCUST–498
  loading statement (DOS) INCUST–212
  loading statement (OS/2 VDM) INCUST–122
  loading statement (Windows VDM) INCUST–158
  operator information area SERSYS–35
  printing panels SERSYS–42
  resetting insert mode SERSYS–42
  saving panels SERSYS–42
  SNA LU number INCUST–497
  SNA LU pool ID INCUST–497
  SNA pool ID INCUST–497
  starting SERSYS–34
  status indicator codes SERSYS–40
  translation table INCUST–407
  X.25 network SERSYS–35
3270 send/receive facility INTPLA–53, SERSYS–214
3270 send/receive facility messages PRODET–223
3270 send/receive facility
  APVUFILE SERSYS–214, SERSYS–215
  CICS (MVS) SERSYS–222, SERSYS–223
  DBCS systems, for INTPLA–53, SERSYS–214
  file transfer facility, alternative to INTPLA–53, SERSYS–214
  IND$FILE SERSYS–215
  RECEIVE command SERSYS–215
  SEND command SERSYS–215
  TSO (MVS) SERSYS–221
  TSO (MVS) SEND SERSYS–219
  VM/CMS RECEIVE SERSYS–218
  VM/CMS SEND SERSYS–217
3270
  characteristics SERSYS–32
  display SERSYS–31
  file transfer programs
    DBCS workstation to host SERSYS–214
    host computer requirements SERSYS–200
  hot keys SERSYS–33
  starting emulator (DOS) PROGREF–10
3274 Model 51C Control Unit SERSYS–31
3278 Model 2 Display Station SERSYS–31
3279 Model S2A Display Station SERSYS–31
3287 emulator INTPLA–29, SERSYS–44
3287 emulator support INTPLA–11
3287 emulator
  operator interface SERSYS–176
3287 printer emulator SERSYS–45
3287 printer emulator
  attribute table INCUST–376, INCUST–500
  AUTOFBSS.BAT modifications, DOS INCUST–195
  characters density INCUST–501
  CONFIG.SYS modifications INCUST–195
  configuration definitions INCUST–499
  form feed INCUST–502
  host application session ID INCUST–502
  loading statement (DOS) INCUST–214
  loading statement (OS/2 VDM) INCUST–123
  loading statement (Windows VDM) INCUST–159
  page length INCUST–501
  polling time interval INCUST–500
  printer character string INCUST–500
  printer ID INCUST–501
  printer selection INCUST–499
  reset control characters INCUST–377
  session number INCUST–500
  SNA LU number INCUST–500
  SNA LU pool ID INCUST–500
  SNA pool ID INCUST–500
  start new listing, control characters to INCUST–377
  time interval of polling INCUST–500
  translation table INCUST–407
3720 controller INTPLA–89
3725 controller INTPLA–89
3745 controller INTPLA–89
4009 printer server SERSYS–68
4009 printer, 3287 printer emulation INCUST–499
4019 laser printer PROGREF–657
4019 printer SERSYS–44
4029 laser printer PROGREF–657
4029 printer SERSYS–44
4039 laser printer PROGREF–657
4039 printer SERSYS–44
4201 Proprinter PROGREF–657
4700 file transfer facility SERSYS–200
4700 processor support INTPLA–15
4702 processor INTPLA–89
4704 read compatibility mode (MSR/E server) PROGREF–217
4707 display modes SERSYS–224
4707 monochrome display support INTPLA–54, SERSYS–224

4710 printer
attention INCUST–321
line length INCUST–320
line skip INCUST–320
object type INCUST–319
page size INCUST–320
printing density INCUST–320
start key INCUST–320
vertical offset INCUST–320
warning INCUST–321
4712 printer server SERSYS–68
4712 printers INTPLA–89
4712 transaction printer PROGREF–141, PROGREF–657
4712/4722 printer server
baud rate INCUST–503, INCUST–504, INCUST–505
configuration definitions INCUST–502
parallel port INCUST–503
port 1 INCUST–503
port 2 INCUST–504
port 3 INCUST–504
port 4 INCUST–505
printer model INCUST–503, INCUST–504, INCUST–505, INCUST–506
4717 MSR/E server SERSYS–75
4718 PIN pad devices
alerts PRODET–239
4718 PIN pad server SERSYS–76
4720 printer
attention INCUST–327
book width INCUST–324
center fold type INCUST–325
line advance INCUST–325
line density INCUST–325
line length INCUST–325
line skip INCUST–324
new document INCUST–326
object type INCUST–323
page size INCUST–326
printing density INCUST–324
REMS INCUST–324, INCUST–326
start key INCUST–326
vertical offset INCUST–327
warning INCUST–327
4721 self service printer server
configuration definitions INCUST–508
DEVSP47.TAB INCUST–508
identification INCUST–508
number INCUST–508
printer ID INCUST–508
printer ID, update INCUST–227
printer number INCUST–508
SNA LU number INCUST–508, INCUST–509, INCUST–510
SNA LU pool ID INCUST–508, INCUST–509, INCUST–510
SNA pool ID INCUST–508, INCUST–509, INCUST–510
4722 document printer PROGREF–141, PROGREF–657
4722 printer server SERSYS–68
4722 printers INTPLA–89
4731, 4738, 4739 PBM INCUST–511, INCUST–513
4731, 4738, 4739 PBM
configuration definitions INCUST–511
configuration path INCUST–511
SNA LU number INCUST–511, INCUST–512
SNA LU pool ID INCUST–511, INCUST–512
SNA pool ID INCUST–511, INCUST–512
4733 unit
configuration definitions INCUST–513
device driver INCUST–13, INCUST–18
DEVICE statement (DOS) INCUST–200
DEVICE statement (OS/2) INCUST–103
line speed INCUST–513
port INCUST–513
4737 transaction statio
SNA LU number INCUST–514
SNA LU pool ID INCUST–514
SNA pool ID INCUST–514
4737 transaction station
configuration definitions INCUST–514
configuration path INCUST–514
4748 and 9068-D01 printer server
loading statement (OS/2) INCUST–120
4748 printer server INCUST–13, INCUST–17, INTPLA–116, SERSYS–71
4748 printer server
9055 Model 1 Printer INCUST–17
alert setting INCUST–517
attention INCUST–346
baud rate INCUST–516
code conversion INCUST–517
configuration definitions INCUST–515
DEVICE statement (DOS) INCUST–200
DEVICE statement (OS/2) INCUST–102
driver file name INCUST–517
LANDP for Windows installation INCUST–14
line length INCUST–344
line skip INCUST–342
lines per inch INCUST–344
loading statement (DOS) INCUST–214
loading statement (Windows) INCUST–157
page size INCUST–345
port INCUST–518
port 1 INCUST–515
port 2 INCUST–516
port ID INCUST–518
printer for port 1 INCUST–516
printer for port 2 INCUST–517
printing mode INCUST–342
REMS selection for port 1 INCUST–516
REMS selection for port 2 INCUST–517
session ID INCUST–518
start key INCUST–346
UDC file name INCUST–517
warning INCUST–346
4770 printer server SERSYS–73
4770 printer server
attention INCUST–351
baud rate INCUST–519, INCUST–520
character density INCUST–350
configuration definitions INCUST–519
density of characters INCUST–350
DEVICE statement (OS/2) INCUST–101
horizontal character density INCUST–350
horizontal density of characters INCUST–350
inverted printing INCUST–350
line length INCUST–349
line skip INCUST–349
loading statement (OS/2) INCUST–120
object type INCUST–348
page size INCUST–350
parallel port INCUST–519
port 1 INCUST–519
port 2 INCUST–519
port 3 INCUST–520
port ID INCUST–520
session ID INCUST–520
type characters INCUST–349
upside-down mode INCUST–350
vertical character density INCUST–350
vertical density of characters INCUST–350
warning INCUST–351
4772 printer server SERSYS–68
4772 printer
DEVICE statement (OS/2) INCUST–102
4772PDD.SYS INCUST–102
4777 MSR/E server SERSYS–75
4778 PIN pad server SERSYS–76
480-mode, 4707 SERSYS–224
5575 printer PROGREF–657
5575 Printer SERSYS–45
5577 Printer SERSYS–45
5577 printer for Korea and Taiwan PROGREF–657
802.2 session INTPLA–88
9055 Model 1 Printer INCUST–17
9055 printer server INTPLA–116
9055-002 printer server SERSYS–68
9068 printer server SERSYS–68
9068-D01 Multi-Purpose Passbook Printer PROGREF–167
9068-D01 printer INCUST–120
9068-D01 printer
4748 printer server INCUST–157
DEVICE statement (OS/2) INCUST–102
loading statement (Windows) INCUST–157
PAR&47X2 vector INCUST–499
9068-S01 printer, DEVICE statement (OS/2) INCUST–102
9069 multi-purpose transaction printer SERSYS–68
9370 information system INTPLA–89

A

A/B keys SERSYS–69
AA (ask for asynchronous events) supervisor local function PROGREF–6
abbreviations INCUST–557, INTPLA–123, PRODET–269, PROGDE–197, PROGREF–677, SERSYS–249
AC (acquire a parallel printer) function in printer manager server PROGREF–201
access methods, shared-file SERSYS–78
access
  access server, DDE INTPLA–49
  DDE access server SERSYS–190
  identifying files SERSYS–49
  LAN common data SERSYS–152
  to host data INTPLA–29, SERSYS–31
  to relational database INTPLA–19, SERSYS–7
  to workstation from host SERSYS–47
  user profile application data SERSYS–155
  user profile data SERSYS–153
accessibility on LANDP
  keyboard access INTPLA–17
  product documentation INTPLA–17
  sound INTPLA–17
  visual INTPLA–17
account number, personal (PAN) PROGREF–232
acquire a parallel printer (AC) function in printer manager server PROGREF–201
ACSRDECR.DLL INCUST–93, INCUST–470, SERSYS–19
ACSRENCR.DLL INCUST–93, INCUST–470, SERSYS–19
acting as client, server PROGDE–2
activate and deactivate timers (T0–T8) supervisor local function PROGREF–21
activate and deactivate timers (T0–T8) supervisor local function
  used in sample application PROGDE–163
activate service (AS) function in local resource manager PROGREF–523
ACTLU received (SNA server) PROGREF–51
ACTPU received (SNA server) PROGREF–50
AD (advise) function in DDE access server PROGREF–443
adapter trace (coprocessor), LANDP for DOS X.25 PRODET–19
adapter trace, LANDP for DOS X.25 PRODET–20
adapter
  SDLC INTPLA–89
ADAPTNUM keyword
  LANCONF vector INCUST–420
  LWSCONF vector INCUST–428
Add record (AR) function
  electronic journal server PROGREF–392
add user to user profile file (AU) function in system manager server PROGREF–476
add user to user profile file (Year-2000) (AX) function in system manager server PROGREF–476
address resolution, internet INCUST–527
administrators (system), description of PRODET–vii
Adobe Acrobat Reader INCUST–21
advanced program-to-program API INTPLA–21, SERSYS–15
advise (AD) function in DDE access server PROGREF–443
AE (ASCII-EBCDIC translation) AE routine PROGREF–573
AEDATA0X to AEDATAFX keywords XLAT2TBL vector INCUST–409
AI (activate application intervention) function in local resource manager PROGREF–522
AL (allocate physical electronic journal) function in electronic journal server PROGREF–392
Alert
  EJ1, unsuccessful call to shared-file server PRODET–233
alerts (in system manager server)
  management PROGREF–498
  resolution notification (UN) function PROGREF–503
  update alerts status (UA) function PROGREF–489
alerts functions
  notification and messages PRODET–7
alerts management SERSYS–143
alerts, LANDP PRODET–231
alerts
  3270 emulator PRODET–236
  4717, 4777 MSR devices PRODET–237
  4718 PIN pad devices PRODET–239
  description of PRODET–7
  EM1—Data stream error PRODET–236
  FF1, unsuccessful call to server PRODET–235
  financial printer server PRODET–234
  forwarding server PRODET–235
  generic architecture PRODET–7
  LANDP PRODET–231
  management INTPLA–39
  MSR/E (magnetic stripe reader/encoder) server PRODET–237
  MSR1, hardware error PRODET–237
  MSR2 alert, device not connected PRODET–238
  NetView program PRODET–7
  PIN1, hardware error PRODET–239
  PIN2, device not connected PRODET–240
  printers (4712, 4722) PRODET–234
  PS1, hardware error PRODET–234
  RC1, file operation error PRODET–241
  RCMS (remote change management services) PRODET–241
  S1, unexpected SNRM command received PRODET–247
  S2—Invalid or unsupported frame received PRODET–248
alerts *(continued)*
  S3—Frame exceeding allowable length received PRODET–249
  S4—Timer expired without being polled PRODET–250
  S5—Modem power off PRODET–251
  SDLC (synchronous data link control) PRODET–247
  SF1, error by disk read PRODET–244
  SF2, file full PRODET–245
  SFF1, unsuccessful call to shared-file server PRODET–246
  SH1, error by disk read or write PRODET–242
  SH2, file full PRODET–243
  shared IBM DOS directory server PRODET–242
  shared-file server PRODET–244
  SN1—SNA protocol error PRODET–252
  SNA server PRODET–252
  software requirements INTPLA–86
  store-for-forwarding server PRODET–246
  X.25 data link control (DLC) PRODET–252
  X2—DCE-Originated clear indication received PRODET–254
  X3—Reset indication packet sent by the DTE PRODET–255
Alerts
  electronic journal server PRODET–233
alias names PROGDE–12
alias, LWSCONF vector, CLIENT keyword INCUST–433
aliases, defining SERSYS–49
allocate physical electronic journal (AL) function PROGREF–392
ALRHNDLR keyword, SMGRPRF vector INCUST–401
alternate collating sequence table INCUST–302
alternate mode, set (SA) function in local resource manager PROGREF–542
alternate print mode SERSYS–73
ALTSESS keyword, FORWPRF vector INCUST–355
AN (alerts notification) function in system manager server PROGREF–499
APAR level SERSYS–232
APAR
  programs for managing PRODET–5
APPC, API INTPLA–21, SERSYS–15
APPDTVAL keyword, SMGRPRF vector INCUST–400
APPLIC keyword, KBDBIWP vector INCUST–366
application data maintenance INTPLA–39
application data maintenance (in system manager server) PROGREF–474
application data validation INCUST–398
application data
  other's, getting SERSYS–142
  own, getting SERSYS–142
application integration programs SERSYS–189

application integration programs
batch machine log file SERSYS–192
mail program SERSYS–192
application integration servers SERSYS–189
application libraries, maintaining INTPLA–41, SERSYS–47
application program disconnection (EJ) supervisor local function PROGREF–11
application programmers, description of PRODET–vii
application programming
32-bit programs PROGDE–16
3270 emulator API PROGREF–593
3270 emulator invocation PROGREF–593
3270 emulator services PROGREF–594
alias names PROGDE–12
API link routines
RMTREQ PROGDE–32
RMTREQ NoWait PROGDE–33
asynchronous event notification PROGDE–39
C Set/2 PROGDE–9
COBOL programs under VisualAge PROGDE–93
common API
invoking PROGDE–31
used by clients PROGDE–5
used by servers PROGDE–5
compiling and linking PROGDE–14
connectivity programming request block (CPRB)
fields required for RMTREQ PROGDE–32
dynamic link library PROGDE–15, PROGDE–18
EHC_NOWAIT_PARM structure in calls PROGDE–35
GETREPLY PROGDE–5
GETREQ PROGDE–5
include file PROGDE–17, PROGDE–18
including options control blocks PROGDE–9
including the CPRB PROGDE–9
invoking the common API PROGDE–31
link-editing PROGDE–14
MASM PROGDE–9
notation convention PROGDE–xii
passing
data PROGDE–10
parameters PROGDE–10
polling asynchronous event information PROGDE–42
pure 16–bit programs PROGDE–16
RMTAREQ PROGDE–5
RMTREQ PROGDE–5, PROGDE–32
RMTREQ NoWait PROGDE–5
RMTRPLY PROGDE–5
SRVINIT PROGDE–5
tutorial PROGDE–119, PROGDE–170
VisualAge for COBOL PROGDE–93
waiting for multiple events PROGDE–41
Application programming
WM used by LANDP servers PROGDE–72
application server integration
Java manager INTPLA–52
applications, query (QA) function in DDE access server PROGREF–440
applications
developing INTPLA–7
effect of XLR takeover SERSYS–90
integration servers INTPLA–13
on host INTPLA–29, SERSYS–31
sharing INTPLA–39, SERSYS–132
APPLVL keyword, SMGRUSER vector INCUST–404
APPLYFIX program PRODET–64
APPLYFIX utility SERSYS–232
APPLYFIX utility program INCUST–251
APPLYFIX utility, description PRODET–5
applying program fixes INCUST–251, SERSYS–232
APVUFILE transfer program SERSYS–214, SERSYS–215
AR function
electronic journal server PROGREF–392
architecture, generic alert PRODET–7
arm operator panel for user input (AR) function in financial printer server PROGREF–146
arm the PIN pad or MSR for data input (AR) function PROGREF–228
AS (activate service) function in local resource manager PROGREF–523
AS (associate semaphore) supervisor local function PROGREF–7
AS/400 INTPLA–89
AS/400
connectivity, SNA LU_0 INCUST–541
connectivity, SNA LU_2 INCUST–540
ASCII characters, return code values PRODET–6
ASCII data SERSYS–49
ASCII to EBCDIC
translation INTPLA–22
translation server INTPLA–116
ASCII-EBCDIC server
return codes PRODET–127
ASCII-EBCDIC translation server
return codes PRODET–127
ASCII-EBCDIC translation
3270 emulator loading parameters, OS/2 INCUST–122
3270 emulator loading parameters, Windows INCUST–158
3287 printer emulator loading parameters, OS/2 INCUST–123
3287 printer emulator loading parameters, Windows INCUST–159
BIWP loading parameters, OS/2 INCUST–121
BIWP loading parameters, Windows INCUST–157
BPP loading parameters, Windows INCUST–158
RCMS loading parameters, OS/2 INCUST–112, INCUST–149
ASCII-EBCDIC translation *(continued)*
translation server loading statement (DOS) INCUST–204
ASCII-to-EBCDIC
translation SERSYS–18, SERSYS–235
translation table SERSYS–45
ask for asynchronous events (AA) supervisor local function PROGREF–6
assistance (IBM support), requesting PRODET–53
associate semaphore (AS) supervisor local function PROGREF–7
asynchronous events PROGDE–66, PROGREF–558
Asynchronous events PROGREF–565
asynchronous events
ask for events (AA) supervisor local function PROGREF–6
asking for TT request (Z4) supervisor local function PROGREF–29
event notification or cancellation (Z5) supervisor local function PROGREF–30
event notification or cancellation with RMTRPLY PROGDE–58, PROGREF–32
extended event notification or cancellation (ZN) supervisor local function PROGREF–31
managing PROGREF–3
notation for codes PROGDE–xii, PROGREF–xxvii
notification PROGDE–39
polling PROGDE–42
start posting (SP) supervisor local function PROGREF–20
stop posting (TP) supervisor local function PROGREF–23
switch printer mode (Z6), FBSI/2 PROGREF–671
wait (WM) supervisor local function PROGREF–24
wait(WM) supervisor local function PROGDE–41
asynchronous operation INTPLA–22, SERSYS–17
Asynchronous/SDLC Communications Adapter INCUST–210, INTPLA–89
attributes, get (GA) function in PPC server PROGREF–112
AU (add user to user profile file) function in system manager server PROGREF–476
audience for this book INCUST–xxiii, PRODET–vii, PROGREF–xxv
audio signal
customizing system manager SERSYS–146
pending message SERSYS–159
authorization level, getting SERSYS–141
authorized program analysis report SERSYS–232
auto connect PROGREF–562, PROGREF–567
AUTO_VDM.BAT file (Windows) INCUST–157
AUTOEXEC.BAT SERSYS–58

AUTOFBSS command SERSYS–233
AUTOFBSS command
including EHCINFO.EXE SERSYS–233
autofbss file
example, Linux INCUST–177
AUTOFBSS file
EHCINFO.EXE SERSYS–233
example SERSYS–234
AUTOFBSS.BAT file.
OfficeVision. SERSYS–213
AUTOFBSS.BAT file
DOS PRINT SERSYS–74
autofbss
autofbss
modifying contents, Linux INCUST–176
AUTOFBSS
AUTOFBSS.BAT, OS/2 INCUST–121
AUTOFBSS.BAT
example, DOS INCUST–202
example, Windows INCUST–140
modifications for emulators, DOS INCUST–195
modifying contents, DOS INCUST–201
modifying contents, Windows INCUST–140
AUTOFBSS.CMD, OS/2
example INCUST–103
modifying contents INCUST–103
VARPARM.EXE INCUST–227
automated startup INCUST–141
automatic building, FBSS INCUST–233
AUTONL keyword
FORM4710 vector INCUST–320
FORM4720 vector INCUST–324
FORM4748 vector INCUST–342
FORM4770 vector INCUST–349
FORM47X2 vector INCUST–331
AUTOUSER.BAT
modifying contents, DOS INCUST–201
AUTSYNC keyword
SMGRPRF vector INCUST–400
AUTTRANS keyword
FORWDS vector INCUST–352
AX (add user to user profile file (Year-2000)) function in system manager server PROGREF–476

B

BACKGRD keyword, DISPLATT vector INCUST–312
backout operation (BO) function in object postbox server PROGREF–580
backout
batch machine operator SERSYS–197
log files SERSYS–81
transactions SERSYS–81
backup program files, APPLYFIX INCUST–253
BACKUP utility program
return codes PRODET–204
backup, SPC files INCUST–37, INCUST–235
backup, system communication INTPLA–19
backup
DBBACKUP shared file utility SERSYS–98
DBRESTOR shared file utility SERSYS–99
dynamic reconfiguration of XLR servers SERSYS–187
example backup procedures DOS, OS/2, Windows SERSYS–99
global data SERSYS–140
shared files SERSYS–98, SERSYS–100
system communication SERSYS–7
BACKUP2 query server program SERSYS–113
BAK files INCUST–37, INCUST–235
banking interactive workstation program PRODET–xi
banking interactive workstation program
4700 SWAPTT instruction INCUST–366
application session ID INCUST–437
BIWP.EXE INCUST–20
configuration definitions INCUST–434
cursor INCUST–435
defaults INCUST–364
display color attributes INCUST–436
display translation table INCUST–436
end of message mask INCUST–436
indicator 1 alarm INCUST–436
indicator 2 alarm INCUST–436
indicator 3 alarm INCUST–436
input translation table (MSR/E) INCUST–372
input translation table (PIN pad) INCUST–378
issue-keyboard-scan code translation table INCUST–368
key assignments INCUST–364
key definition INCUST–366
keyboard table INCUST–364
keyboard translation table INCUST–437
loading servers inline (OS2) INCUST–124
loading statement (OS/2 VDM) INCUST–121
loading statements (Windows VDM) INCUST–157
MSR/E input table INCUST–437
MSR/E output table INCUST–437
MSR/E reads INCUST–373
MSR/E ready alarm INCUST–436
MSR/E tracks INCUST–373
output translation table (MSR/E) INCUST–374
PIN pad input table INCUST–437
present-keystroke defaults INCUST–370
present-keystroke translation table INCUST–370
read operation INCUST–435
read response delay (MSRE) INCUST–373
scan code INCUST–369
SERVER keyword, LWSCONF vector INCUST–430, INCUST–526
SNA LU number INCUST–435
banking interactive workstation program *(continued)*
SNA LU pool ID INCUST–435
SNA pool ID INCUST–435
SYSTEM indicator alarm INCUST–436
translation table INCUST–407
translation table, display INCUST–436
translation table, input (MSR/E) INCUST–372
translation table, input (PIN pad) INCUST–378
translation table, issue-keyboard-scan code INCUST–368
translation table, keyboard INCUST–437
translation table, output (MSR/E) INCUST–374
translation table, present-keystroke INCUST–370
banking printer program PRODET–xi
banking printer program
configuration definitions INCUST–438
host application session ID INCUST–439
host/application identification INCUST–308
loading statement INCUST–104
loading statements(Windows VDM) INCUST–158
printer port number INCUST–438
SNA LU number INCUST–439
SNA LU pool ID INCUST–439
SNA pool ID INCUST–439
translation table INCUST–407, INCUST–439
banking products, installation INCUST–20
banking self-service books INCUST–583, INTPLA–149, PRODET–295, PROGDE–223, PROGREF–703, SERSYS–275
BAT file, getting software INCUST–75
batch machine loader server
configuration definitions INCUST–440
directory INCUST–441
message queue INCUST–440
object post box user name INCUST–440
path INCUST–441
public object post box user name INCUST–440
user name, object post box INCUST–440
batch machine log file SERSYS–192
batch machine operator
loading statement (OS/2) INCUST–106
batch machine server loader
loading statement (OS/2) INCUST–105
batch machine
facility INTPLA–50, SERSYS–191
loading server SERSYS–191
operator INTPLA–51, SERSYS–196
BCK.BAT backup procedure for LANDP for DOS SERSYS–98

BCK.CMD backup procedure for LANDP for OS/2 SERSYS–98
begin transmission (TB) function in store-for-forwarding server PROGREF–418
bibliography INCUST–583, INTPLA–149, PRODET–295, PROGDE–223, PROGREF–703, SERSYS–275
bibliography
3270 SERSYS–276
banking self-service SERSYS–275
Communications server SERSYS–279
Distributed Computing Environment SERSYS–278
encryption and decryption SERSYS–278
FBSS SERSYS–275
Financial Branch System Integrator SERSYS–275
Financial I/O Devices SERSYS–277
LANDP SERSYS–275
Local Area Network SERSYS–276
NetView SERSYS–277
Personal Communications SERSYS–279
Personal Computer SERSYS–276
Personal System/2 SERSYS–276
Transaction Security System SERSYS–275
VisualAge C++ SERSYS–279
VisualAge Generator SERSYS–279
wide area communications SERSYS–277
BID protocol (SNA server) PROGREF–39
binary file distribution SERSYS–49
BIND parameters and protocols (SNA server) PROGREF–38
BIOS INT 17H SERSYS–69
bit positions, convention for PROGDE–xiii, PROGREF–xxvii
BIWP INCUST–20
BIWP/BPP data stream INTPLA–15
BIWP
emulated session number INCUST–435
VDM usage INCUST–20
BKWIDTH keyword
FORM4720 vector INCUST–324
FORM4748 vector INCUST–342
FORM47X2 vector INCUST–331
BLKFAC keyword, FORWPRF vector INCUST–354
block transmission SERSYS–129
BLUE keyword, DISPLATT vector INCUST–313
BMLS.EXE INCUST–105
BMOP INCUST–106
BO (backout operation) function in object postbox server PROGREF–580
books for LANDP INCUST–xxiv, INTPLA–xiii, PRODET–ix, PROGDE–xiv, PROGREF–xxviii, SERSYS–xvi
Borland C++
for DOS INTPLA–78
for Windows NT INTPLA–83
Borland C++programs
compiling and linking PROGDE–14
BOTTVAL keyword
FORM4748 vector INCUST–342
FORM47X2 vector INCUST–331
BPP INCUST–21
BPPPARM vector INCUST–300
BPPPARM vector
example INCUST–302
quick reference INCUST–300
BPPSI1-4 keywords, DEFAULTS vector INCUST–308
bracket protocol (SNA server) PROGREF–38
browse the system log file SERSYS–156
buffer pool size, customization INCUST–427
buffer pool, specifying LANDP for DOS supervisor PRODET–32
buffers for data link controls INTPLA–22
buffers
for data link controls SERSYS–17
for SDLC, number SERSYS–12
for TRDLC, number SERSYS–12
for X25DLC SERSYS–12
building sample applications PROGDE–168

C

C language programs PROGDE–17, PROGDE–18
C language programs
sample client and server programs PROGDE–119
C programs PROGDE–9
C/2 for Personal System/2 and Personal Computers INTPLA–78
C++ programs PROGDE–9
C++, writing application programs using PROGDE–75
CA (change printer assignment) function in local resource manager PROGREF–524
calculating the number of buffers SERSYS–12
call CICS (CC) function in CICS interface serve PROGREF–429
call packets SERSYS–18
called and caller session initiation (X.25 server) PROGREF–92
cancel pending functions (CC) function in local resource manager PROGREF–526, PROGREF–546
CB (close batch) function in shared-file server PROGREF–264
CC (call CICS) function in CICS interface server PROGREF–429
CC (cancel pending functions) function in local resource manager PROGREF–526, PROGREF–546
CCITT 1980 and CCITT 1984 SERSYS–11
CD (change database) function in ODBC query server PROGREF–360
CD (clear operator panel display) function in financial printer server PROGREF–148
CH (check the write status) function in MSR/E server PROGREF–208
chaining emulators SERSYS–33
chaining protocol (SNA server) PROGREF–40
chaining value, initial (IV) function in PIN pad server PROGREF–241
change database (CD) function in ODBC query server. PROGREF–360
change direction protocol (SNA server) PROGREF–41
change LU priority (CP) function in local resource manager PROGREF–529
change modes, 4707 SERSYS–224
change password (CP) function in system manager server PROGREF–463
change print density mode (CM) function in local resource manager PROGREF–528
change printer assignment (CA) function in local resource manager PROGREF–524
change printer to local mode (LP) function in local resource manager PROGREF–549
change printer to remote mode (HP) function in local resource manager PROGREF–548
character set
3270 translation tables SERSYS–32
character, load user-defined (LD) function in 4748 printer server PROGREF–169, PROGREF–182
characters download (DU) function in financial printer server PROGREF–155
check NMVT (CN) function in system manager server PROGREF–503
check status (RD) function in object postbox server PROGREF–583
check the write status (CH) function in MSR/E server PROGREF–208
checking program version level INCUST–247, PRODET–59
checking program version level, Linux INCUST–249, PRODET–61
choosing software INTPLA–77
CHSTRID keyword, BPPPARM vector INCUST–301
CICS interface server INTPLA–48, SERSYS–189
CICS interface server
return codes PRODET–128
CICS, call (CC) function in CICS interface serve PROGREF–429
CICS, read (RC) function in CICS interface server PROGREF–433
CICS/VS support SERSYS–130
CICS.
interface server
loading statement (OS/2) INCUST–106
CICS
host communications definitions INCUST–537
CID (Configuration, Installation, and Distribution)
distribution using CID INCUST–77

cipher block chaining PROGREF–76
ciphering operations, normal request unit PROGREF–89
CL (close conversation) function in PPC server PROGREF–111
CL (close PIN pad or MSR) function in PIN pad server PROGREF–236
class, return code PRODET–6
clear operator panel display (CD) function in financial printer server PROGREF–148
clear packets
  Native X.25 server PRODET–171
CLIENT keyword, LWSCONF vector INCUST–431
client, definition of PROGDE–1
client/server mechanism INTPLA–7
client/server mechanism
  communication PROGDE–3
  how clients and servers interact PROGDE–1
  routing requests PROGDE–2
  server acting as client PROGDE–2
  supervisor local functions PROGREF–3
client
  defined INTPLA–7
  maximum number per server INTPLA–99
clients, testing SERSYS–233
clipboard INTPLA–49
clipboard functions (in DDE access server) PROGREF–449
clipboard services, DDE access server SERSYS–190
close batch (CB) function in shared-file server PROGREF–264
close query mode (CQ) function in ODBC query server. PROGREF–368
close query mode (CQ) function in query server PROGREF–319
CM (change print density mode) function in local resource manager PROGREF–528
CM (compress data) function in SNA compression server exit PROGREF–71
CMD file, getting software INCUST–75
CN (check NMVT) function in system manager server PROGREF–503
COBOL (VisualAge for OS/2 programs) PROGDE–9
COBOL programs under VisualAge
  sample client and server programs PROGDE–140, PROGDE–159
COBOL programs, under VisualAge PROGDE–93
COBOL/2 INTPLA–78
COBOL/2 programs PROGDE–9
code page 850 SERSYS–235
code pages SERSYS–69
code pages
  DBCS, for 3270 emulator SERSYS–33
COFF (Common Object File Format) PROGDE–18
collate tables SERSYS–87
COLLKEYS keyword, SHFLDBD vector INCUST–392
COLSQTBL vector INCUST–302
COLSQTBL vector
  example INCUST–303
  quick reference INCUST–302
COMDTVAL keyword, SMGRPRF vector INCUST–400
command execution (EC) function in DDE access server PROGREF–444
command run (RC) function in DDE access server PROGREF–440
COMMAND.COM SERSYS–58
commands, Tivoli NetView DM SERSYS–55
commit work (CW) function in ODBC query server. PROGREF–368
commit work (CW) function in query server PROGREF–319
committed transactions SERSYS–81
common API INTPLA–3
common data INCUST–26
common data maintenance INTPLA–39, SERSYS–140
common data maintenance (in system manager server) PROGREF–487
common data
  editing INCUST–297
  embedded files INCUST–29
  INCLUDE statement INCUST–29
  introduction INCUST–297
  partial files INCUST–30
  vector editing INCUST–297
Common Object File Format (COFF) PROGDE–18
common status indicator codes (3270 emulator) SERSYS–40
common vectors PRODET–xi
common vectors
  CREATE command INCUST–298
  creating INCUST–297
  default values INCUST–298
  editing INCUST–279, INCUST–297
  editing tool INCUST–297
  EDITSPC command INCUST–297
  GENSPEC command INCUST–298
  one by one INCUST–300
  overview INCUST–298
COMMON.SPC INCUST–26, INCUST–38, INCUST–237
COMMON.SPC
  embedded files INCUST–29
  INCLUDE statement INCUST–29
  partial files INCUST–30
communication and internal traces, EHCLIP program PRODET–49
communication between clients and servers PROGDE–1, PROGDE–3
communication server problems PRODET–70, PRODET–77
communication services in 3270 emulator PROGREF–648
communication status set (CS) function in store-for-forwarding server PROGREF–410
communication traces, LANDP for DOS
  DCA DCL information PRODET–26
  DCA DLC PRODET–24
  EHCLIP trace PRODET–35
communication traces, LANDP for DOS *(continued)*
  native X.25 PRODET–23
  SNA PRODET–22
  start X.25 adapter PRODET–20
  stop X.25 adapter PRODET–21
  token-ring DLC PRODET–27
  X.25 adapter PRODET–20
  X.25 adapter (coprocessor) PRODET–19
  X.25 network errors PRODET–18
communication traces
  SDLC PRODET–15
communication
  backup INTPLA–19, SERSYS–7
  books INCUST–584, INTPLA–150, PRODET–296, PROGDE–224, PROGREF–704, SERSYS–277
  configuration records, updating INCUST–226
  conversation INTPLA–26
  host definitions INCUST–531
  layers INTPLA–20, SERSYS–8
  monitored SERSYS–47
  protocol, low-level INCUST–527
  server INTPLA–19
  servers SERSYS–7
  TCP/IP INCUST–527
  variable data (DOS) INCUST–223, INCUST–227
  with host INTPLA–29, SERSYS–31
  X.25 SERSYS–31
Communications Server for OS/2 Warp INTPLA–21
Communications Server for Windows NT INTPLA–21
Communications Server
  books INCUST–587, INTPLA–153, PRODET–299, PROGDE–227, PROGREF–707, SERSYS–279
  for OS/2 Warp INCUST–89, SERSYS–43
  for Windows NT SERSYS–15
  OS/2 INCUST–87
  Windows NT INCUST–127, INCUST–129
communications
  conversation SERSYS–24
compatibility SERSYS–212
compatibility of LANDP 3270 emulator HLLAPI with other 3270 emulator APIs PROGREF–653
compilers
  DOS INTPLA–78
  OS/2 INTPLA–81
  Windows NT INTPLA–83
compiling application programs PROGDE–14
component verification SERSYS–233
compress data (CM) function in SNA compression server exit PROGREF–71
compression of data with DOS PROGREF–68
compression server INTPLA–25, PROGREF–69, SERSYS–22
compression server loading statement (DOS) INCUST–204

compression server, LANDP for DOS SNA PRODET–130
compression server
return codes PRODET–130
CONFIG.SYS INCUST–226
CONFIG.SYS (DOS)
example INCUST–197
CONFIG.SYS file
NLS support SERSYS–70
SHELL statement SERSYS–58
CONFIG.SYS
contents modifications (DOS) INCUST–197
contents modifications (OS/2) INCUST–99
DOS INCUST–197, INCUST–201
files INCUST–197
hard disks INCUST–197
modifications for emulators INCUST–195
modifying contents (DOS) INCUST–197
modifying contents (OS/2) INCUST–99
OS/2 INCUST–99, INCUST–103
performance INCUST–197
shared-file server INCUST–197
statements required for using expanded memory (DOS) INCUST–217
UMB INCUST–218
upper memory block INCUST–218
CONFIGUR. INCUST–114, INCUST–151, INCUST–182, INCUST–208
configuration data
editing INCUST–413
introduction INCUST–413
vector editing INCUST–413
configuration files
communication variable data INCUST–223
installing INCUST–228
configuration vectors PRODET–xi
configuration vectors
editing tool INCUST–415
EDITSPC command INCUST–415
GENSPEC command INCUST–416
one by one (model) INCUST–522
one by one (workgroup) INCUST–417
configuration, examples INCUST–277
configurations, LANDP INTPLA–65
configuring DLC buffers INTPLA–22, SERSYS–17
connectivity programming request block
definition of PROGDE–3
use with RMTREQ PROGDE–32
contention (in program-to-program communication server) PROGREF–105, PROGREF–106
control functions (in system manager server) PROGREF–462
controlling functions INTPLA–39, SERSYS–140
conventional LU application custom feature (LUA) INTPLA–21, SERSYS–14, SERSYS–16
conventions, in this book PRODET–viii, PROGREF–xxvi
conversation, LANDP SERSYS–24
conversion, ASCII to EBCDIC SERSYS–49
conversion, ASCII to EBCDIC
translation mode in RCMS SERSYS–49
copies of database SERSYS–107
coprocessor, LANDP for DOS X.25 adapter trace PRODET–19
copy service in 3270 emulator PROGREF–606, PROGREF–639
copy text (CT) function in DDE access server PROGREF–449
copying files
from shared disk INCUST–80
onto the shared disk INCUST–79
correlation tables INCUST–93, INCUST–133
COS2PRT.SYS INCUST–101
COUNTRY command INCUST–195
CP (change LU priority) function in local resource manager PROGREF–529
CP (change password) function in system manager server PROGREF–463
CPI keyword
FORM4710 vector INCUST–320
FORM4720 vector INCUST–324
FORM4748 vector INCUST–342
FORM47X2 vector INCUST–331
CPRB
use with RMTREQ PROGDE–32
CQ (close query mode) function in ODBC query server. PROGREF–368
CQ (close query mode) function in query server PROGREF–319
CREADB.BAT INCUST–139, INCUST–197
CREADB.CMD INCUST–99
CREATE command INCUST–298
create index (DI) function in query server PROGREF–333
CREATE utility program
Generating common data default definitions INCUST–35
creating common vectors, sample INCUST–279
creating diskettes, shared DOS directory server
command INCUST–71
EHCDISTR INCUST–71
procedure INCUST–71
creating partial SPC files INCUST–29
critical errors, LANDP for DOS
shared-file servers PRODET–200
critical errors, LANDP for Linux
shared-file servers PRODET–201
critical errors, LANDP for OS/2
shared-file servers PRODET–201
critical errors, LANDP for Windows
shared-file servers PRODET–201
cryptographic interface PROGREF–75, SERSYS–19
cryptographic interface
example of SNA session-level encryption PROGREF–85
return codes PRODET–131
SNA session-level encryption PROGREF–85
cryptography interface
errors SERSYS–38
LANDP for OS/2 SNA server SERSYS–47
server-controlled SERSYS–47
SNA session level SERSYS–47
cryptography
books INCUST–586, INTPLA–152, PRODET–298, PROGDE–226, PROGREF–706, SERSYS–278
LANDP cryptographic interface INTPLA–22
management, installation requirements INCUST–93
CS (set communication status) function in store-for-forwarding server PROGREF–410
CT (copy text) function in DDE access server PROGREF–449
ctrl-print screen SERSYS–74
current owner of print port SERSYS–74
current pointer SERSYS–79
current version SERSYS–232
CUSPARM.LST
creating diskettes INCUST–72
getting INCUST–69
listing internal repository INCUST–239
migration INCUST–235
validating common vectors INCUST–280
validating workgroup vectors INCUST–282
validation INCUST–58
customization return codes
attention INCUST–56
error INCUST–56
informative INCUST–56
severe INCUST–56
warning INCUST–56
customization vectors, editing INCUST–41
customization
common data INCUST–26
configuration data, editing INCUST–413
configuration vectors, editing INCUST–413
customization data migration INCUST–231
customization vectors, editing INCUST–41, INCUST–55
customization vectors, editing tasks INCUST–33
data structure INCUST–26
directory structure INCUST–27
editing common data INCUST–297
editing customization vectors INCUST–297
editing tool INCUST–41
embedded files INCUST–29
graphical editor INCUST–255
guideline through the steps INCUST–31
installation INCUST–7
installing LANDP INCUST–7
introduction INCUST–3

customization *(continued)*
migrating customization data INCUST–231
migration return codes INCUST–232
model configuration data INCUST–26
objectives INCUST–32
partial files INCUST–29
program, FBSS INCUST–231
remote INCUST–29
remote customization INCUST–29
step-by-step INCUST–30
steps INCUST–25
user server INCUST–297
vectors, editing INCUST–41, INCUST–55
workgroup configuration data INCUST–26
workgroup vectors INCUST–416
CW (commit work) function in ODBC query server. PROGREF–368
CW (commit work) function in query server PROGREF–319

D

D
session number INCUST–497
DA (deallocate physical electronic journal) function in electronic journal server PROGREF–394
data compression (CM function) PRODET–130
data compression with DOS PROGREF–68
data compression with DOS
compression (CM) function in SNA compression server exit PROGREF–71
decompression (UC) function in SNA compression server exit PROGREF–71
data input, arm PIN pad or MSR (AR) function PROGREF–228
data insertion (ID) function in DDE access server PROGREF–438
data interchange, TCP/IP INCUST–529
data link control SERSYS–8
data link control
support SERSYS–8
data link
buffer pools SERSYS–11
data maintenance, workgroup INTPLA–39
data management servers INTPLA–12, INTPLA–31
data management servers
ODBC query server PROGREF–353
query server PROGREF–301
data management
servers SERSYS–77
data received (DR) function in EXFS user-written exit server PROGREF–663
data request (RD) function in DDE access server PROGREF–447
data required when reporting problems PRODET–54
data security protocol (SNA server) PROGREF–41
data stream
3270 extended PROGREF–655
PIN pad PROGREF–227
data validation, application INCUST–398
data, get (GD) function in DDE access server PROGREF–437
data, passing through the API PROGDE–10
data, read (RD) function in financial printer server PROGREF–160
data, read (RD)
function in 4748 printer server PROGREF–185
data, receive (RD) function in PPC server PROGREF–115
data, retrieve application program (GU) function in system manager server PROGREF–477
data, send (SD) function in PPC server PROGREF–116
data, update application program (SU) function in system manager server PROGREF–482
data
distribution INTPLA–41, SERSYS–47
getting in link format from clipboard SERSYS–191
maintenance, workgroup SERSYS–140
translation SERSYS–51
validation INTPLA–39, SERSYS–140
DATA0X to DATAFX keywords
COLSQTBL vector INCUST–303
XLATETBL vector INCUST–408
database access, relational INTPLA–19
database description INCUST–390
database server problems PRODET–69, PRODET–76
Database Server support (OS/2 Warp) PROGREF–301
database, change (CD) function in ODBC query server. PROGREF–360
database
access, relational SERSYS–7
copies SERSYS–107
description file SERSYS–80
disjoint SERSYS–105
datagram INCUST–527
DATASETS keyword
EJOUPRF vector INCUST–315
SFORWPRF vector INCUST–387
date and time synchronization INTPLA–39, SERSYS–140
DB/2 database support PROGREF–301
DB2 for OS/2 INCUST–xxiv, INTPLA–xii, PRODET–viii, PROGDE–xiii, PROGREF–xxvii, SERSYS–xiv
DB2 Universal Database INCUST–xxiv, INTPLA–xii, PRODET–viii, PROGDE–xiii, PROGREF–xxvii, SERSYS–xiv
DB2
OS/2 support INTPLA–81
tuning for ODBC Query Server INCUST–245
DBBACKUP utility SERSYS–98
DBCS mode INCUST–308
DBCS support INCUST–308, INCUST–385
DBCS
3270 distribution INTPLA–53
and 3270 emulator SERSYS–33
KS (Korean Standard) codes SERSYS–72
Linux workstations INTPLA–117
mode restrictions INTPLA–115
mode restrictions
batch machine operator SERSYS–197
shared-file server SERSYS–87
support INTPLA–14, INTPLA–115
workgroups INTPLA–117
DBCSCTRY keyword, DEFAULTS vector INCUST–308
DBCSPATH keyword, DEFAULTS vector INCUST–309
DBCSXLAT keyword, LWSCONF vector INCUST–429
DBD INCUST–390
DBD file SERSYS–80
DBDNAME keyword, SHFLDBD vector INCUST–391
DBDPATH keyword
EJOUPRF vector INCUST–316
SFORWPRF vector INCUST–388
SHFLDBD vector INCUST–392
DBDPATH6 keyword, SHFLDBD vector INCUST–392
DBDPATH6 keyword
EJOUPRF vector INCUST–316
SFORWPRF vector INCUST–388
DBFLNAME keyword, SHFLDBD vector INCUST–393
DBLLINE keyword, FORM47X2 vector INCUST–331
DBLREC keyword
FORM4720 vector INCUST–324
FORM4748 vector INCUST–342
FORM47X2 vector INCUST–331
DBLSTRK keyword
FORM4748 vector INCUST–342
FORM47X2 vector INCUST–332
DBN INCUST–228
DBRESTOR utility SERSYS–99
DCA DLC
DCA DLC information, LANDP for DOS PRODET–26
DCA DLC trace, LANDP for DOS PRODET–24
DCADLC SERSYS–8
DCE
books SERSYS–278
clients
integration INCUST–433
servers
definitions INCUST–285
dczyxsvp file SERSYS–233
DD (define DBD) function in query server PROGREF–332
DDCS/2 INTPLA–81
DDE access server
loading statement (OS/2) INCUST–106
return codes PRODET–133
DDE
access server SERSYS–190

DDT (trace tools), start PROGREF–10
DDT.EXE INCUST–212
DDT.EXE
  loading statement (DOS) INCUST–212
deactivate and activate timers (T0–T8) supervisor local function PROGREF–21
deactivate and activate timers (T0–T8) supervisor local function
  used in sample application PROGDE–163
deadlock detection SERSYS–78
deallocate physical electronic journal (DA) function PROGREF–394
DEBUGHK keyword, DEFAULTS vector INCUST–305
DECIMALS keyword, RECFIELD vector INCUST–385
decipher (cryptographic interface return codes) PRODET–131
decompress data (UC) function in SNA compression server exit PROGREF–71
decompression (UC function) PRODET–130
decrypt (X'0031') in cryptographic interface PROGREF–81
decryption (cryptographic interface return codes) PRODET–131
decryption and encryption books INCUST–586, INTPLA–152, PRODET–298, PROGDE–226, PROGREF–706, SERSYS–278
DECSEP keyword, RECDEF vector INCUST–383
default parallel attached printers INCUST–156
DEFAULTS keyword, LANCONF vector INCUST–418
DEFAULTS vector INCUST–303
DEFAULTS vector
  example INCUST–309
  quick reference INCUST–304
DEFCCHR keyword, P3287ATT vector INCUST–377
DEFCOLRS keyword, DISPLATT vector INCUST–311
defect, reporting program PRODET–53
define DBD (DD) function in query server PROGREF–332
define index (DI) function in query server PROGREF–333
define PCB (DP) function in query server PROGREF–334
defined record structures, retrieving INTPLA–39, SERSYS–140
defined users list, retrieve (RE) function in system manager server PROGREF–467
defined users, listing SERSYS–141
defining DLC buffers INTPLA–22
defining jobs (batch machine operator) SERSYS–196
defining
  aliases SERSYS–49
  DLC buffers SERSYS–17
  print formats SERSYS–69
definitions of terms INCUST–557, INTPLA–123, PRODET–269, PROGDE–197, PROGREF–677, SERSYS–249
DEFSERV vector INCUST–285
DELAY keyword, MSRINTBL vector INCUST–373
DELETE command SERSYS–56
Delete record (DL) function
  electronic journal server PROGREF–394
delete row (DR) function in ODBC query server. PROGREF–370
delete row (DR) function in query server PROGREF–321
delete user in user profile file (DU) function in system manager server PROGREF–477
deleting files (batch machine operator) SERSYS–197
DELIMIT keyword, RECDEF vector INCUST–383
density mode of printing, change (CM) function in local resource manager PROGREF–528
describe query (DQ) function in ODBC query server. PROGREF–369
describe query (DQ) function in query server PROGREF–320
describe table (DT) function in ODBC query server. PROGREF–370
describe table (DT) function in query server PROGREF–321
DESCRIPT keyword, RECFIELD vector INCUST–385
destination batch machine (batch machine operator) SERSYS–196
DETACH command (OS/2) INCUST–104
developing applications INTPLA–7
development site INCUST–7
device cluster attachment DLC server
  buffers, number INCUST–441
  configuration definitions INCUST–441
  retries, maximum number INCUST–441
  time-out INCUST–442
DEVICE command INCUST–195
device drivers INCUST–11, INCUST–13, INCUST–15, INCUST–16
device drivers for LANDP for Windows INCUST–11
device drivers, how to get INTPLA–13, INTPLA–43, INTPLA–94
device servers SERSYS–67
device servers, events from PROGREF–26
device services in 3270 emulator PROGREF–646
DEVICE vector INCUST–289
DEVPARM instruction INCUST–301
DHCP (Dynamic Host Configuration Protocol) INCUST–529
DI (define index) function in query server PROGREF–333
diagnostic and debugging tool server using PRODET–11
diagnostic and debugging tool
  description of PRODET–9
diagnostic and trace tools INTPLA–15
diagnostic tools, overview PRODET–3
direct access method (in shared-file server) PROGREF–255
direct access, shared-file SERSYS–78
direct indexed access SERSYS–79
direct indexed access method (in shared-file server) PROGREF–255
directory tasks SERSYS–132
DIRNAME keyword, X25DIR vector INCUST–410
disable storing (DS) function in store-for-forwarding server PROGREF–412
disconnection
  application program (EJ) supervisor local function PROGREF–11
disjoint database data SERSYS–105
disk space management SERSYS–79
DISPLACE keyword
  FORM4720 vector INCUST–324
  FORM4748 vector INCUST–342
  FORM47X2 vector INCUST–331
DISPLATT vector INCUST–310
DISPLATT vector
  example INCUST–314
  quick reference INCUST–311
display attributes, 3270 SERSYS–32
display characteristics, 3270 SERSYS–31
display messages for the operator SERSYS–159
display modes, 4707 SERSYS–224
display program, general description of trace tool PRODET–4
display routines trace active or inactive, LANDP for DOS PRODET–37
display support, 4707 SERSYS–224
display system status and enter commands SERSYS–149
display, monochrome, 4707 INTPLA–54
display, write (WD) function in PIN pad server PROGREF–249
displaying trace files and records
  LANDP for OS/2 PRODET–44
  LANDP for Windows PRODET–44
displaying trace files
  LANDP for DOS PRODET–14
displaying
  server status SERSYS–233
dissociate semaphore (DS) supervisor local function PROGREF–9
DISTRIB vector INCUST–290
distributed database SERSYS–105
Distributed Database Connection Services/2 INTPLA–81
Distributed Relational Database Architecture SERSYS–109
Distributed Relational Database Architecture (DRDA) PROGREF–301
distributing production data INTPLA–41, SERSYS–47
distributing simultaneously, GETTING parameter INCUST–69
distributing software INCUST–67
distributing software
  distribution server INCUST–68, INCUST–77

distributing software *(continued)*
EHCADD INCUST–73
EHCAPPEN INCUST–74
GETTING INCUST–67
GETTING.SPC INCUST–67
obtaining software INCUST–61
sample INCUST–283
shared DOS directory server INCUST–67, INCUST–70
shared DOS directory server
GETDATA command INCUST–73
procedure INCUST–73
to a Linux workstation INCUST–68
distribution server INCUST–77
distribution, binary/test files SERSYS–49
distributor server SERSYS–105
distributor server, shared-file PROGREF–258
DL function
electronic journal server PROGREF–394
DLC INTPLA–20, SERSYS–8
DLC buffer definition INTPLA–22, SERSYS–17
DLC keyword, LUPOOL vector INCUST–372
DLC
asynchronous operation INTPLA–22
buffers INTPLA–22
LANDP support for DOS INTPLA–20
LANDP support for Windows INTPLA–21
DLL (dynamic link library) PROGDE–15, PROGDE–18
document printer server SERSYS–68
documentation, LANDP PRODET–viii
DOS box (VDM) INTPLA–54, PROGDE–47, PROGREF–555, SERSYS–226
DOS box
DOS (VDM) for Windows INCUST–157
for OS/2 (VDM) INCUST–91
DOS compression server exit PROGREF–68
DOS EXEC facility SERSYS–211, SERSYS–212
DOS office direct connect SERSYS–212
DOS, use of native system functions PROGDE–2
DOS/V DBCS mode INTPLA–116
DOS
box (OS/2) INCUST–121
communication supports INTPLA–78
compilers INTPLA–78
DOS workstations INCUST–189
installation path INCUST–219
operating system INTPLA–78
path, installation INCUST–219
TCP/IP INCUST–191
DosBox (LANDP for Linux) PROGREF–563
DOSEMU PROGREF–563
DOSEMU (LANDP for Linux) INCUST–174
double-byte character set INTPLA–115
download code pages SERSYS–69
download user characters (DU) function in financial printer server PROGREF–155
download user-defined characters (LD) function in 4748 printer server PROGREF–169
DP (define PCB) function in query server PROGREF–334
DQ (describe query) function in ODBC query server PROGREF–369
DQ (describe query) function in query server PROGREF–320
DR (data received) function in EXFS user-written exit server PROGREF–663
DR (delete row) function in ODBC query server. PROGREF–370
DR (delete row) function in query server PROGREF–321
DRDA SERSYS–109
DRDA (Distributed Relational Database Architecture) PROGREF–301
DS (disable storing) function in store-for-forwarding server PROGREF–412
DS (dissociate semaphore) supervisor local function PROGREF–9
DSA SERSYS–190
DSPRTY keyword, FORWPRF vector INCUST–355
DT (describe table) function in ODBC query server. PROGREF–370
DT (describe table) function in query server PROGREF–321
DU (delete user in user profile file) function in system manager server PROGREF–477
DU (download user characters) function in financial printer server PROGREF–155
duplicate workstation identifier (WSID) LWSCONF vector INCUST–421
DXM..MOD.SYS INCUST–19
dynamic data exchange INTPLA–49, SERSYS–190
Dynamic Host Configuration Protocol (DHCP) INCUST–529
dynamic link library (DLL) PROGDE–15, PROGDE–18
dynamic logging SERSYS–80

E

E3270HK1-E3270HK5 keywords, DEFAULTS vector INCUST–306
E3287SI1-5 keywords, DEFAULTS vector INCUST–308
EA (EBCDIC-ASCII translation) routine PROGREF–573
EADATA0X-FX keywords, XLAT2TBL vector INCUST–409
EAEXTEN keyword, KBDBIWP vector INCUST–366
EBCDIC data SERSYS–49
EBCDIC MLP code page 500 SERSYS–235
EBCDIC to ASCII translation INTPLA–22
EBCDIC-to-ASCII translation SERSYS–18
EBCDIC/ASCII translation table SERSYS–45
EBCDIC/ASCII
data translation INTPLA–22
translation server INTPLA–116
EBCDICXL keyword, FORWDS vector INCUST–352
EC (end connection) function in local resource manager PROGREF–519
EC (execute command) function in DDE access server PROGREF–444
ED (erase DBD) function in query server PROGREF–335
editing INCUST–416
editing
model configuration data and model vectors INCUST–521
tool
customization INCUST–41, INCUST–297, INCUST–415
validation INCUST–58
workgroup vectors, sample INCUST–280
editor specifications INCUST–41
EDITSPC INCUST–297, INCUST–414
EDITSPC COMMON INCUST–297
EDITSPC.CMD
creating INCUST–414
editing INCUST–414
editing common vectors INCUST–297
editing configuration vectors INCUST–414
editing tool INCUST–41
EE (simulate hot-key) supervisor local function PROGREF–10
EHC_GETREQ_OPTS structure in calls PROGDE–56
EHC_GETRPLY_OPTS structure in calls PROGDE–37
EHC_NOWAIT_PARM structure in calls PROGDE–35, PROGDE–37
EHC_RESERVED field in calls PROGDE–25, PROGDE–32
EHC_RMTREQ_OPTS structure in calls PROGDE–34
EHC_SRVINIT_OPTS structure in calls PROGDE–54
EHC#ALRU.DAT file PROGREF–501
EHC#RESU.DAT file PROGREF–501
EHCADD INCUST–73
EHCALRH user exit (in system manager server) PROGREF–503
EHCAPLVM.BAT INCUST–196
EHCAPPEN INCUST–74
EHCBOXM.EXE monitor program PROGREF–555
EHCBOXS.CFG file PROGREF–557, PROGREF–564
EHCCINFO INCUST–202
EHCCINFO.EXE utility program SERSYS–233
EHCCINST INCUST–80
EHCCOMP (SNA compression server exit) PROGREF–70
EHCCOMP.EXE INCUST–204
EHCCONN SNA connection program PROGDE–23, PROGREF–54

EHCCUS INCUST–28
EHCCUS
  COMMON.SPC INCUST–38, INCUST–237
  LANCONF.SPC INCUST–39, INCUST–237
EHCDBTR (ASCII-EBCDIC translation server) PROGREF–569
EHCDBTR.EXE INCUST–204
EHCDEFC.INC include file PROGDE–24
EHCDEFP.INC include file PROGDE–9, PROGDE–14
EHCDISTR INCUST–71
EHCDOS.LIB library file PROGDE–14, PROGDE–31
EHCDOSQ SERSYS–242
EHCDOSQ program for SQL tables PROGDE–29
EHCDOSVM.BAT INCUST–196
EHCDOSVM.PIF INCUST–196
EHCDOSXM.LIB library file PROGDE–14, PROGDE–31
EHCEXITS.C user exit PROGREF–557, PROGREF–564
ehcfree LANDP for Linux utility INCUST–187
EHCFREE.EXE LANDP for OS/2 utility INCUST–125
EHCFREE.EXE LANDP for Windows utility INCUST–160
EHCHELP directory INCUST–53
EHCIMAGE INCUST–79
EHCIN initialization program PROGDE–23
EHCINFO INCUST–104, INCUST–141, INCUST–177
EHCINFO program PROGREF–14
EHCINFO.EXE utility program SERSYS–233
EHCLAD (DDE access server) PROGREF–436
EHCLAD.EXE INCUST–106
ehclink INCUST–180
EHCLINK.EXE INCUST–108, INCUST–145
ehclip INCUST–179
EHCLIP program
  return codes PRODET–155
EHCLIP.EXE INCUST–108, INCUST–145, INCUST–205
EHCLIP
  description of, LANDP for DOS PRODET–35
  error codes, LANDP for DOS PRODET–36
  loading parameters PRODET–49
  statistics codes, LANDP for DOS PRODET–36
  TCP/IP tools, using with PRODET–36
EHCLIST INCUST–239
EHCLOGxx.DAT INCUST–104
EHCLRMGR (local resource manager) PROGREF–518
EHCLRMGR.EXE INCUST–206
EHCMGR1 SERSYS–240
EHCMGR1 migration program PROGDE–29
EHCMGR2 SERSYS–243
EHCMGR2 migration program PROGDE–29
EHCMGROS SERSYS–242
EHCMGROS migration program PROGDE–29
EHCODB## (ODBC query server) PROGREF–359
EHCOS2.DLL dynamic link library file PROGDE–15, PROGDE–26
EHCOS2.LIB library file PROGDE–14
EHCOS216.LIB library file PROGDE–14
EHCOS232.LIB library file PROGDE–14
EHCOS2Q SERSYS–242
EHCOS2Q program for SQL tables PROGDE–29
EHCPDT program, using PRODET–44
ehcplug.c PROGREF–563
EHCPREV.BAT INCUST–196
EHCRCMS.LOG SERSYS–63
EHCRCMS.MSG SERSYS–63
EHCREL SNA release program PROGDE–23
ehcrstml
  Linux LANDP restart INCUST–176
EHCSAM (system availability manager) INTPLA–32
EHCSAM, service availability manager SERSYS–187
EHCSAM.EXE
  loading statement (OS/2) INCUST–113
  loading statement (Windows) INCUST–150
EHCSFD## (shared-file distributor server) PROGREF–262
EHCSFD##.EXE INCUST–114
EHCSFR## (shared-file replicator server) PROGREF–262
EHCSFR##.EXE INCUST–114
EHCSFRPC.PCN INCUST–464
EHCSQL ##
  return codes PRODET–184
EHCSQL server migration SERSYS–237
EHCSQL## (query server) PROGREF–310
EHCSQL##.EXE INCUST–111
EHCSVPUE exit server PROGDE–113
EHCTRACF program, using PRODET–49
ehctracw INCUST–185
EHCTRACW server PRODET–40
EHCTRACW.EXE INCUST–119, INCUST–154
EHCTRACW
  loading PRODET–40
EHCTRALL program, using PRODET–14
EHCTRAN (CICS interface server) PROGREF–428
EHCTRAN.EXE INCUST–106
EHCUSER.CFG file for server-to-server calls PROGDE–68
EHCVAL program, loading messages PRODET–221
EHCVAL.EXE INCUST–229
ehcvdmgr PROGREF–563
EHCVDMGR.EXE INCUST–120, INCUST–155, INCUST–186, PROGREF–556
EHCVDMGR.EXE server PROGREF–555
ehcvdmir PROGREF–563
EHCVDMIR.EXE PROGREF–556
EHCVDMVD.SYS driver program PROGREF–555
EHCVDSPV.COM PROGREF–556, PROGREF–563
EHCVDSPV.COM (LANDP for Linux) INCUST–174
EHCVDSPV.COM (LANDP for Windows) INCUST–136
EHCVDVXD.DLL PROGREF–556
EHCWIN.DLL INCUST–98
EHCWINNT library file (LANDP for Windows) PROGDE–31
EHCWINNT.DLL dynamic link library file PROGDE–18
EHCWINNT.DLL, loading INCUST–14
EHCWINNT.DLL
  loading INCUST–138
EHCWINNT.OMF library file PROGDE–14
EHCWINNT.VC5 library file PROGDE–14
EHCWINNT.VC5 library file (LANDP for Windows) PROGDE–31
EHCWINNT.VC6 library file PROGDE–14
EHCWINNT.VC6 library file (LANDP for Windows) PROGDE–31
EHCWVDMI INCUST–196
EHLLAPI SERSYS–43
EI (end operator intervention) function in local resource manager PROGREF–531
EI (erase index) function in query server PROGREF–336
EJ (disconnect an application program) supervisor local function PROGREF–11
EJ1 alert, unsuccessful call to shared-file server
  LANDP PRODET–233
EJOU.PRN INCUST–228
EJOUPRF vector INCUST–314
EJOUPRF vector
  example INCUST–317
  quick reference INCUST–315
EJOUREC vector INCUST–317
EJOUREC vector
  example INCUST–318
  quick reference INCUST–318
EJUTIL.EXE program for electronic journal data sets SERSYS–122
elecjo## INCUST–178
ELECJO## (electronic journal server) PROGREF–390
ELECJO##.EXE INCUST–106, INCUST–143, INCUST–204
electronic journal server INTPLA–35, SERSYS–118
electronic journal server utility SERSYS–122
electronic journal server
  configuration definitions INCUST–442
  data access INCUST–315
  data and index files INCUST–316
  data integrity SERSYS–120
  data sets INCUST–315
  database error messages PROGREF–392

electronic journal server *(continued)*
DBCS mode restrictions SERSYS–122
environments SERSYS–121
files SERSYS–119
keys INCUST–317
loading statement (DOS) INCUST–204
loading statement (Linux) INCUST–178
loading statement (OS/2) INCUST–106
loading statement (Windows) INCUST–143
maximum record size INCUST–442
profile INCUST–314, INCUST–442
record INCUST–316, INCUST–318
return codes PRODET–136
search operations SERSYS–122
server functions PROGREF–392
server utility SERSYS–122
using the server PROGREF–390
Electronic journal server
alerts PRODET–233
EJ1 alert, unsuccessful call to shared-file server PRODET–233
EJ1—Unsuccessful call to shared-file server PRODET–233
EM1—Data stream error
alerts PRODET–236
embedding SPC files INCUST–29
EMM INCUST–215
EMPHASIZ keyword
FORM4748 vector INCUST–342
FORM47X2 vector INCUST–332
EMU3270.EXE INCUST–122, INCUST–158, INCUST–212
EMU3287 and EMU3287R INTPLA–29
EMU3287.EXE INCUST–123, INCUST–159, INCUST–214
emulate hot-key (EE) supervisor local function PROGREF–10
emulator considerations (DOS) INCUST–195
emulator
3287 INTPLA–29, SERSYS–44
print modes SERSYS–44
support INTPLA–11, INTPLA–29, SERSYS–31
EN (enable storing) function in store-for-forwarding server PROGREF–412
enable storing (EN) function in store-for-forwarding server PROGREF–412
encipher (cryptographic interface return codes) PRODET–131
encrypt (X'0030') in cryptographic interface PROGREF–80
encrypting SNA session data INTPLA–22, SERSYS–19
encryption (cryptographic interface return codes) PRODET–131
encryption and decryption
books INCUST–586, INTPLA–152, PRODET–298, PROGDE–226, PROGREF–706, SERSYS–278
end an application program (EJ) supervisor local function PROGREF–11
end connection (EC) function in local resource manager PROGREF–519
end operator intervention (EI) function in local resource manager PROGREF–531
end query (EQ) function in ODBC query server. PROGREF–371
end query (EQ) function in query server PROGREF–322
end transmission (TE) function in store-for-forwarding server PROGREF–419
entries, LANDP for OS/2 error log PRODET–41
EP (erase PCB) function in query server PROGREF–336
EPM.EXE INCUST–41
EQ (end query) function in ODBC query server. PROGREF–371
EQ (end query) function in query server PROGREF–322
erase DBD (ED) function in query server PROGREF–335
erase index (EI) function in query server PROGREF–336
erase PCB (EP) function in query server PROGREF–336
error codes
LANDP for DOS PRODET–36, PRODET–123
LANDP for Linux PRODET–123
LANDP for OS/2 PRODET–123
LANDP for Windows PRODET–123
error log entries, LANDP for OS/2 PRODET–41
error logging, LANDP for Linux PRODET–40
error logging, LANDP for OS/2 PRODET–40
error logging, LANDP for Windows PRODET–40
error logging
MQSeries Link Server PRODET–51
error number and message tables (in system manager server) PROGREF–507
errors, external communication, TCP/IP and LIP
LANDP for DOS PRODET–36
LANDP for OS/2 PRODET–50
ES (end of service) PROGDE–60
ES (end of service) &finals.
used in sample application PROGDE–146
ES (unload LANDP) supervisor local function PROGREF–12
ES (unload LANDP)
supervisor local function PROGREF–12
ESC/P printers for People's Republic of China PROGREF–657
Ethernet support INCUST–419
euro currency INTPLA–17
event codes, notation for PROGDE–xii, PROGREF–xxvii
event notification PROGDE–39
event notification support INTPLA–10
event notification
event codes PROGDE–xii, PROGREF–xxvii
I/O device servers PROGREF–26
multiple events PROGDE–41
polling asynchronous events PROGDE–42
event query (QE) supervisor local function PROGREF–17
event tracing, LANDP for Linux PRODET–41
event tracing, LANDP for OS/2 PRODET–41
event tracing, LANDP for Windows PRODET–41
event types, system and server PROGDE–39
event-driven applications PROGDE–66
examples
4712/4722 printer in passbook mode PROGREF–154
4748 printer sharing PROGREF–169
asynchronous event codes PROGDE–xiii, PROGREF–xxvii
autofbss, Linux INCUST–177
AUTOFBSS.BAT, DOS INCUST–202
AUTOFBSS.BAT, Windows INCUST–140
AUTOFBSS.CMD, OS/2 INCUST–103
CONFIG.SYS (DOS) INCUST–197, INCUST–217
configuration INCUST–277
configuration, PS/2 Model 70 INCUST–217
cryptographic interface PROGREF–85
DOS
sample client program (COBOL) PROGDE–160, PROGDE–170
electronic journal, physical PROGREF–381
electronic journal, searching PROGREF–388
function codes PROGDE–xiii, PROGREF–xxvii
LANDP configuration INCUST–277
listed and annotated PROGDE–170
ODBC query server PROGREF–355
OS/2
LANDP application (COBOL) PROGDE–140, PROGDE–159
sample client program (COBOL) PROGDE–160, PROGDE–170
query server PROGREF–304
return codes PROGDE–xiii, PROGREF–xxvii
sample application programs PROGDE–119
servers listing, workgroup configuration INCUST–240
services listing, workgroup configuration INCUST–241
shared-file server PROGREF–296
SNA server PROGREF–71
SNA session-level encryption PROGREF–85
tutorial PROGDE–170

examples *(continued)*
Win32 API
LANDP application (C) PROGDE–119
Windows
LANDP application (COBOL) PROGDE–140, PROGDE–159
exchanging data with host INTPLA–29, SERSYS–31
exclusive mode, set (SE) function in local resource manager PROGREF–544
exclusive print mode SERSYS–73
exclusive use of record (in shared-file server) PROGREF–276
execute command (EC) function in DDE access server PROGREF–444
EXFS user server support INCUST–124
exit to idle status (EX) function in FBSS PROGDE–48
expanded memory INCUST–215
expanded memory (LANDP for DOS) PROGDE–70
expanded memory manager (EMM) INCUST–215
expanded memory specification (LIM) INCUST–215
expanded memory, using INTPLA–79
expanded memory
LOADERE INCUST–215
software requirements INCUST–217
user servers INCUST–218
EXPMEM keyword, SVRMODEL vector INCUST–526
EXTEN keyword
DISPLATT vector INCUST–311
KBD3270 vector INCUST–360
KBD3270X vector INCUST–363
KBDBIWP vector INCUST–366
KSCCBIWP vector INCUST–369
KSTRBIWP vector INCUST–370
MSRINTBL vector INCUST–373
MSROUTBL vector INCUST–375
P3287ATT vector INCUST–377
PINPTBL vector INCUST–378
XLAT2TBL vector INCUST–409
XLATETBL vector INCUST–407
extended 3270 color attributes INCUST–311
extended 3270 data stream PROGREF–655
extended logging replicator (XLR)
dynamic reconfiguration of XLR servers SERSYS–187
maintaining state information for XLR servers SERSYS–187
message broadcast facility. SERSYS–188
external call interface (CICS) PROGREF–427
external communication errors, TCP/IP and LIP
LANDP for DOS PRODET–36
LANDP for OS/2 PRODET–50
external logging replicator (XLR) INTPLA–32, SERSYS–78, SERSYS–88, SERSYS–92
external logging replicator (XLR)
effect on applications of XLR takeover SERSYS–90
log files SERSYS–90
messages SERSYS–89
relationship between components SERSYS–90
servers in an XLR configuration SERSYS–88
service availability manager (EHCSAM) SERSYS–89
external logging replicator
configuration data, shared-file server INCUST–467, INCUST–468

F

facilities INTPLA–14, SERSYS–199
facilities
3270 send/receive SERSYS–214, SERSYS–215
3270 send/receive facility INTPLA–53
4707 monochrome display support INTPLA–54
file transfer commands SERSYS–201
VDM INTPLA–54
virtual DOS machines INTPLA–54
Windows 3.1 support SERSYS–227
family messages, list of LANDP PRODET–221, PRODET–231
family, LANDP INTPLA–3
FBHLLAPI resident module PROGREF–616
FBSI SERSYS–8
FBSI restriction, Windows INTPLA–15
FBSI/2 switch printer mode (Z6 function) PROGREF–671
FBSS
books INCUST–583, INTPLA–149, PRODET–295, PROGDE–223, PROGREF–703, SERSYS–275
customization program INCUST–231
FBSS#GDT INCUST–229
FBSS#USP INCUST–229
FBSSBDV procedure INCUST–21
FBSSCUS INCUST–233
FBSSGLUS INCUST–398
FBSSPATH.DAT INCUST–229
FBSSUSPR INCUST–398
installation INCUST–20
migrating data INCUST–231
support INTPLA–15
FBSS3270.SCN file (3270 emulator) SERSYS–42
FBSSP command SERSYS–74
fetch next record (FN) function in shared-file server PROGREF–268
fetch previous record (FP) function in shred-file server PROGREF–269
fetch row (FR) function in ODBC query server. PROGREF–372
fetch row (FR) function in query server PROGREF–323
fetch unique record (FU) function in shred-file server PROGREF–271
FF1 alert, unsuccessful call to server PRODET–235
file access SERSYS–49
file error subcodes
VARDAT PRODET–122
file locking in on-line mode (in shared-file server) PROGREF–261
file modification INCUST–73
file modification
EHCADD INCUST–73
EHCAPPEN INCUST–74
file query (QD) function in store-for-forwarding server PROGREF–414
file status setting, LANDP for Linux trace tool PRODET–41
file status setting, LANDP for OS/2 trace tool PRODET–41
file status setting, LANDP for Windows trace tool PRODET–41
file transfer facility SERSYS–200
file transfer facility messages PRODET–223
file-naming convention, program fixes INCUST–251
file
CONFIG.SYS SERSYS–70
sharing INTPLA–38, SERSYS–132
STARTUP.CMD SERSYS–70
FILENAME keyword, SOFTPACK vector INCUST–406
FILEPATH keyword, SOFTPACK vector INCUST–406
files, by name
.LGD PRODET–40
.TRP PRODET–40
TR$*xxx*A*n*.DAT PRODET–13
TR$*xxxx*n.DAT PRODET–12
files
file transfer facility INTPLA–53
transfer software, host INTPLA–86
FILESYS utility SERSYS–132, SERSYS–135
FILLER keyword, PINPTBL vector INCUST–378
financial I/O servers problems PRODET–68, PRODET–75
financial printer server INCUST–12, INCUST–14, INCUST–15, INCUST–17, SERSYS–68
financial printer server
alerts PRODET–234
default parallel attached printers INCUST–156
device name INCUST–507
DEVICE statement (DOS) INCUST–199
DEVICE statement (OS/2) INCUST–101
format definition
4009 printer PROGREF–150
4712 and 4722 printers, example in passbook mode PROGREF–154
4712, 4722, and 9068-S01 printers PROGREF–150
4722-003 printer with magnetic stripe PROGREF–154
4772 printer PROGREF–150
9068-S01 printer PROGREF–150
laser printer support INCUST–156

financial printer server *(continued)*
loading statement (DOS) INCUST–214
loading statement (Linux) INCUST–186
loading statement (OS/2) INCUST–120
loading statement (Windows) INCUST–156
MICR reader, 9069 printer PROGREF–141
port INCUST–507
port ID INCUST–506
PS1 alert, hardware error PRODET–234
return codes PRODET–141
session ID INCUST–506
financial printers SERSYS–44
fix records SERSYS–232
fixes, applying program INCUST–251
FIXSTORE directory INCUST–253
flowcharts, problem determination PRODET–64, PRODET–78
flowcharts, problem determination
load time problems
communication server PRODET–70
database server PRODET–69
financial I/O servers PRODET–68
run time problems
communication server PRODET–77
database server PRODET–76
financial I/O servers PRODET–75
FN (fetch next record) function in shared-file server PROGREF–268
FOLDADDS keyword INCUST–343
FOLDBEG keyword
FORM4720 vector INCUST–324
FORM4748 vector INCUST–343
FORM47X2 vector INCUST–332
FOLDSKIP keyword
FORM4720 vector INCUST–324
FORM4748 vector INCUST–343
FORM47X2 vector INCUST–332
FOLDTYPE keyword
FORM4720 vector INCUST–325
FORM4748 vector INCUST–343
FORM47X2 vector INCUST–332
font code page SERSYS–69
FONT keyword
FORM4748 vector INCUST–343
FORM4770 vector INCUST–349
FORM4710 vector INCUST–318
FORM4710 vector
example INCUST–321
quick reference INCUST–319
FORM4720 vector INCUST–322
FORM4720 vector
example INCUST–327
quick reference INCUST–322
FORM4748 vector INCUST–339
FORM4748 vector
example INCUST–347
quick reference INCUST–340
FORM4748
object type INCUST–341
FORM4770 vector INCUST–347
FORM4770 vector
example INCUST–351
FORM4770 vector *(continued)*
quick reference INCUST–348
FORM47X2 vector INCUST–328
FORM47X2 vector
attention INCUST–337
book width INCUST–331
example INCUST–337
line length INCUST–333
lines per inch INCUST–334
object type INCUST–330
page size INCUST–335
printing mode INCUST–332
quality print INCUST–336
quick reference INCUST–330
REMS INCUST–336
start key INCUST–336
vertical offset INCUST–336
warning INCUST–337
format definition
4722-003 printer with magnetic stripe PROGREF–154
format error subcodes
VARDAT PRODET–119
FORMAT keyword
RECFIELD vector INCUST–385
format validation, variable data INCUST–225
format, VARPARM.SPC INCUST–227
FORW.PRN INCUST–228
forward INCUST–179
forward recovery SERSYS–81
FORWARD.EXE INCUST–106, INCUST–143, INCUST–204
forwarding data set INCUST–351
forwarding priority SERSYS–129
forwarding server INTPLA–37, SERSYS–128
forwarding server
alerts PRODET–235
automatic transmission INCUST–352
block transmission INCUST–355
configuration definitions INCUST–443
data set priority INCUST–352, INCUST–355
DBCS mode restrictions SERSYS–131
field translation INCUST–352
forwarding session number INCUST–444
forwarding stored records SERSYS–126
forwarding stored records
forwarding priority SERSYS–126
forwarding sessions SERSYS–126
host applications SERSYS–127
host session identification INCUST–355
INITSELF string INCUST–356
loading statement (DOS) INCUST–204
loading statement (Linux) INCUST–179
loading statement (OS/2) INCUST–106
loading statement (Windows) INCUST–143
maximum record size INCUST–443
profile INCUST–353, INCUST–443
profile name INCUST–354
forwarding server *(continued)*
session definition INCUST–352
session device name INCUST–444
SNA LU number INCUST–444
SNA LU pool ID INCUST–444
SNA pool ID INCUST–444
transaction code INCUST–352
translation table INCUST–407, INCUST–443
transmission SERSYS–128
transmission
block transmission SERSYS–129
CICS/VS support SERSYS–129
host computer considerations SERSYS–129
IMS/MVS SERSYS–129
modes of transmission SERSYS–129
signon feature SERSYS–129
Transmission priority SERSYS–129
forwarding software requirements INTPLA–86
Forwarding, CICS INCUST–539
FORWDS vector INCUST–351
FORWDS vector
example INCUST–353
quick reference INCUST–351
FORWPRF vector INCUST–353
FORWPRF vector
example INCUST–357
quick reference INCUST–354
foundation of LANDP INTPLA–5
FP (fetch previous record) function in shred-file server PROGREF–269
FR (fetch row) function in ODBC query serverfunction in ODBC query server. PROGREF–372
FR (fetch row) function in query server PROGREF–323
FRAME keyword, LWSCONF vector INCUST–426
FREE.EXE LANDP for DOS utility INCUST–215
FU (fetch unique record) function in shred-file server PROGREF–271
function (in a server) PROGDE–1
function codes
notation for PROGDE–xii, PROGREF–xxvii
notation for operating environment PROGDE–xii, PROGREF–xxvi
function management headers protocol (SNA server) PROGREF–41
functions trace pages, number of LANDP for DOS supervisor PRODET–32
functions trace, LANDP for DOS supervisor PRODET–31
functions trace, on-request/on-completion values, LANDP for DOS supervisor PRODET–32
functions, controlling INTPLA–39, SERSYS–140
functions, system manager operator SERSYS–149

G

GA (generate message authentication code) function in PIN pad server PROGREF–240
GA (get attributes) function in PPC server PROGREF–112
Gaiji character, load user-defined (LD) function in 4748 printer server PROGREF–182
gateway INTPLA–24, SERSYS–20
gateway (SNA server) PROGREF–35
GD (get data) function in DDE access server PROGREF–437
GD (retrieve system date and time) function in system manager server PROGREF–485
generate message authentication code (GA) function in PIN pad server PROGREF–240
Generating common data default definitions
  CREATE utility program INCUST–35
generation
  command INCUST–37, INCUST–236
  customization data INCUST–37, INCUST–231, INCUST–235
  data INCUST–37, INCUST–231, INCUST–235
  GENSPEC INCUST–37, INCUST–236
  LANLIMIT.SPC INCUST–231
  procedure INCUST–37, INCUST–236
  vector format INCUST–38, INCUST–237
  vectors INCUST–37, INCUST–231, INCUST–235
generic alert architecture PRODET–7
GENLOG utility SERSYS–93
GENLOG2 query server program SERSYS–111
GENRUN INCUST–61
GENRUN procedure INCUST–65
GENSPEC INCUST–37, INCUST–236, INCUST–298, INCUST–416
get application program data (GU) function in system manager server PROGREF–477
get attributes (GA) function in PPC server PROGREF–112
get data (GD) function in DDE access server PROGREF–437
get defined record structures server functions PROGREF–493
get defined users list (RE) function in system manager server PROGREF–467
get LANDP workgroup common data (RD) function in system manager server PROGREF–489
get list of users holding locks (RK) function in system manager server PROGREF–468
get LOG record (R1) function in system manager server PROGREF–509
get LOG record (RL) function in system manager server PROGREF–507
get record format (RR) function in system manager server PROGREF–493
get signed-on PC (GP) function in system manager server PROGREF–465
get signed-on PC (Year-2000) (GW) function in system manager server PROGREF–466
get signed-on user (GI) function in system manager server PROGREF–464
get signed-on user (GL) function in system manager server PROGREF–463
get signed-on users list (GO) function in system manager server PROGREF–470
get signed-on users list (RO) function in system manager server PROGREF–469
get system date and time (GD) function in system manager server PROGREF–485
get system status (GG) function in system manager server PROGREF–487
GETDATA INCUST–73
GETGLOB INCUST–61, INCUST–65
GETREQ call PROGDE–5, PROGDE–55
GETREQ call
  used in sample application PROGDE–157
GETRPLY call PROGDE–5, PROGDE–36
GETRPLY call
  used in sample application PROGDE–149
GETTING INCUST–67, INCUST–70
getting assistance (IBM support) PRODET–53
getting customization data INCUST–61
getting LANDP device drivers INCUST–11, INCUST–14, INCUST–15, INCUST–16, INTPLA–13, INTPLA–43, INTPLA–94
getting software
  BAT file, sample INCUST–75
  CMD file, sample INCUST–75
  command INCUST–65
  GETGLOB INCUST–65
  procedure INCUST–65
getting
  procedure INCUST–68
GETTING
  GETTING.SPC INCUST–61, INCUST–67
GETTRACE program, using PRODET–14
GG (get system status) function in system manager server PROGREF–487
GI (get signed-on user) function in system manager server PROGREF–464
GL (get signed-on user) function in system manager server PROGREF–463
global data, backup SERSYS–140
glossary INCUST–557, INTPLA–123, PRODET–269, PROGDE–197, PROGREF–677, SERSYS–249
GNU C compiler
  for Linux INTPLA–85
GO (get signed-on users list) function in system manager server PROGREF–470
GP (get signed-on PC) function in system manager server PROGREF–465
graphical customization editor INCUST–255
graphical editor
  customization INCUST–255
GREEN keyword, DISPLATT vector INCUST–313
GROUP keyword, LANCONF vector INCUST–418
GROUPID keyword, LUPOOL vector INCUST–372
GU (retrieve application program data) function in system manager server PROGREF–477
GUI programs, VisualAge for COBOL PROGDE–93
guidelines for reporting problems PRODET–53
GW (get signed-on PC (Year-2000) function in system manager server PROGREF–466

H

hardware errors, alerts
  PS1 PRODET–234
header, read (RH) function in shared-file server PROGREF–290
help facility for servers INCUST–53
Hewlett Packard print mode SERSYS–44
hexadecimal codes PRODET–81, PRODET–123
high memory INCUST–218
high memory
  UMB INCUST–218
  upper memory block INCUST–218
high-level functions (in DDE access server) PROGREF–437
high-level language API (HLLAPI) messages PRODET–226
HIGHCHR keyword, FORM47X2 vector INCUST–332
HIGHDFLT keyword, DISPLATT vector INCUST–314
highlighting, in this book PRODET–viii, PROGREF–xxvi
HIGHPROT keyword, DISPLATT vector INCUST–313
HIGHUNPR keyword, DISPLATT vector INCUST–313
HISPEED keyword, FORM4748 vector INCUST–344
history files, APPLYFIX INCUST–253
HLLAPI messages PRODET–226
HLLAPI, LANDP SERSYS–43
host access SERSYS–31
host access to workstation SERSYS–47
host communication support
  DOS INTPLA–78
  file transfer software INTPLA–86
  files, sending and receiving INTPLA–53
  OS/2 INTPLA–81
  receiving INTPLA–53
  sending INTPLA–53
host computer, events from PROGREF–6
host data stream errors SERSYS–38
host files
  receiving SERSYS–200
  sending SERSYS–200

host printing support INTPLA–29, SERSYS–44
host program error, alert PRODET–236
host resource tracking INTPLA–41, SERSYS–47
host/workstation data conversion SERSYS–47
host
  communication definitions INCUST–531
  internet addresses INCUST–527
  LANDP 3270 emulator INTPLA–29
hot key
  3270 SERSYS–33
hot-key simulation (EE) supervisor local function PROGREF–10
hotkeys
  3270 emulator INCUST–306
  3287 printer emulator INCUST–308
  operator interface INCUST–305
  scan codes INCUST–305
  system manager operator INCUST–305
  trace tool INCUST–305
HP (change printer to remote mode) function in local resource manager PROGREF–548
HP print mode SERSYS–44
HRZOFFS keyword
  FORM4720 vector INCUST–325
  FORM4748 vector INCUST–344
  FORM4770 vector INCUST–349
  FORM47X2 vector INCUST–332

I

I/O books INCUST–585, INTPLA–151, PRODET–297, PROGDE–225, PROGREF–705, SERSYS–277
I/O device servers INTPLA–13, SERSYS–67
I/O devices supported
  DOS INTPLA–89
  Linux INTPLA–98
  OS/2 INTPLA–94
  Windows INTPLA–96
I/O devices, events from PROGREF–6
I/O error subcodes
  VARDAT PRODET–118
I/O structure blocks (ODBC query server) PROGREF–357
I/O structure blocks (query server) PROGREF–306
IBM 4717 Magnetic Stripe Reader/Encoder
  return codes PRODET–163
IBM 4717 Magnetic Stripe Reader
  return codes PRODET–163
IBM 4718 PIN Key Pad
  return codes PRODET–177
IBM 4748 printer server
  return codes PRODET–145
IBM 4770 printer server
  return codes PRODET–148
IBM 4777 Magnetic Stripe Reader/Encoder
  return codes PRODET–163
IBM 4777 Magnetic Stripe Reader
  return codes PRODET–163
IBM 4778 PIN Pad Magnetic Stripe Reader
  return codes PRODET–177
IBM Java Development Kit
  for Linux INTPLA–85
IBM support, requesting PRODET–53
IC (initiate conversation) function in DDE access server PROGREF–445
ID (insert data) function in DDE access server PROGREF–438
ID
  local session INTPLA–22, SERSYS–18
  session INTPLA–23, SERSYS–18
identification, user (in system manager server) PROGREF–462
IEEE 802.2 session INTPLA–88
II (inquire information) supervisor local function PROGREF–14
II (inquire information) supervisor local function
  used in sample application PROGDE–153
IL (inquire logical) function in electronic journal server PROGREF–395
import libraries PROGDE–14
IMS INCUST–540
IMS/MVS SERSYS–130
IMS/VS SERSYS–130
IN (initialize) supervisor local function PROGREF–16
IN (initialize) supervisor local function
  used in sample application PROGDE–153, PROGDE–163
IN (server recognition) PROGDE–60
inactive queues SERSYS–192
include files
  needed by LANDP applications PROGDE–14
  OS/2 PROGDE–17
  Windows NT PROGDE–18
INCLUDE statement INCUST–29
including the CPRB and options control block structures PROGDE–9
IND$FILE command 3270 HLLAPI PROGREF–655
IND$FILE transfer program SERSYS–213, SERSYS–215
indexed access method (in shared-file server) PROGREF–255
indexed access, shared-file SERSYS–78
indexed sequential access SERSYS–79
indexed sequential access method (in shared-file server) PROGREF–255
INET host addresses INCUST–527
information about IBM products INCUST–583, INTPLA–149, PRODET–295, PROGDE–223, PROGREF–703, SERSYS–275
information about query (DQ) function in ODBC query server. PROGREF–369
information about query (DQ) function in query server PROGREF–320
information area (3270 emulator) PRODET–257
information display system terminal INTPLA–29, SERSYS–31
information inquiry (II) supervisor local function PROGREF–14
information of system status (SI) supervisor local function PROGREF–18
information required by IBM PRODET–54
information required when reporting problems PRODET–54
information sources, public INTPLA–19, SERSYS–7
information, LANDP PRODET–viii
information, server (ZI) function in SNA server PROGREF–66
informative code INCUST–56
initial chaining value (IV) function in PIN pad server PROGREF–241
initialize (IN) supervisor local function PROGREF–16
initialize (IN) supervisor local function
  used in sample application PROGDE–153, PROGDE–163
INITIATE CLIST command SERSYS–56
initiate conversation (IC) function in DDE access server PROGREF–445
initiate session (IS) function in local resource manager PROGREF–536
initiate store (SI) function in store-for-forwarding server PROGREF–417
INITPOS keyword INCUST–344
ink jet transaction printer server SERSYS–73
inner node SERSYS–105
input data formats MSR/E server PROGREF–216
input queue (batch machine operator) SERSYS–197
input queue, list (LI) function in object postbox server PROGREF–580
inquire information (II) supervisor local function PROGREF–14
inquire logical (IL) function in electronic journal server PROGREF–395
inquire physical (IP) function in electronic journal serve PROGREF–396
inquire status (IS) function in store-for-forwarding server PROGREF–413
insert data (ID) function in DDE access server PROGREF–438
insert row (IR) function in ODBC query server. PROGREF–373
insert row (IR) function in query server PROGREF–323
installation INCUST–10
installation path, run-time verification INCUST–228
installation requirements, TRDLC server INCUST–193
installation
  onto Windows workstations INCUST–10
  OS/2 INCUST–10
  planning INCUST–7
  software migration INCUST–8
installing PRODET–xi

installing
4748 printer server INCUST–13, INCUST–14, INCUST–17
banking products INCUST–20
BIWP INCUST–20
device drivers INCUST–11
device drivers (DOS) INCUST–16
device drivers (Linux) INCUST–15
device drivers (Windows) INCUST–13
DOS workstations INCUST–189
FBSS family INCUST–20
financial printer server INCUST–12, INCUST–14, INCUST–15, INCUST–17
installation path, run-time verification INCUST–228
installing LANDP INCUST–7
LAN support program INCUST–18
LDA7 INCUST–21
Linux workstations INCUST–163
magnetic stripe reader/encoder server INCUST–12, INCUST–14, INCUST–15, INCUST–16
NetBIOS support INCUST–18
OS/2 workstations INCUST–87
PC Integrator/2 INCUST–8
PC/Integrator INCUST–8
PIN pad server INCUST–12, INCUST–14, INCUST–15, INCUST–16
program fixes INCUST–251
remote installation INCUST–7
run-time files (DOS) INCUST–218
run-time files (Linux) INCUST–188
run-time files (OS/2) INCUST–126
run-time files (Windows) INCUST–161
sample INCUST–278
system files INCUST–229
updated configuration files INCUST–228
user servers INCUST–20
Windows workstations INCUST–127
X.25 DLC INCUST–19
INT X'7F' API SERSYS–226
integration servers SERSYS–189
Interface Co-processor/2 SERSYS–10
interface
printer server SERSYS–69
internal and communication traces, EHCLIP program PRODET–49
internal communication
LANDP for DOS INTPLA–78
LANDP for OS/2 INTPLA–81
internal communications
LANDP for Windows INTPLA–83
internal repository, removing data INCUST–38, INCUST–236
interrupt handling PROGDE–70
interrupts INTPLA–89, INTPLA–93
intervention by operator, end (EI) function in local resource manager PROGREF–531
introduction to LANDP INTPLA–3
introduction, diagnostic tools PRODET–3
invoking the common API PROGDE–31
IP (inquire physical) function in electronic journal server PROGREF–396
IPTXFER.MSG message file SERSYS–211
IR (insert row) function in ODBC query server. PROGREF–373
IR (insert row) function in query server PROGREF–323
IS (initiate session) function in local resource manager PROGREF–536
IS (inquire status) function in store-for-forwarding server PROGREF–413
IV (load initial chaining value) function in PIN pad server PROGREF–241

J

J/XFS device support PROGDE–84
Java 'server'
file distribution definitions INCUST–445
Java compilers INTPLA–81
Java manager INTPLA–52
Java Manager
J/XFS printer classes, distribution of INCUST–445
MSR/E classes, distribution of INCUST–445
number of dispatcher processes INCUST–445
PINpad classes, distribution of INCUST–446
startup statement INCUST–445
Java Virtual Machine INCUST–9
Java websites and redbooks INCUST–587, INTPLA–153, PRODET–299, PROGDE–227, PROGREF–707, SERSYS–279
Java, LANDP support PROGDE–83, PROGDE–91
Java, LANDP support
client development PROGDE–86
exception handling PROGDE–89
installation requirements
Linux INCUST–164
OS/2 INCUST–98
Windows INCUST–135
LANDP Version 4 classes supported PROGDE–85
multiple client in a JVM PROGDE–87
using PROGDE–83
VisualAge for Java PROGDE–85
writing applets to access LANDP PROGDE–90
writing LANDP servers PROGDE–90
writing servlets PROGDE–89
JOURADV keyword, FORM4720 vector INCUST–325
journal server INTPLA–35, SERSYS–118

K

KBD3270 vector INCUST–357
KBD3270 vector
example INCUST–361
quick reference INCUST–360
KBD3270X vector INCUST–358, INCUST–362
KBD3270X vector
example INCUST–364
KBD3270X vector *(continued)*
quick reference INCUST–363
KBDBIWP vector INCUST–364
KBDBIWP vector
example INCUST–368
quick reference INCUST–366
KD (peek data) function in DDE access server PROGREF–446
key add (X'0050') in cryptographic interface PROGREF–83
key assignment set, 3270 SERSYS–32
KEY keyword
KBD3270 vector INCUST–360
KBD3270X vector INCUST–363
KBDBIWP vector INCUST–366
KSCCBIWP vector INCUST–369
KSTRBIWP vector INCUST–371
key load (LK) function in PIN pad server PROGREF–242
key record delete (X'0052') in cryptographic interface PROGREF–84
key records in cryptographic interface PROGREF–78
key update (X'0051') in cryptographic interface PROGREF–84
KEY0-9 keywords, PINPTBL vector INCUST–378
KEY01-15 keywords, SHFLDBD vector INCUST–393
KEY02-15 keywords
EJOUPRF vector INCUST–317
SFORWPRF vector INCUST–388
keyboard
events from PROGREF–6
KEYENDP keyword, PINPTBL vector INCUST–380
KEYFIELD keyword, SHFLPCB vector INCUST–396
keys, shared-file SERSYS–79
KEYSCP keyword, PINPTBL vector INCUST–379
KEYSEP keyword, PINPTBL vector INCUST–379
knowledge, prerequisite INCUST–xxiii, PRODET–vii, PROGREF–xxv
Korean Standard (KS) codes SERSYS–72
KS (Korean Standard) codes SERSYS–72
KSCCBIWP vector INCUST–368
KSCCBIWP vector
example INCUST–369
quick reference INCUST–369
KSTRBIWP vector INCUST–370
KSTRBIWP vector
example INCUST–371
quick reference INCUST–370

L

LAN (local area network) PROGDE–1
LAN adapter and protocol support INCUST–87
LAN books INCUST–584, INTPLA–150, PRODET–296, PROGDE–224, PROGREF–704, SERSYS–276
LAN common data SERSYS–152
LAN common data validation INCUST–398

LAN server
loading statement (DOS) INCUST–204
loading statement (OS/2) INCUST–107
loading statement (Windows) INCUST–144
LAN support program INCUST–18
LAN system status and common data SERSYS–163
LAN.EXE INCUST–107, INCUST–144, INCUST–204
LANADAPT keyword, LANCONF vector INCUST–419
LANCONF vector INCUST–417
LANCONF vector
examples INCUST–422
quick reference INCUST–417
LANCONF.SPC INCUST–26, INCUST–39, INCUST–237
LANDP INCUST–87
LANDP application programs
Borland C++programs PROGDE–14
FBSS/2 PROGDE–14
Micro Focus COBOL PROGDE–14
Microsoft Visual C ++ PROGDE–14
OS/2 16-bit PROGDE–14
OS/2 32-bit PROGDE–14
VisualAge C++ PROGDE–14
LANDP customization editing tool INCUST–41
LANDP family INTPLA–3
LANDP family books INCUST–xxiv, INTPLA–xiii, PRODET–ix, PROGDE–xiv, PROGREF–xxviii, SERSYS–xvi
LANDP family
common API INTPLA–3
components INTPLA–3
LANDP for DOS applications in Linux workstations PROGREF–563
LANDP for DOS applications in OS/2 or Windows workstations PROGREF–555
LANDP for DOS programming PROGDE–68
LANDP for DOS Windows 3.1 support PROGDE–47
LANDP for DOS
functions INTPLA–71
I/O devices supported INTPLA–89
software INTPLA–78
trace tools PRODET–9, PRODET–37
LANDP for Linux programming
writing servers PROGDE–71
LANDP for Linux
compiling and link-editing programs PROGDE–20
DBCS support INTPLA–117
developing applications PROGDE–20
functions INTPLA–71
I/O devices supported INTPLA–98
multithreaded applications PROGDE–21
preventing possible loading problems INCUST–175
programming environments PROGDE–19
shared object file PROGDE–19
LANDP for Linux *(continued)*
software INTPLA–85
trace tools PRODET–39
LANDP for OS/2 programming PROGDE–15, PROGDE–18
LANDP for OS/2 programming
REXX PROGDE–103
REXX application programming interface (OS/2) PROGDE–105
writing servers PROGDE–71
LANDP for OS/2 workstations, preparing INCUST–87
LANDP for OS/2
functions INTPLA–71
I/O devices supported INTPLA–94
software INTPLA–81
trace tools PRODET–39
LANDP for Windows programming
writing servers PROGDE–71
LANDP for Windows
functions INTPLA–71
I/O devices supported INTPLA–96
preventing possible loading problems INCUST–138
software INTPLA–83
trace tools PRODET–39
LANDP global return codes PRODET–150
LANDP installation INCUST–10
LANDP Internet Protocol
return codes PRODET–155
LANDP link server INTPLA–10
LANDP link server
ehclink INCUST–180
EHCLINK.EXE INCUST–108, INCUST–145
LANDP for Linux INCUST–164
LANDP for OS/2 INCUST–96
LANDP for Windows INCUST–133
loading statement (Linux) INCUST–180
loading statement (OS/2) INCUST–108
loading statement (Windows) INCUST–145
return codes PRODET–158
LANDP return codes PRODET–123
LANDP servers
help facility INCUST–53
information INCUST–53
list of vectors/keywords INCUST–44
requirements INCUST–51
return codes PRODET–125
LANDP workgroup PROGDE–1
LANDP
3270 emulator SERSYS–31
3287 emulator INTPLA–29, SERSYS–44
alerts PRODET–231
configurations INTPLA–65
conversation INTPLA–26, SERSYS–24
DOS workstations INCUST–189
EHCWINNT.DLL INCUST–138
emulator support INTPLA–29, SERSYS–31
functional areas, vectors/keywords INCUST–44
high-level language API SERSYS–43
LANDP *(continued)*
LANDP.HST history file, program fixes INCUST–253
libehclnx.so INCUST–175
Linux workstations INCUST–163
preventing possible loading problems INCUST–138, INCUST–175
session INTPLA–23, SERSYS–18
TOTS.HST history file, program fixes INCUST–253
vectors/keywords, functional areas INCUST–44
Windows workstations INCUST–127, INCUST–161
workgroup INTPLA–5
workgroup suffix, LANDP session INCUST–227
LandpRequest class PROGDE–75, PROGDE–80
LandpServer class PROGDE–78
language interface module (LIM) in 3270 emulator PROGREF–616, PROGREF–654
LANGUAGE keyword
LANCONF vector INCUST–419
SMGRUSER vector INCUST–403
LANID keyword, SMGRPRF vector INCUST–399
LANLIMIT.SPC INCUST–55, INCUST–62, INCUST–77, INCUST–231
LANMODEL vector INCUST–522
LANMODEL vector
example INCUST–523
quick reference INCUST–522
LAPS INCUST–87
laser printer support INCUST–156, PROGREF–163
layers, communication INTPLA–20, SERSYS–8
LD (load user-defined character) function in 4748 printer server PROGREF–169, PROGREF–182
LDA7 INCUST–21
leaf node SERSYS–105
leased connections INTPLA–88, SERSYS–9
LENGTH keyword, RECFIELD vector INCUST–385
LEVELA keyword, SMGRUSER vector INCUST–404
LEVELF keyword
SMGRPRF vector INCUST–401
SMGRUSER vector INCUST–404
LEVELM keyword
SMGRPRF vector INCUST–401
SMGRUSER vector INCUST–404
LEVELO keyword, SMGRUSER vector INCUST–404
LEVELOA keyword, SMGRPRF vector INCUST–401
LEVELR keyword
SMGRPRF vector INCUST–401
SMGRUSER vector INCUST–404
LEVELS keyword
SMGRPRF vector INCUST–400
SMGRUSER vector INCUST–403
LGD files PRODET–40

LI (list input queue) function in object postbox server PROGREF–580
libehclnx shared object file (LANDP for Linux) PROGDE–31
libehclnx.so, loading INCUST–16
libehclnx.so
  loading INCUST–175
libraries, maintaining SERSYS–47
library maintenance INTPLA–41
library, books in LANDP PRODET–viii
LIM, expanded memory specification INCUST–215
line speed INTPLA–88, SERSYS–9
line speed, SDLC INTPLA–88
LINELEN keyword
  FORM4710 vector INCUST–320
  FORM4720 vector INCUST–325
  FORM4748 vector INCUST–344
  FORM4770 vector INCUST–349
  FORM47X2 vector INCUST–333
link libraries PROGDE–14
link routines PROGDE–5
link server SERSYS–3
link server
  definitions INCUST–446
link-editing application programs PROGDE–14
linking LANDP workgroups INTPLA–10
linking LANDP workgroups
  LANDP link server SERSYS–3
Linux Dosbox support INTPLA–54
Linux DosBox support PROGREF–563
Linux system log PRODET–56
Linux workstations INCUST–163
Linux, use of native system functions PROGDE–2
Linux
  installation path INCUST–188
  installing run-time files INCUST–188
  operating system levels INTPLA–85
  path, installation INCUST–188
  semaphore-handling PROGREF–5
  supported distributions PROGREF–xxviii
  workstation installation requirements INCUST–163
LIP (LANDP Internet Protocol) INCUST–527
LIP (LANDP Internet Protocol)
  address checking INCUST–422
LIP programs
  EHCLIP PRODET–49
  EHCLIP, LANDP for DOS PRODET–35
  error codes, LANDP for DOS PRODET–36
  statistics codes, LANDP for DOS PRODET–36
  TCP/IP tools, using with PRODET–36
LIP
  address checking INCUST–428
  availability probe datagrams INCUST–421, INCUST–427
  expanded memory selection INCUST–428
  loading statement (DOS) INCUST–205
LIP *(continued)*
  loading statement (Linux) INCUST–179
  loading statement (OS/2) INCUST–108
  loading statement (Windows) INCUST–145
  retransmission table, space INCUST–422, INCUST–428
  space for retransmission table INCUST–422, INCUST–428
list input queue (LI) function in object postbox server PROGREF–580
list of files (batch machine operator) SERSYS–196
list of users holding locks, retrieve (RK) function in system manager server PROGREF–468
list output queue (LO) function in object postbox server PROGREF–581
listing
  configurations, workgroup INCUST–239
  customization data INCUST–239
  data, customization INCUST–239
  internal repository INCUST–239
  repository, internal INCUST–239
  servers INCUST–239
  services INCUST–239
  workgroup configurations INCUST–239
LISTRTOC INCUST–239
LK (load key) function in PIN pad server PROGREF–242
LM (load master key) function in PIN pad server PROGREF–243
LO (list output queue) function in object postbox server PROGREF–581
LO (lock topic) function in DDE access server PROGREF–439
load initial chaining value (IV) function in PIN pad server PROGREF–241
load key (LK) function in PIN pad server PROGREF–242
load master key (LM) function in PIN pad server PROGREF–243
load PIN verification parameters (LP) function PROGREF–244
load program (LP) function in DDE access server PROGREF–439
load server inline utility INCUST–124
load servers inline utility SERSYS–226
load user-defined character (LD) function in 4748 printer server PROGREF–169, PROGREF–182
LOADER (DOS) INCUST–203
loader (Linux) INCUST–178
LOADER (OS/2) INCUST–104
LOADER (Windows) INCUST–141
LOADER program and trace tools PRODET–4
LOADERE (DOS) INCUST–203, INCUST–215
loading error return subcodes
  NEWCFG PRODET–117
  VARPARM PRODET–116
loading parameter, LIP INCUST–527
loading return codes PRODET–82
loading statements (DOS) PRODET–xi
loading statements (DOS)
  3270 emulator INCUST–212
  3287 printer emulator INCUST–214
  4748 printer server INCUST–214
  ASCII-EBCDIC translation server INCUST–204
  compression server INCUST–204
  DDT.EXE INCUST–212
  electronic journal server INCUST–204
  expanded memory INCUST–203
  financial printer server INCUST–214
  forwarding server INCUST–204
  LAN server INCUST–204
  LANDP for DOS servers INCUST–203
  LANDP internet protocol INCUST–205
  LOADER INCUST–203
  LOADERE INCUST–203
  local resource manager server INCUST–206
  magnetic stripe reader/encoder server INCUST–206
  native X.25 server INCUST–206
  operator interface INCUST–206
  PIN pad server INCUST–206
  printer manager server INCUST–206
  remote change management services INCUST–206
  searcher INCUST–207
  shared DOS directory server INCUST–208
  shared-file server INCUST–208
  SNA server INCUST–209
  store-for-forwarding server INCUST–209
  supervisor INCUST–209
  synchronous data link control server INCUST–210
  system manager operator INCUST–211
  system manager server INCUST–211
  TCP/IP wide area communications server INCUST–211
  token-ring data link control server INCUST–211
  Windows 3.1/3.11 support INCUST–195
  X.25 data link control server (X25DLC) INCUST–212
  X.25DLC2.EXE INCUST–212
loading statements (Linux)
  electronic journal server INCUST–178
  financial printer server INCUST–186
  LANDP for Linux servers INCUST–178
  LANDP Internet Protocol INCUST–179
  magnetic stripe reader/encoder server INCUST–181
  PIN pad server INCUST–181
  service availability manager INCUST–181
  shared-file server INCUST–182
  store-for-forwarding server INCUST–184

loading statements (Linux) *(continued)*
supervisor INCUST–184
trace tools INCUST–185
virtual DOS machine relay INCUST–186
loading statements (OS/2 VDM)
3270 emulator INCUST–122
3287 printer emulator INCUST–123
AUTOFBSS.BAT INCUST–121
banking interactive workstation program INCUST–121
emulators INCUST–121
LSI INCUST–121
loading statements (OS/2) PRODET–xi
loading statements (OS/2)
4748 and 9068-D01 printer server INCUST–120
4770 printer server INCUST–120
batch machine operator INCUST–106
batch machine server loader INCUST–105
CICS interface server INCUST–106
DDE access server INCUST–106
DETACH command INCUST–104
electronic journal server INCUST–106
financial printer server INCUST–120
forwarding server INCUST–106
LAN server INCUST–107
LANDP for OS/2 servers INCUST–104
LANDP Internet Protocol INCUST–108
LANDP link server INCUST–108
LOADER INCUST–104
magnetic stripe reader/encoder server INCUST–109
native X.25 server INCUST–110
object post box server INCUST–111
PIN pad server INCUST–111
program-to-program communication server INCUST–111
query server INCUST–111
remote change management services INCUST–112
searcher INCUST–113
service availability manager INCUST–113
shared-file distributor INCUST–114
shared-file replicator INCUST–114
shared-file server INCUST–114
SNA server INCUST–117
START command INCUST–104
store-for-forwarding server INCUST–117
supervisor INCUST–118
system manager operator INCUST–118
system manager server INCUST–118
timeout INCUST–104
trace tools INCUST–119
virtual DOS machine relay INCUST–120
loading statements (Windows 3.1/3.11) INCUST–195
loading statements (Windows VDM)
banking interactive workstation program INCUST–157
loading statements (Windows VDM) *(continued)*
banking printer program INCUST–158
emulators INCUST–157
loading statements (Windows)
4748 printer server INCUST–157
DETACH INCUST–141
electronic journal server INCUST–143
financial printer server INCUST–156
forwarding server INCUST–143
LAN server INCUST–144
LANDP for Windows servers INCUST–141
LANDP Internet Protocol INCUST–145
LOADER INCUST–141
magnetic stripe reader/encoder server INCUST–146
PIN pad server INCUST–148
program-to-program communication server INCUST–149
searcher INCUST–150
service availability manager INCUST–150
shared-file server INCUST–151
SNA server INCUST–153
store-for-forwarding server INCUST–153
supervisor INCUST–153
system manager server INCUST–154
timeout INCUST–142
trace tools INCUST–154
virtual DOS machine relay INCUST–155
loading statements for Windows
remote change management services INCUST–149
local administrative address INCUST–224
local area network (LAN) PROGDE–1
local mode, change printer to (LP) function in local resource manager PROGREF–549
Local resource management server
return codes PRODET–160
local resource manager server INTPLA–41, SERSYS–186
local resource manager server
loading statement (DOS) INCUST–206
local servers PROGDE–5
local session ID INTPLA–23, SERSYS–18
local sessions, maximum SERSYS–19
location of workstation INCUST–7
lock management SERSYS–78
lock topic (LO) function in DDE access server PROGREF–439
locking DDE topics SERSYS–190
log entries, LANDP for OS/2 error PRODET–41
log file SERSYS–80
log file contents
MQSeries Link Server PRODET–51
log file naming
MQSeries Link Server PRODET–51
log file, shared-file server SERSYS–81
log file
query server SERSYS–110
log files, XLR SERSYS–90
log management INTPLA–39, SERSYS–140
LOGFSIZE keyword, SMGRPRF vector INCUST–400
logging errors, LANDP for Linux PRODET–40
logging errors, LANDP for OS/2 PRODET–40
logging errors, LANDP for Windows PRODET–40
logical channel identification, X.25 INCUST–493
logical device address 7 program PRODET–xi
logical device address 7 program
configuration definitions INCUST–448
emulated session number, BIWP INCUST–448
SERVER keyword, LWSCONF vector INCUST–430, INCUST–526
SNA LU number INCUST–448
SNA LU pool ID INCUST–448
SNA pool ID INCUST–448
logical unit (LU) INCUST–371
logical unit of work INTPLA–48, SERSYS–190
logical unit pooling SERSYS–21
LOGRECL keyword, SMGRPRF vector INCUST–400
LOGSUPP keyword, SMGRPRF vector INCUST–399
Lotus/Intel/Microsoft expanded memory specification INCUST–215
low-level communication protocol INCUST–527
low-level functions (in DDE access server) PROGREF–442
low-level INT X'7F' API SERSYS–226
LP (change printer to local mode) function in local resource manager PROGREF–549
LP (load PIN verification parameters) function in PIN pad server PROGREF–244
LP (load program) function in DDE access server PROGREF–439
LPI keyword
FORM4720 vector INCUST–325
FORM4748 vector INCUST–344
FORM47X2 vector INCUST–334
LSI SERSYS–226
LSI
BIWP INCUST–121, INCUST–124, INCUST–157
BPP INCUST–158
OS/2 VDM INCUST–121
Windows VDM INCUST–157
LSTDELIM keyword, P3287ATT vector INCUST–377
LU pool INCUST–90, INCUST–130
LU pooling SERSYS–21
LU pooling support INCUST–514
LU pooling support
Windows installation requirements INCUST–130
LU priority, change (CP) function in local resource manager PROGREF–529

LU_0 applications INTPLA–69
LU_1 3287 applications INTPLA–69
LU_1 session SERSYS–45
LU_2 3270 applications INTPLA–69
LU_2 session SERSYS–31
LU_6.2 applications INTPLA–69
LU–LU session (SNA server) PROGREF–42
LU
  LU pooling support
    OS/2 installation requirements INCUST–90
    PAR&4731 keyword INCUST–510, INCUST–511
    PAR&4737 keyword INCUST–512
    PAR&BIWP keyword INCUST–435
    PAR&LDA7 keyword INCUST–448
    PAR&PT21 keyword INCUST–508, INCUST–509
    PAR&RCMS keyword INCUST–459
    PAR&SNA keyword INCUST–470
    PAR&VFIL keyword INCUST–488
    PAR&VVOL keyword INCUST–490
    SES&3270 keyword INCUST–497
    SES&3287 keyword INCUST–500
    SES&BPP keyword INCUST–439
    SES&FORW keyword INCUST–444
  LU_0, CICS INCUST–537
  LU_0, IMS/VS INCUST–540
  LU_1, CICS INCUST–538
  LU_1, IMS/VS INCUST–540
  LU_2, CICS INCUST–539
  LU_2, IMS/VS INCUST–540
LUA INTPLA–21, SERSYS–14, SERSYS–16
LUA interface INCUST–89, INCUST–129
LUA interface
  correlation tables INCUST–93, INCUST–133
  profiles INCUST–90, INCUST–130
LUNUMBER keyword, LUPOOL vector INCUST–372
LUPOOL vector INCUST–371
LUPOOL vector
  example INCUST–372
  LUPOOL table INCUST–372
  quick reference INCUST–371
LWSCONF vector INCUST–423
LWSCONF vector
  examples INCUST–434
  quick reference INCUST–423

M

MAC (message authentication code) in PIN pad server PROGREF–240
magnetic stripe reader/encoder server INCUST–14, INCUST–15, SERSYS–75
Magnetic stripe reader/encoder server
  return codes PRODET–163
mail program SERSYS–192
MAIL program INTPLA–51, PROGREF–588, SERSYS–192
MAIL program messages PRODET–228
maintaining data, application PROGREF–474
maintaining
  application libraries INTPLA–41, SERSYS–47
  workgroup data INTPLA–39, SERSYS–140
maintenance level (Linux), checking INCUST–249, PRODET–61
maintenance level, checking INCUST–247, PRODET–59
maintenance strategy, example PRODET–64
making LANDP operational INTPLA–17
managing
  alerts INTPLA–39, SERSYS–140
  logs INTPLA–39, SERSYS–140
  server data INTPLA–40, SERSYS–146
  user identification INTPLA–39, SERSYS–140
  user profile INTPLA–39, SERSYS–140
manually dialed connections INTPLA–88, SERSYS–9
manuals, LANDP PRODET–viii
MASM programs PROGDE–9
master key load (LM) function in PIN pad server PROGREF–243
MAXACC keyword
  EJOUPRF vector INCUST–316
  SFORWPRF vector INCUST–387
maximum datagram length INCUST–530
maximum number of clients per server INTPLA–99
maximum SDLC speed INTPLA–88, SERSYS–9
MAXNUML keyword, EJOUPRF vector INCUST–315
MAXSKEW keyword
  FORM4720 vector INCUST–325
  FORM4748 vector INCUST–344
  FORM47X2 vector INCUST–334
mechanism, client/server INTPLA–7
memory blocks, using upper INTPLA–80
memory management considerations (LANDP for DOS) PROGDE–68
memory status setting, LANDP for Linux trace tool PRODET–41
memory status setting, LANDP for OS/2 trace tool PRODET–41
memory status setting, LANDP for Windows trace tool PRODET–41
memory, expanded INTPLA–79
memory
  expanded INCUST–215
  high INCUST–218
message tables (in system manager server) PROGREF–507
message
  translation INTPLA–22
messages for the operator SERSYS–175
messages to NetView operators PRODET–7
messages, LANDP family PRODET–221, PRODET–231
messages, LANDP family
  description of PRODET–7
messages
  external logging replicator (XLR) SERSYS–89
messages *(continued)*
  operator INTPLA–41
  support INTPLA–39, SERSYS–140
  translation SERSYS–18
MICR reader, 9069 printer PROGREF–141
MICR reader, 9069 printer
  financial printer server flag PROGREF–145
  read data (RD) function PROGREF–160
  reply DATA values PROGREF–161
Micro Focus COBOL INTPLA–78
Micro Focus COBOL programs
  compiling and linking PROGDE–14
Microsoft C Version INTPLA–78
Microsoft Host Integration Server SERSYS–15
Microsoft Host Integration Server 2000 INTPLA–21
Microsoft SNA Server INTPLA–21, SERSYS–15
Microsoft Visual Basic, installing requirements LANDP for Windows INCUST–134
Microsoft Visual C ++ programs
  compiling and linking PROGDE–14
Microsoft Visual C++ INTPLA–83
Microsoft Windows 3.1 support SERSYS–227
Microsoft Windows 3.1/3.11, unloading LANDP for DOS INCUST–215
Microsoft Windows Terminal Server
  distributing LANDP files INCUST–547
  introduction INCUST–547
Microsoft Windows
  software INTPLA–79
  supported releases PROGREF–xxvii
migration INTPLA–15, SERSYS–237
migration
  command INCUST–234
  customization data INCUST–231, INCUST–232
  data INCUST–231, INCUST–232
  data, source INCUST–233
  LANLIMIT.SPC INCUST–231
  MIGRATE INCUST–234
  procedure INCUST–234
  query server from FBSS/2 to LANDP for OS/2 SERSYS–237
  shared-file server to LANDP for OS/2 query server SERSYS–238
  source data INCUST–233
  vectors INCUST–231, INCUST–232
millennium INTPLA–16
MINLOCKS keyword INCUST–394
mixed 32-bit programs PROGDE–16
mixed transport protocols
  installation requirements (OS/2) INCUST–89
  installation requirements (Windows) INCUST–129
MO (send message to NetView operator) function in system manager server PROGREF–502
MODEENT macro in VTAM logon mode table SERSYS–215

MODEENT
LU_0 INCUST–535
LU_1 INCUST–535
LU_2 INCUST–535
LU_6.2 INCUST–536
RCMS INCUST–536
model concept INCUST–26
model configuration data INCUST–26
model configuration data
editing INCUST–521
embedded files INCUST–29
INCLUDE statement INCUST–29
partial files INCUST–30
vector editing INCUST–521
MODEL keyword
LANCONF vector INCUST–418
LWSCONF vector INCUST–424
MODELS.SPC INCUST–26
MODELS.SPC
embedded files INCUST–29
INCLUDE statement INCUST–29
partial files INCUST–30
modifying files
DOS INCUST–194
EHCADD INCUST–73
EHCAPPEN INCUST–74
Linux INCUST–176
OS/2 INCUST–99
Windows INCUST–139
MODNAME keyword
LANMODEL vector INCUST–523
SVRMODEL vector INCUST–525
WSMODEL vector INCUST–525
monitored communication SERSYS–47
mono-service servers PROGDE–11
monochrome display support, 4707 INTPLA–54, SERSYS–224
mouse events PROGREF–6
mouse events under LANDP for OS/2 and LANDP for Windows PROGDE–44
moving services INTPLA–15
moving services to LANDP for OS/2 PROGDE–23
moving services to LANDP for Windows PROGDE–23
MQSeries Link server INTPLA–28, PROGREF–137, SERSYS–27
MQSeries Link server
begin transaction (BT) PROGREF–123
checkpoint (CP) PROGREF–124
close queue (CQ) PROGREF–125
close session (CS) PROGREF–124
definitions INCUST–450
end transaction (ET) PROGREF–126
integration With MQSeries PROGREF–122
LANDP for OS/2 INCUST–96
LANDP for Windows INCUST–133
loading statement (OS/2) INCUST–109
loading statement (Windows) INCUST–147
MQGET (GQ function) PROGREF–127
MQPUT (PQ function) PROGREF–131
MQPUT1 (PQ1 function) PROGREF–134
MQSeries Link server *(continued)*
PAR&MQ keyword, LWSCONF vector INCUST–450
rollback (RB function) PROGREF–135
using PROGREF–120
MQSeries Link Server
log file contents PRODET–51
log file naming PRODET–51
logging PRODET–51
return codes PRODET–166
MSGOPRCV keyword, SMGRPRF vector INCUST–401
MSR device, arm (AT) function in PIN pad server PROGREF–234
MSR/E (magnetic stripe reader/encoder) server
alerts PRODET–237
MSR/E and PINPad sharing, 4700 and local applications INCUST–121
MSR/E server PRODET–xi, SERSYS–75
MSR/E server
COM port INCUST–452
configuration definitions INCUST–451
DEVICE statement (DOS) INCUST–198
DEVICE statement (OS/2) INCUST–100
input translation table INCUST–372
Linux installation INCUST–15
loading statement (DOS) INCUST–206
loading statement (Linux) INCUST–181
loading statement (OS/2) INCUST–109
loading statement (Windows) INCUST–146
MSR/E device INCUST–451
MSRE47##.EXE INCUST–109
MSRINTBL vector INCUST–372
MSROUTBL vector INCUST–374
OS/2 installation INCUST–12
output translation table INCUST–374
read response delay INCUST–373
return codes PRODET–163
Windows installation INCUST–14
MSR1, hardware error
alerts PRODET–237
MSR2 alert, device not connected
alerts PRODET–238
MSRE47## (MSR/E server) PROGREF–205
MSRE47##.EXE INCUST–109, INCUST–146, INCUST–181, INCUST–206
MSRINTBL vector INCUST–372
MSRINTBL vector
example INCUST–374
quick reference INCUST–372
MSROUTBL vector INCUST–374
MSROUTBL vector
example INCUST–376
quick reference INCUST–375
Multi-Protocol Adapter INTPLA–89
Multi-Protocol Adapter/A INTPLA–89
multiple copies of database SERSYS–107
multiple events PROGDE–41
multiple threads
LANDP for Linux PROGDE–71
LANDP for OS/2 PROGDE–71
LANDP for Windows PROGDE–71
multiple-service servers PROGDE–11
multipoint line INTPLA–88, SERSYS–9
multitasking programs SERSYS–227
MVDM relay PROGREF–555
MVDM
DOS applications running under OS/2 or Windows INTPLA–14

N

NAME keyword
COLSQTBL vector INCUST–302
DEFAULTS vector INCUST–305
EJOUPRF vector INCUST–315
FORM4710 vector INCUST–320
FORM4720 vector INCUST–323
FORM4748 vector INCUST–341
FORM4770 vector INCUST–349
FORM47X2 vector INCUST–331
FORWPRF vector INCUST–354
LANCONF vector INCUST–418
LUPOOL vector INCUST–372
LWSCONF vector INCUST–424
RCMSLNF vector INCUST–381
RECDEF vector INCUST–383
RECFIELD vector INCUST–384
SFORWPRF vector INCUST–387
SMGRPRF vector INCUST–399
SMGRUSER vector INCUST–403
name, workstation INCUST–527
names of system resources PROGDE–11
naming convention, program fix files INCUST–251
naming conventions, DDE SERSYS–190
national language codepages
DOS INCUST–189
Linux INCUST–164
OS/2 INCUST–87
Windows INCUST–127
National Language Support for printers
OS/2 SERSYS–70
Windows SERSYS–71
native X.25 communication SERSYS–7
native X.25 communication
trace, LANDP for DOS PRODET–23
native X.25 server SERSYS–23
native X.25 server
communications server (OS/2) INCUST–94
configuration definitions INCUST–452
connection type INCUST–453
country identification INCUST–453
country subcode INCUST–453
destination ID INCUST–453
facility code INCUST–454
installation requirements (OS/2) INCUST–94
loading statement (DOS) INCUST–206
loading statement (OS/2) INCUST–110
session ID INCUST–453
subscriber address INCUST–453
subscriber number INCUST–453

native X.25 server *(continued)*
telephone number INCUST–452
workstation installation requirements (OS/2) INCUST–94
Native X.25 server
clear packets PRODET–171
reset packets PRODET–171
Native X.25 Server
return codes PRODET–169
native X.25
communication INTPLA–20
server INTPLA–25
NETBEUI.OS2, NetBIOS protocol driver INCUST–88
NetBIOS internal communication
LANDP for DOS INTPLA–78
LANDP for OS/2 INTPLA–81
LANDP for Windows INTPLA–83
NetBIOS, installation requirements INCUST–128
NETBIOS.OS2, NetBIOS device driver INCUST–88
NetBIOS
installation requirements (OS/2) INCUST–87
LAN support program INCUST–18
Linux workstation INCUST–163
OS/2 workstation INCUST–87
resources (DOS) INCUST–190
Windows workstation INCUST–127
NETBIOS
NETBEUI.OS2, NetBIOS protocol driver INCUST–88
NETBIOS.OS2, NetBIOS device driver INCUST–88
NETBUFF keyword
LANCONF vector INCUST–420
LWSCONF vector INCUST–429
NetManage
PC/TCP Network Software INTPLA–79
NetView books INCUST–585, INTPLA–151, PRODET–297, PROGDE–225, PROGREF–705, SERSYS–277
NetView Distribution Manager SERSYS–48
NetView DM SERSYS–48
NetView DM commands SERSYS–55
NetView DM commands
DELETE SERSYS–56
INITIATE CLIST SERSYS–56
REPLACE SERSYS–59
RETRIEVE SERSYS–60
RETRIEVE by CATALOG SERSYS–61
SEND SERSYS–62
SEND MESSAGE SERSYS–63
NetView DM resources, identifying SERSYS–49
NetView operator, send message to (MO) function in system manager server PROGREF–502
NetView program, and alerts PRODET–7
Netview
naming conventions used by RCMSLNF INCUST–381
NetView
distribution manager (DM/2) INCUST–77
response file name (DM/2 restriction) INCUST–80
workstation name INCUST–79
network packet switching interface INTPLA–24
network packet switching interface (NPSI) SERSYS–20
Network SignON Coordinator/2 SERSYS–141
network, TCP/IP INCUST–527
NEWCFG.EXE INCUST–228
NEWCFG
loading error return subcodes PRODET–117
NEWDOC keyword
FORM4720 vector INCUST–326
FORM4748 vector INCUST–345
FORM47X2 vector INCUST–334
NLS SERSYS–87
NLS for printers
OS/2 SERSYS–70
Windows SERSYS–71
NMVT, check (CN) function in system manager server PROGREF–503
node problem management INTPLA–41
node
problem management SERSYS–47
non-4704 read compatibility mode MSR/E server PROGREF–216
non-GUI programs, VisualAge for COBOL for PROGDE–93
non-Windows programs, multitasking SERSYS–227
NORMDFLT keyword, DISPLATT vector INCUST–314
NORMPROT keyword, DISPLATT vector INCUST–313
NORMUNPR keyword, DISPLATT vector INCUST–313
notation conventions PROGDE–xii, SERSYS–xiv
notices, event INTPLA–10
notification INTPLA–10
notification of alerts (AN) function in system manager server PROGREF–499
notification of resolution (UN) function in system manager server PROGREF–503
notification, alert PRODET–7
NPSI INTPLA–24
NPSI (network packet switching interface) SERSYS–20
number of buffers for data link controls INTPLA–22
number of buffers
for data link controls SERSYS–17
for SDLC SERSYS–12
for TRDLC SERSYS–12
for X25DLC SERSYS–12
number of personal account (PAN) PROGREF–232
number of printer port SERSYS–74
number of printers supported INCUST–500
NWSIDDUP keyword, LWSCONF vector INCUST–421

O

OB (open batch) function in shared-file server PROGREF–286
Object Module Format (OMF) PROGDE–18
object post box server SERSYS–191, SERSYS–195
object post box server
configuration definitions INCUST–455
database path INCUST–455
loading statement (OS/2) INCUST–111
Object post box server
return codes PRODET–173
obtain RDBMS information (RI) function in ODBC query server PROGREF–374
obtaining software INCUST–61, INCUST–66
obtaining software
GENRUN INCUST–61
GETGLOB INCUST–61
GETTING.SPC INCUST–61
sample INCUST–282
ODBC query server INTPLA–34, PROGREF–353, PROGREF–379, SERSYS–115
ODBC query server
as an access path to the RDBMS PROGREF–354
CD (change database) function in ODBC query server. PROGREF–360
close query mode (CQ) PROGREF–368
close session (CS) PROGREF–361
commit work (CW) PROGREF–368
configuration definitions
configuration name INCUST–455
maximum number of worker threads INCUST–456
maximum sessions per workstation INCUST–456
number of initial worker threads INCUST–455
request time-out INCUST–456
creating connection criteria SERSYS–116
data source creation SERSYS–116
delete row (DR) PROGREF–370
describe query (DQ) PROGREF–369
describe table (DT) PROGREF–370
end query (EQ) PROGREF–371
fetch row (FR) PROGREF–372
grant (GF) PROGREF–361
habilitate logging (HL) PROGREF–362
I/O structure blocks PROGREF–357
inhibit logging (IL) PROGREF–362
insert row (IR) PROGREF–373
installation requirements INCUST–134
long descriptor I/O block PROGREF–357
migrating from OS/2 query server SERSYS–239
modes of operation PROGREF–354
not-logged-on mode PROGREF–360
obtain RDBMS information (RI) PROGREF–374

ODBC query server *(continued)*
ODBC conformance levels SERSYS–116
ODBC query server utilities SERSYS–116
open query mode (OQ) PROGREF–362
open session (OS) PROGREF–363
OPENODB SERSYS–116
operating modes SERSYS–115
pre-fetch I/O block PROGREF–358
query mode PROGREF–365
replace row (RR) PROGREF–374
request reference
any mode PROGREF–360
query mode PROGREF–368
return code and explanation handling PROGREF–356
return codes PRODET–175
revoke (RF) PROGREF–364
rollback work (RW) PROGREF–375
set parameters (SP) PROGREF–375
short descriptor I/O block PROGREF–357
structured query (SQ) PROGREF–376
supported data types PROGREF–366
test status (TS) PROGREF–364
using PROGREF–358
ODBC query Server
tuning the performance INCUST–245
ODBC Query server
configuration definitions INCUST–455
ODBC Query Server
supported products INTPLA–84
OfficeVision SERSYS–212
offline transaction (in shared-file server) PROGREF–296
OIA SERSYS–31
OIA (operator information area) SERSYS–35
OIA (operator information area) service in 3270 emulator PROGREF–609
OMF (Object Module Format) PROGDE–18
on-request/on-completion values, LANDP for DOS supervisor functions trace PRODET–32
online books INCUST–21
OP (open conversation) function in PPC server PROGREF–113
OP (open PIN pad) function in PIN pad server PROGREF–245
OPBS SERSYS–191
OPBS (object postbox server) PROGREF–579
OPBS.EXE INCUST–111
open batch (OB) function in shared-file server PROGREF–286
open conversation (OP) function in PPC server PROGREF–113
open conversations, DDE SERSYS–190
open PIN pad (OP) function PROGREF–245
open query mode (OQ) function in ODBC query server. PROGREF–362
open query mode (OQ) function in query server PROGREF–315
open system INTPLA–9
open transactions SERSYS–81
OPENDB2 query server program SERSYS–112
OPENLOG utility SERSYS–98
OPER.EXE INCUST–206
operating environment, notation for PROGDE–xii, PROGREF–xxvi
operating modes SERSYS–78
operating system extension INTPLA–7
operating system requirements INCUST–9
operating system
DOS INTPLA–78
OS/2 INTPLA–81
TYPE keyword, LWSCONF vector INCUST–424
workstation configuration INCUST–424
operating systems
Linux INTPLA–85
supported INTPLA–3
Windows NT INTPLA–83
operator information area (3270 emulator) PRODET–257
operator information area (OIA) SERSYS–35
operator information area (OIA) service in 3270 emulator PROGREF–609
operator interface, start PROGREF–10
operator interface
3270 emulator SERSYS–176
3287 printer emulator SERSYS–176
BPP SERSYS–176
FBSI SERSYS–176
loading statement (DOS) INCUST–206
printer manager SERSYS–176
operator intervention, end (EI) function in local resource manager PROGREF–531
operator messages
support INTPLA–39, SERSYS–140
operator receiver, update (UO) function in system manager server PROGREF–492
operator services in 3270 emulator PROGREF–618
operator
information area SERSYS–31
interface INTPLA–40, SERSYS–176
messages INTPLA–41
OPERHK keyword, DEFAULTS vector INCUST–305
options control blocks PROGDE–9
OPTIONS keyword, MSROUTBL vector INCUST–375
OQ (open query mode) function in ODBC query server. PROGREF–362
OQ (open query mode) function in query server PROGREF–315
organization of this book PRODET–viii, PROGREF–xxv
OS/2 16-bit programs
compiling and linking PROGDE–14
OS/2 32-bit programs
compiling and linking PROGDE–14
OS/2 FBSS/2 programs
compiling and linking PROGDE–14
OS/2 VDM
PAR&VBIW INCUST–434
SERVER keyword, LWSCONF vector INCUST–434
SERVER keyword, LWSCONF vector
BIWP INCUST–430, INCUST–526
LDA7 INCUST–430, INCUST–526
OS/2 virtual DOS machine PROGREF–555, PROGREF–563
OS/2 Warp H3.0 SERSYS–72
OS/2 workstations
preparing and installing LANDP INCUST–87
TCP/IP INCUST–89
workgroup installation requirements INCUST–87
OS/2, COBOL programs under VisualAge PROGDE–93
OS/2, use of native system functions PROGDE–2
OS/2
communication support INTPLA–81
compilers INTPLA–81
installation path INCUST–126
operating system INTPLA–81
path, installation INCUST–126
VDM SERSYS–226
OS2PRT.SYS INCUST–101
OUTCHR0-F keywords, MSROUTBL vector INCUST–375
output data formats (MSR/E server). PROGREF–219
output data formats MSR/E server PROGREF–219
output queue, list (LO) function in object postbox server PROGREF–581
overview, diagnostic tools PRODET–3
OVL files INCUST–229

P

P3287ATT vector INCUST–376
P3287ATT vector
example INCUST–378
quick reference INCUST–376
packets, call SERSYS–18
PACKNAME keyword, SOFTPACK vector INCUST–406
pages, number of LANDP for DOS SNA trace PRODET–22
pages, number of LANDP for DOS supervisor functions trace PRODET–32
PAGESIZE keyword
FORM4710 vector INCUST–320
FORM4720 vector INCUST–326
FORM4748 vector INCUST–345
FORM4770 vector INCUST–350
FORM47X2 vector INCUST–335
PAN (personal account number) PROGREF–232
paper jams SERSYS–45
PAR&3270 keyword, LWSCONF vector INCUST–496
PAR&3287 keyword, LWSCONF vector INCUST–499

PAR&4731 keyword, LWSCONF vector INCUST–511
PAR&4733 keyword, LWSCONF vector INCUST–513
PAR&4737 keyword, LWSCONF vector INCUST–514
PAR&4748 keyword, LWSCONF vector INCUST–515
PAR&4770 keyword, LWSCONF vector INCUST–519
PAR&47X2 keyword, LWSCONF vector INCUST–502
PAR&BIWP keyword, LWSCONF vector INCUST–435
PAR&BMLS keyword, LWSCONF vector INCUST–440
PAR&DCA keyword, LWSCONF vector INCUST–441
PAR&EJOU keyword, LWSCONF vector INCUST–442
PAR&FORW keyword, LWSCONF vector INCUST–443
PAR&JAVA keyword, LWSCONF vector INCUST–445
PAR&LDA7 keyword, LWSCONF vector INCUST–448
PAR&LINK keyword, LANDP link server INCUST–446
PAR&MQ keyword, LWSCONF vector INCUST–450
PAR&MSRE keyword, LWSCONF vector INCUST–451
PAR&ODB keyword, LWSCONF vector INCUST–455
PAR&OPBS keyword, LWSCONF vector INCUST–455
PAR&PBMS keyword, LWSCONF vector INCUST–514
PAR&PINP keyword, LWSCONF vector INCUST–457
PAR&PT21 keyword, LWSCONF vector INCUST–508
PAR&RCMS keyword, LWSCONF vector INCUST–459
PAR&SDLC keyword, LWSCONF vector INCUST–475
PAR&SFD keyword, LWSCONF vector INCUST–462
PAR&SFOR keyword, LWSCONF vector INCUST–475
PAR&SFR keyword, LWSCONF vector INCUST–464
PAR&SHDR keyword, LWSCONF vector INCUST–461
PAR&SHFL keyword, LWSCONF vector INCUST–465
PAR&SMGR keyword, LWSCONF vector INCUST–478
PAR&SMOP keyword, LWSCONF vector INCUST–477
PAR&SNA keyword, LWSCONF vector INCUST–469
PAR&SP21 keyword, LWSCONF vector INCUST–508
PAR&SQL keyword, LWSCONF vector INCUST–458
PAR&TCP keyword, LWSCONF vector INCUST–481
PAR&TKR keyword, LWSCONF vector INCUST–486
PAR&VBIW keyword, LWSCONF vector INCUST–434
PAR&VFIL keyword, LWSCONF vector INCUST–488
PAR&VVOL keyword, LWSCONF vector INCUST–489
PAR&X252 keyword, LWSCONF vector INCUST–494
PAR&X25D keyword, LWSCONF vector INCUST–491
PAR&XNAT keyword, LWSCONF vector INCUST–452
PAR4710 keyword, BPPPARM vector INCUST–301
PAR4712 keyword, BPPPARM vector INCUST–301
PAR4720 keyword, BPPPARM vector INCUST–301
PAR4722 keyword, BPPPARM vector INCUST–301
parallel redirection settings (RM) function in financial printer server PROGREF–161
parameters, passing through the API PROGDE–10
parameters, set (SP) function in ODBC query server PROGREF–375
parameters, set (SP) function in query server PROGREF–325
parameters
  run-time verification INCUST–228
  workgroup variable run-time program INCUST–227
PARLIP keyword
  LANCONF vector INCUST–421
  LWSCONF vector INCUST–427
PARLIPEX keyword, LWSCONF vector INCUST–428
PARPORT vector INCUST–291
partial files INCUST–29
PARWIN keyword, LWSCONF vector INCUST–429
PASCAL Compiler/2 INTPLA–78
Pascal programs PROGDE–9
PASSWORD keyword, SMGRUSER vector INCUST–403
password, change (CP) function in system manager server PROGREF–463
paste text (PT) function in DDE access server PROGREF–450
path (installation), run-time verification INCUST–228
PATH keyword, RCMSLNF vector INCUST–381
PC codes SERSYS–72
PC ID for userid, getting SERSYS–141
PC Integrator/2 INCUST–8
PC MACRO Assembler INTPLA–78
PC X.25 communications support program SERSYS–10
PC X.25
  Interface Co-Processor/2 Adapter INTPLA–89
PC/host file transfer INTPLA–29, SERSYS–31
PC/Integrator INCUST–8
PC/Integrator
  translation table INCUST–408
  VDM (OS/2) INCUST–91
PC/TCP INCUST–527, INCUST–530
PC/TCP Network Software INTPLA–78
PC/TCP
  datagram length INCUST–191
  LANCONF vector
    XPORT keyword INCUST–419
PCB INCUST–395
PCB table SERSYS–80
PCBNAME keyword, SHFLPCB vector INCUST–396
PCL4 and PCL5 print modes SERSYS–44
PCN INCUST–228
PD (poke data) function in DDE access server PROGREF–446
PD (print data) function in EXFS user-written exit server PROGREF–664
PDPACK utility PRODET–57
PDPACK utility, description PRODET–5
peek data (KD) function in DDE access server PROGREF–446
performance PRODET–xi
performance
  query server INCUST–244
  shared-file server INCUST–243
  Windows 3.1 under LANDP for DOS INCUST–246
personal account number (PAN) PROGREF–232
Personal Communications INTPLA–21
Personal Communications books INCUST–587, INTPLA–153, PRODET–299, PROGDE–227, PROGREF–707, SERSYS–279
Personal Communications for Windows SERSYS–15
Personal Communications
  OS/2 INCUST–87
  Windows INCUST–127, INCUST–129
personal computer books INCUST–583, INTPLA–149, PRODET–295, PROGDE–223, PROGREF–703, SERSYS–276
personal identification number (pin) pad server SERSYS–76
personal identification number (PIN) pad server PROGREF–223, PROGREF–251
personal printer data stream SERSYS–44
phase management SERSYS–49
phase remote release SERSYS–51
physical electronic journal
  allocate (AL) PROGREF–392
physical layer INTPLA–20, SERSYS–8
physical unit SERSYS–10, SERSYS–21
PHYSREC keyword, SHFLDBD vector INCUST–392
PIF (LANDP for Linux) INCUST–174
PIF (LANDP for Windows) INCUST–136
PIN pad device server SERSYS–76
PIN pad server INCUST–12, INCUST–14, INCUST–15, INCUST–16, PRODET–xi

PIN pad server
COM port INCUST–457
configuration definitions INCUST–457
configuration example INCUST–458
DEVICE statement (DOS) INCUST–198
DEVICE statement (OS/2) INCUST–100
loading statement (DOS) INCUST–206
loading statement (Linux) INCUST–181
loading statement (OS/2) INCUST–111
loading statement (Windows) INCUST–148
PIN pad device INCUST–457
return codes PRODET–177, PRODET–181
PIN pad
input translation table INCUST–378
PIN verification parameters, load (LP) function PROGREF–244
PIN1 alert, hardware error
LANDP for DOS PRODET–239
PIN1, hardware error
alerts PRODET–239
PIN2 alert, device not connected PRODET–240
PIN2, device not connected
alerts PRODET–240
PING, TCP/IP (OS/2) INCUST–528
PINK keyword, DISPLATT vector INCUST–313
PINP47## (PIN pad server) PROGREF–226
PINP47##.EXE INCUST–111, INCUST–148, INCUST–181, INCUST–206
PINP47##
return codes PRODET–177
PINPTBL vector INCUST–378
PINPTBL vector
example INCUST–380
quick reference INCUST–378
planning a LANDP environment INTPLA–59
planning approach INTPLA–17
planning tasks INTPLA–63
PLAYLOG2 query server program SERSYS–113
point-to-point line INTPLA–88, SERSYS–9
poke data (PD) function in DDE access server PROGREF–446
polling asynchronous event information PROGDE–42
pool, specifying LANDP for DOS supervisor buffer PRODET–32
pooling support, LU INCUST–514
pooling support, LU
OS/2 installation requirements INCUST–90
PAR&4731 keyword INCUST–510, INCUST–511
PAR&4737 keyword INCUST–512
PAR&BIWP keyword INCUST–435
PAR&LDA7 keyword INCUST–448
PAR&PT21 keyword INCUST–508, INCUST–509
pooling support, LU *(continued)*
PAR&RCMS keyword INCUST–459
PAR&SNA keyword INCUST–470
PAR&VFIL keyword INCUST–488
PAR&VVOL keyword INCUST–490
SES&3270 keyword INCUST–497
SES&3287 keyword INCUST–500
SES&BPP keyword INCUST–439
SES&FORW keyword INCUST–444
Windows installation requirements INCUST–130
pooling, LU SERSYS–21
POOLSIZE keyword, LWSCONF vector INCUST–427
port number, LIP INCUST–529
port status SERSYS–74
portability INTPLA–15
portability considerations in 3270 emulator PROGREF–653
portable clients INTPLA–8
post, telephone, and telegraph administration SERSYS–11
posted GUI messages PROGDE–42
posting events
start (SP) PROGREF–20
stop (TP) PROGREF–23
POSTLOAD vector INCUST–292
power-on reset, printer SERSYS–69
PPC server
emulation over TCP/IP INCUST–482
OS/2 INCUST–94
OS/2
loading statement INCUST–111
startup parameters INCUST–111
return codes PRODET–181
Windows INCUST–133
Windows
loading statement INCUST–149
startup parameters INCUST–149
PPC#### (name of PPC server) PROGREF–108
PPC
communication INTPLA–20, SERSYS–7
server INTPLA–26, SERSYS–24
service requests INTPLA–21, SERSYS–14
PPDS SERSYS–44
PR (process read data) function in EXFS user-written server PROGREF–107
PR4748.UDC PROGREF–170
PR4748## (4748 printer server) PROGREF–171
PR4748##.EXE INCUST–120, INCUST–157, INCUST–214
PR4770## (4770 printer server) PROGREF–190
PR4770##.EXE INCUST–120
pr47x2## INCUST–186
PR47X2## (financial printer server) PROGREF–144
PR47X2##.EXE INCUST–120, INCUST–156, INCUST–214
PR47X2##.EXE, printer server PRODET–56
preparing plans utility SERSYS–49
preparing workstations
DOS INCUST–189
Linux INCUST–163
OS/2 INCUST–87
Windows INCUST–127
prerequisite knowledge INCUST–xxiii, PRODET–vii, PROGREF–xxv
presentation services in 3270 emulator PROGREF–630
preventing locking by using timeouts PROGREF–28
PREVLOAD vector INCUST–293
primary I/O errors
shared-file servers PRODET–202
print data (PD) function in EXFS user-written exit server PROGREF–664
print density mode, change (CM) function in local resource manager PROGREF–528
print formats SERSYS–69
print modes SERSYS–73
print modes
emulator SERSYS–44
printer errors
PS1, hardware error PRODET–234
printer formats, defining SERSYS–72
printer manager server PROGREF–199
printer manager server operator interface SERSYS–176
printer manager server
loading statement (DOS) INCUST–206
PRINT statement (DOS) INCUST–202
Printer manager server
return codes PRODET–180
printer manager
server SERSYS–73
printer POR SERSYS–69
printer server SERSYS–68
printer server
interface SERSYS–69
printer sharing (4700 and local applications) INCUST–105
printing host data INTPLA–29, SERSYS–44
priority of LU, change (CP) function in local resource manager PROGREF–529
problem determination SERSYS–143
problem determination tools, overview PRODET–3
problem determination
APPLYFIX program PRODET–64
corrective service diskette (CSD) PRODET–54
data required when reporting problems PRODET–54
flowcharts PRODET–64, PRODET–78
flowcharts
communication server PRODET–70, PRODET–77
database server PRODET–69, PRODET–76
financial I/O servers PRODET–68, PRODET–75
load time problems PRODET–66, PRODET–72
IBM support PRODET–53, PRODET–78

problem determination *(continued)*
VERSION utility PRODET–59
problem management INTPLA–41, SERSYS–47
process connection (&&) PROGDE–66
process connection and disconnection events PROGDE–45
process disconnection (**) PROGDE–64
process ID SERSYS–24
process identification PROGDE–7
process read data (PR) function in EXFS user-written server PROGREF–107
process results, RCMS SERSYS–63
process send data (PS) function in EXFS user-written server PROGREF–108
PRODLVL keyword, LWSCONF vector INCUST–425
production data distribution INTPLA–41, SERSYS–47
production site INCUST–7
profile, run-time verification INCUST–228
program control blocks SERSYS–80
program defect, reporting PRODET–53
program fix (APAR), applying INCUST–251
program fixes, applying SERSYS–232
program load (LP) function in DDE access server PROGREF–439
program temporary fix SERSYS–232
program types (LANDP for OS/2) PROGDE–16
program version level PRODET–59
program version level, checking PRODET–59
program-to-program communication INTPLA–20, INTPLA–22, SERSYS–7, SERSYS–18
Program-to-program communications server
return codes PRODET–181
program-to-program server INTPLA–26, SERSYS–24
program
control block INCUST–395
fixes, installing INCUST–251
information file (PIF) INCUST–136, INCUST–174
version level (Linux), checking INCUST–249, PRODET–61
version level, checking INCUST–247
workgroup variable run-time parameters INCUST–227
programs, by name
DDT PRODET–9
EHCLIP PRODET–49
EHCLIP, description of LANDP for DOS PRODET–35
EHCTRACF PRODET–49
EHCTRACW PRODET–40
programs, sharing INTPLA–38, SERSYS–132
programs
EHCTRALL PRODET–14
GETTRACE PRODET–14
protect record in shared-file server PROGREF–282, PROGREF–286
protocol handling INTPLA–20, SERSYS–8
protocol, low-level communication INCUST–527
PROTOCOL.INI INCUST–88
PRTMGR (printer manager server) PROGREF–200
PRTMGR.EXE INCUST–206
PRTMON.EXE INCUST–105, PROGREF–161
PRTY keyword, FORWDS vector INCUST–352
PS (process send data) function in EXFS user-written server PROGREF–108
PS1 alert, hardware error PRODET–234
PSWCRYPT keyword, SMGRUSER vector INCUST–403
PT (paste text) function in DDE access server PROGREF–450
PTF SERSYS–232
PTT parameters SERSYS–11
PU SERSYS–10, SERSYS–21
public information sources INTPLA–19, SERSYS–7
publications, LANDP PRODET–viii
pure 16-bit programs PROGDE–16
pure 32-bit programs PROGDE–16

Q

QA (query applications) function in DDE access server PROGREF–440
QD (query file) function in store-for-forwarding server PROGREF–414
QE (query event) supervisor local function PROGREF–17
QP (query PCB) function in shared-file server PROGREF–287
QUALITY keyword
FORM4720 vector INCUST–326
FORM47X2 vector INCUST–336
query functions
information (II) supervisor local function PROGREF–14
query event (QE) supervisor local function PROGREF–17
query server INTPLA–33, PRODET–xi, SERSYS–109
query server migration SERSYS–237
query server utilities, LANDP for OS/2 SERSYS–239
Query server utility programs
return codes PRODET–188
query server
concurrent requests, maximum number INCUST–458
configuration definitions INCUST–458
configuration name INCUST–458
installation requirements (OS/2) INCUST–97
loading statement (OS/2) INCUST–111
migration from FBSS/2 to LANDP for OS/2 SERSYS–237
migration from shared-file server SERSYS–238
ODBC flag INCUST–459
query manager INCUST–97
request time-out INCUST–458
query server *(continued)*
sessions per terminal, maximum number INCUST–458
shared file response time INCUST–458
simultaneous commit units, maximum number INCUST–458
tuning the performance INCUST–244
utilities SERSYS–239
utilities, LANDP for OS/2 SERSYS–111
Query server
return codes PRODET–184
query status (TS) function in ODBC query server. PROGREF–364
query status (TS) function in query server PROGREF–316
query, describe (DQ) function in ODBC query server. PROGREF–369
query, describe (DQ) function in query server PROGREF–320
query, end of (EQ) function in ODBC query server. PROGREF–371
query, end of (EQ) function in query server PROGREF–322
query, structured (SQ) function in ODBC query server PROGREF–376
query, structured (SQ) function in query server PROGREF–326
queues, inactive SERSYS–192
quiesce protocol (SNA server) PROGREF–42

R

R1 (retrieve LOG record) function in system manager server PROGREF–509
random number generation (X'0040') in cryptographic interface PROGREF–82
RC (read CICS) function in CICS interface server PROGREF–433
RC (read code page) function in financial printer server PROGREF–159
RC (run command) function in DDE access server PROGREF–440
RC1 alert, file operation error PRODET–241
RC1, file operation error
alerts PRODET–241
RCME.MSG INCUST–229
RCMS INTPLA–12, INTPLA–41, SERSYS–47
RCMS (remote change management services)
alerts PRODET–241
RCMS.EXE INCUST–112, INCUST–149, INCUST–206
RCMS.LNF INCUST–229
RCMS.LNF, creating and modifying SERSYS–50, SERSYS–51
RCMS.LNF, creating and modifying
LNFEDIT program, using correct VDM for SERSYS–51
RCMS
configuration definitions INCUST–459
DLC type INCUST–460
loading statement (DOS) INCUST–206
loading statement
OS/2 INCUST–112

RCMS *(continued)*
loading statement *(continued)*
Windows INCUST–149
logical name in the host INCUST–381
Netview distribution manager INCUST–381
Netview DM INCUST–381
process file path INCUST–460
return codes PRODET–189
session device name INCUST–460
SNA LU number INCUST–459
SNA LU pool ID INCUST–459
SNA pool ID INCUST–459
software requirements INTPLA–86
system file path INCUST–460
translation table INCUST–407, INCUST–460, INCUST–461
RCMSLNF vector INCUST–381
RCMSLNF vector
example INCUST–382
quick reference INCUST–381
RCMSPLAN files SERSYS–49
RCMSPLAN.NEW SERSYS–51
RCMSPLAN.OLD SERSYS–51
RCMSPLAN.TXT SERSYS–51
RD (read data) function in 4748 printer server PROGREF–185
RD (read data)
function in financial printer server PROGREF–160
RD (read from the IBM 47xx MSR/E) function in MSR/E server PROGREF–214
RD (read from the IBM 47xx PIN pad) function in PIN pad server PROGREF–246
RD (receive data) function in PPC server PROGREF–115
RD (register device and check status) function in object postbox server PROGREF–583
RD (request data) function in DDE access server PROGREF–447
RD (retrieve LANDP workgroup common data) function in system manager server PROGREF–489
RDBMS information, obtain (RI) function in ODBC query server PROGREF–374
RDF.CFG INCUST–229
RE (retrieve defined users list) function in system manager server PROGREF–467
read response delay (MSRE) INCUST–373
readers of this book INCUST–xxiii, PRODET–vii, PROGREF–xxv
Realtime Interface Co-Processor DOS Support SERSYS–10
RECDEF vector INCUST–382, INCUST–384
RECEIVE command SERSYS–201, SERSYS–215
RECEIVE command 3270 HLLAPI PROGREF–655
receive data (RD) function in PPC server PROGREF–115
RECEIVE messages SERSYS–211
RECEIVE.COM and RECEIVE.EXE SERSYS–214
receiving
files INTPLA–53, SERSYS–200
resources INTPLA–41
RECFIELD vector INCUST–384, INCUST–386
RECLEN keyword, SHFLDBD vector INCUST–392
RECNAME keyword
EJOUREC vector INCUST–318
SFORWREC vector INCUST–389
SHFLDBD vector INCUST–391
record definitions, system manager SERSYS–146
record format
defined by RECFIELD vector INCUST–382
run-time verification INCUST–228
variable data (DOS) INCUST–223
record locks, managing SERSYS–87
record of applied fixes SERSYS–232
record structures, retrieving INTPLA–39, SERSYS–140
recording transactions INTPLA–35, SERSYS–118
records, variable length SERSYS–49
RECOVER2 query server program SERSYS–114
recovery, forward SERSYS–81
RED keyword, DISPLATT vector INCUST–313
redirecting data from parallel port to serial printer PROGREF–161
redirection mode, set (RM) function in financial printer server PROGREF–161
register device and check status (RD) function in object postbox server PROGREF–583
registry (Windows) INCUST–140
related information INCUST–xxiv, PRODET–viii, PROGREF–xxviii
related planning tasks INTPLA–17
relational database access INTPLA–19, SERSYS–7
relationship between clients and servers PROGDE–1
releasing phases SERSYS–49
remote change management services INTPLA–12, INTPLA–41, PRODET–xi
remote change management services (RCMS) SERSYS–47
remote change management services (RCMS)
defining aliases SERSYS–49
EHCRCMS.LOG SERSYS–63
error log SERSYS–63
file access SERSYS–49
NetView DM commands SERSYS–55
RCMSPLAN.NEW SERSYS–51
RCMSPLAN.OLD SERSYS–51
RCMSPLAN.TXT SERSYS–51
reporting process results SERSYS–63
requesting phase remote release SERSYS–51
translating data SERSYS–51
transmission log SERSYS–63
remote change management services
translation table INCUST–381
Remote change management services
return codes PRODET–189
remote customization INCUST–29
remote installation INCUST–7
remote mode, change printer to (HP) function in local resource manager PROGREF–548
remote node problem management INTPLA–41, SERSYS–47
remote release, phase SERSYS–51
remote requests included or excluded, LANDP for DOS PRODET–37
remote servers PROGDE–5
remote sign-off (RF) function in system manager server PROGREF–467
removing data from repository INCUST–38, INCUST–236
REMSMODE keyword
FORM4720 vector INCUST–326
FORM4748 vector INCUST–345
FORM47X2 vector INCUST–336
REPLACE command SERSYS–59
replace row (RR) function in ODBC query server PROGREF–374
replace row (RR) function in query server PROGREF–324
replicator server SERSYS–107
replicator server, shared-file PROGREF–259
replied DATA length PROGDE–7, PROGDE–10
replied PARMLIST length PROGDE–7, PROGDE–10
reply DATA PROGDE–3
reply PARMLIST PROGDE–3
request DATA PROGDE–3
request data (RD) function in DDE access server PROGREF–447
request PARMLIST PROGDE–3
RequestFromLandp class PROGDE–77
requesting assistance, guidelines PRODET–53
requesting services INTPLA–8
reserved names PROGDE–12
reset electronic journal file (RS) function PROGREF–400
RESET keyword, P3287ATT vector INCUST–377
reset packets
Native X.25 server PRODET–171
reset store-for-forwarding file (RS) function PROGREF–417
resolution notification PRODET–7
resolution notification (UN) function in system manager server PROGREF–503
resource name PROGDE–7
resource
tracking INTPLA–41
resources assigned SERSYS–74
resources
receiving INTPLA–41
sending INTPLA–41
tracking SERSYS–47
response protocol (SNA server) PROGREF–41
restarting LANDP
ehcrstml INCUST–176

RESTORE utility program
return codes PRODET–204
RESTORE2 query server program SERSYS–113
restoring shared files SERSYS–99
restrictions, Windows INTPLA–15
retrieval of defined record structures server functions PROGREF–493
retrieve application program data (GU) function in system manager server PROGREF–477
RETRIEVE by CATALOG command SERSYS–61
RETRIEVE command SERSYS–60
retrieve defined users list (RE) function in system manager server PROGREF–467
retrieve LANDP workgroup common data (RD) function in system manager server PROGREF–489
retrieve lists of users holding locks (RK) function in system manager server PROGREF–468
retrieve LOG record (R1) function in system manager server PROGREF–509
retrieve LOG record (RL) function in system manager server PROGREF–507
retrieve record format (RR) function in system manager server PROGREF–493
retrieve signed-on users list (RO) function in system manager server PROGREF–469
retrieve system date and time (GD) function in system manager server PROGREF–485
retrieving defined record structures INTPLA–39, SERSYS–140
retrieving messages PROGREF–577
return code classes PRODET–6
return codes, LANDP for DOS PRODET–123
return codes, loading PRODET–81
return codes,
LOADER and LOADERE programs PRODET–82
return codes
ASCII-EBCDIC server PRODET–127
ASCII-EBCDIC translation server PRODET–127
BACKUP utility program PRODET–204
CICS interface server PRODET–128
compression server PRODET–130
cryptographic interface PRODET–131
DDE access server PRODET–133
description of PRODET–5
EHCLIP program PRODET–155
EHCSQL ## PRODET–184
electronic journal server PRODET–136
financial printer server PRODET–141
IBM 4717 Magnetic Stripe Reader PRODET–163
IBM 4717 Magnetic Stripe Reader/Encoder PRODET–163
IBM 4718 PIN Key Pad PRODET–177
IBM 4748 printer server PRODET–145
IBM 4770 printer server PRODET–148
return codes *(continued)*
IBM 4777 Magnetic Stripe Reader PRODET–163
IBM 4777 Magnetic Stripe Reader/Encoder PRODET–163
IBM 4778 PIN Pad Magnetic Stripe Reader PRODET–177
LANDP for DOS PRODET–123
LANDP for Linux PRODET–123
LANDP for OS/2 PRODET–123
LANDP for Windows PRODET–123
LANDP Internet Protocol PRODET–155
LANDP link server PRODET–158
LANDP servers PRODET–125
Local resource management server PRODET–160
Magnetic stripe reader/encoder server PRODET–163
MQSeries Link Server PRODET–166
MSR/E server PRODET–163
Native X.25 Server PRODET–169
notation for PROGDE–xii, PROGREF–xxvii
Object post box server PRODET–173
ODBC query server PRODET–175
PIN pad server PRODET–177, PRODET–181
PINP47## PRODET–177
PPC server PRODET–181
Printer manager server PRODET–180
printer servers
IBM 4009 Universal Banking Printer PRODET–141
IBM 4712 Transaction Printer PRODET–141
IBM 4722 Document Printer PRODET–141
IBM 4748 Document Printer PRODET–145
IBM 4772 Ink Jet Transaction Printer PRODET–141
IBM 9055-001 Multi–purpose Passbook Printer PRODET–145
IBM 9055-002 Document Printer PRODET–141
IBM 9068-A01 Multi–purpose Passbook Printer PRODET–141
IBM 9068-A03 Multi–purpose Passbook Printer PRODET–141
IBM 9068-D01 Multi–purpose Passbook Printer PRODET–145
IBM 9068-S01 Multi–purpose Passbook Printer PRODET–141
Program-to-program communications server PRODET–181
Query server PRODET–184
Query server utility programs PRODET–188
RCMS PRODET–189
Remote change management services PRODET–189
RESTORE utility program PRODET–204
shared-file servers PRODET–200, PRODET–201
Shared-file servers PRODET–193
return codes *(continued)*
shared-file utility programs PRODET–204
SHFILE ## PRODET–193
SNA ## PRODET–205
SNA server PRODET–205
store-for-forwarding server PRODET–136
Supervisor local functions PRODET–210
System manager server PRODET–212
TCP/IP wide area communications server PRODET–218
types of
migrating customization INCUST–232
obtaining software INCUST–63
validating customization data INCUST–56
VisualAge Generator support functions PRODET–220
REXX application programming interface (OS/2) PROGDE–103
REXX messages (for LANDP for OS/2) PRODET–229
RF (remote sign-off) function in system manager server PROGREF–467
RH (read header) function in shared-file server PROGREF–290
RI (obtain RDBMS information) function in ODBC query server PROGREF–374
RK (retrieve lists of users holding locks) function in system manager server PROGREF–468
RL (release a parallel printer port) function in printer manager server PROGREF–202
RL (release electronic journal) function in electronic journal server PROGREF–398
RL (retrieve LOG record) function in system manager server PROGREF–507
RM (read message) function in object postbox server PROGREF–584
RM (set redirection mode) function in financial printer server PROGREF–161
RMTAREQ call PROGDE–5, PROGDE–58
RMTREQ call PROGDE–5, PROGDE–31
RMTREQ NoWait call PROGDE–5, PROGDE–33
RMTRPLY call PROGDE–5, PROGDE–57
RN (read serial number) function in PIN pad server PROGREF–247
RN (retrieve user profile by record number) function in system manager server PROGREF–478
RO (retrieve signed-on users list) function in system manager server PROGREF–469
rollback work (RW) function in ODBC query server PROGREF–375
rollback work (RW) function in query server PROGREF–325
rolled-back transactions SERSYS–81
root node SERSYS–105
root server SERSYS–106
router return codes, description of PRODET–6

router return codes
notation for PROGDE–xii, PROGREF–xxvii
routines trace, LANDP for DOS supervisor PRODET–34
routing requests PROGDE–2
row, delete (DR) function in ODBC query server. PROGREF–370
row, delete (DR) function in query server PROGREF–321
row, fetch (FR) function in ODBC query server. PROGREF–372
row, fetch (FR) function in query server PROGREF–323
row, insert (IR) function in ODBC query server. PROGREF–373
row, insert (IR) function in query server PROGREF–323
row, replace (RR) function in ODBC query server PROGREF–374
row, replace (RR) function in query server PROGREF–324
RPLOAD keyword
LANCONF vector INCUST–419
LWSCONF vector INCUST–426
RR (replace row) function in ODBC query server PROGREF–374
RR (replace row) function in query server PROGREF–324
RR (retrieve record format) function in system manager server PROGREF–493
RS (reset electronic journal file) function in electronic journal server PROGREF–400
RS (reset store-for-forwarding file) function in store-for-forwarding server PROGREF–417
RS/6000 Transaction Security System SERSYS–19
RTR protocol (SNA server) PROGREF–40
RU (retrieve user profile) function in system manager server PROGREF–480
RU maximum size SERSYS–12
run command (RC) function in DDE access server PROGREF–440
run time problems PRODET–72
run-time file generation
GENRUN procedure INCUST–63
overview INCUST–61
run-time files
installation
DOS INCUST–218
installing
Linux INCUST–188
OS/2 INCUST–126
Windows INCUST–161
modifying
DOS INCUST–194
Linux INCUST–176
OS/2 INCUST–99
Windows INCUST–139
run-time parameters program, workgroup variable INCUST–227
run-time utility programs INCUST–223
run-time verification of installation path INCUST–228
running LANDP for DOS applications in Linux workstations PROGREF–563
running LANDP for DOS applications in OS/2 or Windows workstations PROGREF–555
RW (rollback work) function in ODBC query server PROGREF–375
RW (rollback work) function in query server PROGREF–325
RX (retrieve user profile (Year-2000)) function in system manager server PROGREF–481

S

S1 alert, unexpected SNRM command received PRODET–247
S1-3APPNAM keywords, FORWPRF vector INCUST–356
S1-3INITS1 keywords, FORWPRF vector INCUST–356
S1-3INITS2 keywords, FORWPRF vector INCUST–356
S1-3MAXCHR keywords, FORWPRF vector INCUST–355
S1-3RESTO keywords, FORWPRF vector INCUST–355
S1-3RETTO keywords, FORWPRF vector INCUST–356
S1-3TYPDLC keywords, FORWPRF vector INCUST–356
S1-3TYPE keywords, FORWPRF vector INCUST–355
S1, unexpected SNRM command received alerts PRODET–247
S2 alert, invalid or unsupported frame received PRODET–248
S2—Invalid or unsupported frame received
alerts PRODET–248
S3 alert, frame exceeding allowable length received PRODET–249
S3—Frame exceeding allowable length received
alerts PRODET–249
S4 alert, timer expired without being polled PRODET–250
S4—Timer expired without being polled
alerts PRODET–250
S5 alert, modem power off PRODET–251
S5—Modem power off
alerts PRODET–251
SA (set alternate mode) function in local resource manager PROGREF–542
SAM (system availability manager) INTPLA–32
SAMCFG.EXE INCUST–228
sample application programs
building PROGDE–168
DOS client (COBOL) PROGDE–160, PROGDE–170
header files (C language) PROGDE–130
listed and annotated PROGDE–119
OS/2 (COBOL) PROGDE–140, PROGDE–159
sample application programs *(continued)*
OS/2 client (COBOL) PROGDE–141, PROGDE–153, PROGDE–160, PROGDE–170
OS/2 user-written server (COBOL) PROGDE–154, PROGDE–159
tutorial PROGDE–119
Windows (C) PROGDE–119
Windows (C)
building PROGDE–168
header files (C language) PROGDE–168
using PROGDE–168
Windows (COBOL) PROGDE–140, PROGDE–159
Windows client (C) PROGDE–119
Windows client (COBOL) PROGDE–141, PROGDE–153
Windows user-written server (C) PROGDE–131
Windows user-written server (COBOL) PROGDE–154, PROGDE–159
sample configurations INTPLA–65
sample customization INCUST–277, INCUST–283
sample customization
creating common vectors INCUST–279
distributing software INCUST–283
editing common vectors INCUST–279
editing workgroup vectors INCUST–280
installing INCUST–278
obtaining software for distribution INCUST–282
validating common vectors INCUST–279
validating workgroup vectors INCUST–282
sample files for MVDM relays PROGREF–557, PROGREF–564
SAMPLE1 INCUST–277
SAMPLE1, sample customization INCUST–277
saving transactions INTPLA–35, SERSYS–118
SBC keyword
LWSCONF vector INCUST–429
SBCS INTPLA–115
SBSX25 keyword,
LWSCONF vector INCUST–473
SC (set code page) function in financial printer server PROGREF–162
scan code of keystroke in 3270 emulator PROGREF–603
scan codes for hotkeys INCUST–305
screens, levels and names of LANDP for DOS trace tool PRODET–11
SD (send data) function in PPC server PROGREF–116
SD (set system date and time) function in system manager server PROGREF–486
SD (statistics on DBD) function in query server PROGREF–349
SDLC INTPLA–20, PRODET–xi, SERSYS–8

SDLC (synchronous data link control)
alerts PRODET–247
SDLC server
buffers INCUST–475
connection INCUST–476
identification block INCUST–476
identification number INCUST–476
line mode INCUST–476
line time-out INCUST–476
loading statement (DOS) INCUST–210
NRZI INCUST–476
PU physical address, host INCUST–476
SDLC.COM INCUST–210
SSCP name INCUST–476
switched line INCUST–476
SDLC
Communication Adapter INTPLA–89
line speeds INTPLA–88
number of buffers SERSYS–12
server SERSYS–9
speed INTPLA–88, SERSYS–9
trace, LANDP for DOS PRODET–15
SE (set exclusive mode) function in local resource manager PROGREF–544
search
hints in electronic journal server PROGREF–390
searcher
loading statement (DOS) INCUST–207
loading statement (OS/2) INCUST–113
loading statement (Windows) INCUST–150
SECLVL keyword, SMGRPRF vector INCUST–400
security level SERSYS–136
security system SERSYS–141
SECY (cryptographic interface server) PROGREF–79
segmentation protocol (SNA server) PROGREF–38
segmented key INCUST–396
select current electronic journal (SL) function PROGREF–401
semaphore-handling
Linux PROGREF–5
semaphores
association (AS) supervisor local function PROGREF–7
dissociation (DS) supervisor local function PROGREF–9
events PROGREF–6
managing PROGREF–3
SEND command SERSYS–62, SERSYS–201, SERSYS–215
SEND command 3270 HLLAPI PROGREF–655
send CPRBs, for application testing PROGDE–112
send data (SD) function in PPC server PROGREF–116
send data, process (PS) function in EXFS user-written server PROGREF–108
SEND MESSAGE command SERSYS–63
SEND messages SERSYS–211
SEND.COM and SEND.EXE SERSYS–214
sending alerts PROGREF–499, PROGREF–503
sending asynchronous events PROGDE–66
sending
files INTPLA–53, SERSYS–200
resources INTPLA–41
SEPSESS keyword
EJOUPRF vector INCUST–315
SFORWPRF vector INCUST–387
sequential access method (in shared-file server) PROGREF–255
sequential access, shared-file SERSYS–78
serial number, read (RN) function in PIN pad server PROGREF–247
server data, managing INTPLA–40, SERSYS–146
server generated events INTPLA–10
server information (ZI) function in SNA server PROGREF–66
server interface, printer SERSYS–69
SERVER keyword, LWSCONF vector INCUST–430
server programming
in name PROGDE–12
alias names PROGDE–12
definition of server PROGDE–1
function of a server PROGDE–1
mono-service servers PROGDE–11
multiple-service servers PROGDE–11
name substitution PROGREF–565
names of servers PROGDE–11
receiving system requests PROGDE–59
server names PROGDE–11
structure of a server PROGDE–5
wait multiple (WM) in a server PROGDE–72
where servers are located PROGDE–1, PROGDE–5
server recognition (IN) PROGDE–60
server return codes, description of PRODET–6
server return codes
notation for PROGDE–xii, PROGREF–xxvii
server status, displaying SERSYS–233
server, definition of PROGDE–1
server
4717 MSR/E server SERSYS–75
4718 PIN Pad server SERSYS–76
4777 MSR/E server SERSYS–75
4778 PIN Pad server SERSYS–76
batch machine facility INTPLA–50, SERSYS–191
batch machine operator SERSYS–196
CICS interface server INTPLA–48, SERSYS–189
communication servers SERSYS–7
compression server INTPLA–25, SERSYS–22
data management servers INTPLA–31
DDE access server INTPLA–49, SERSYS–190
defined INTPLA–7
distributor server SERSYS–105
server *(continued)*
electronic journal server INTPLA–35, SERSYS–118
forwarding server INTPLA–37, SERSYS–128
ink jet transaction printer server SERSYS–73
journal server INTPLA–35, SERSYS–118
LANDP link server SERSYS–3
linking LANDP workgroups SERSYS–3
local resource manager server INTPLA–41, SERSYS–186
magnetic stripe reader/encoder server SERSYS–75
MAIL program INTPLA–51, SERSYS–192
maximum number of clients INTPLA–99
MSR/E server SERSYS–75
native X.25 server INTPLA–25, SERSYS–23
object post box server SERSYS–195
personal identification number pad server SERSYS–76
PIN Pad server SERSYS–76
PPC server INTPLA–26, SERSYS–24
printer manager server SERSYS–73
program-to-program server INTPLA–26, SERSYS–24
query server INTPLA–33, SERSYS–109
replicator server SERSYS–107
service availability manager (EHCSAM) SERSYS–89
service availability manager (SAM) SERSYS–187
shared-file distributor server SERSYS–105
shared-file replicator server SERSYS–107
shared-file server INTPLA–31, SERSYS–78
SNA server INTPLA–24, SERSYS–20, SERSYS–87
store-for-forwarding server INTPLA–36, SERSYS–124
system management servers INTPLA–39
system manager server INTPLA–39, SERSYS–140
translation server INTPLA–116
wide area communication INTPLA–19
wide area communication servers SERSYS–7
X.25 server INTPLA–25, SERSYS–23
servers supplied with LANDP
query server PROGREF–301
system manager PROGREF–459
servers
help facility INCUST–53
ODBC query server PROGREF–353
Windows services INCUST–139
service activation (AS) function in local resource manager PROGREF–523
service availability manager (EHCSAM) SERSYS–89

service availability manager (SAM) SERSYS–187
service availability manager (SAM)
dynamic reconfiguration of XLR servers SERSYS–187
maintaining state information for XLR servers SERSYS–187
message broadcast facility. SERSYS–188
service availability manager
loading statement (OS/2) INCUST–113
loading statement (Windows) INCUST–150
loading statements (Linux) INCUST–181
service marks INCUST–554, INTPLA–120, PRODET–266, PROGDE–194, PROGREF–674, SERSYS–246
service suspension (SS) function in local resource manager PROGREF–537
service, requesting IBM PRODET–53
services, request INTPLA–8
services, Windows INCUST–139
services
application integration INTPLA–13
communications INTPLA–11
data management INTPLA–12
I/O device INTPLA–13
system management INTPLA–12
SERVPARM keyword, SVRMODEL vector INCUST–526
SES&3270 keyword, LWSCONF vector INCUST–496
SES&3287 keyword, LWSCONF vector INCUST–500
SES&4748 keyword, LWSCONF vector INCUST–517
SES&4770 keyword, LWSCONF vector INCUST–520
SES&47X2 keyword, LWSCONF vector INCUST–506
SES&BPP keyword, LWSCONF vector INCUST–438
SES&FORW keyword, LWSCONF vector INCUST–443
SES&LINK keyword, LANDP link server INCUST–447
SES&NSVC keyword, LWSCONF vector INCUST–453
SES&SHDR keyword, LWSCONF vector INCUST–462
SES&SNA keyword, LWSCONF vector INCUST–470
SES&SPVC keyword, LWSCONF vector INCUST–471
SES&SSVC keyword, LWSCONF vector INCUST–472
SES&TCP keyword, LWSCONF vector INCUST–482
session cryptography, SNA SERSYS–47
session ID
local INTPLA–22, INTPLA–23, SERSYS–18
workstation INTPLA–23, SERSYS–18
session initiation (IS) function in local resource manager PROGREF–536
SESSION keyword, FORWDS vector INCUST–352
session release PROGREF–557, PROGREF–562, PROGREF–564, PROGREF–567
session
LANDP INTPLA–23, SERSYS–18
LU_1 SERSYS–45
LU_2 SERSYS–31
routing within a LANDP workgroup INTPLA–22, SERSYS–18
set alternate mode (SA) function in local resource manager PROGREF–542
set code page (SC) function in financial printer server PROGREF–162
set communication status (CS) function in store-for-forwarding server PROGREF–410
set exclusive mode (SE) function in local resource manager PROGREF–544
set parameters (SP) function in ODBC query server PROGREF–375
set parameters (SP) function in query server PROGREF–325
set redirection mode (RM) function in financial printer server PROGREF–161
set system date and time (SD) function in system manager server PROGREF–486
SET, DOS command SERSYS–212
setting status of LANDP for Linux trace tool PRODET–41
setting status of LANDP for OS/2 trace tool PRODET–41
setting status of LANDP for Windows trace tool PRODET–41
SF (sign-off) function in system manager server PROGREF–471
SF1 alert, error by disk read PRODET–244
SF1, error by disk read
alerts PRODET–244
SF2 alert, file full
LANDP for DOS PRODET–245
SF2, file full
alerts PRODET–245
SFF1 alert, unsuccessful call to shared-file server PRODET–246
SFF1, unsuccessful call to shared-file server
alerts PRODET–246
SFORFORW (store-for-forwarding server) PROGREF–408
SFORFORW.EXE INCUST–117, INCUST–153, INCUST–184, INCUST–209
SFORWPRF vector INCUST–386
SFORWPRF vector
example INCUST–389
quick reference INCUST–387
SFORWREC vector INCUST–389
SFORWREC vector
example INCUST–390
quick reference INCUST–389
SFQUERY.EXE INCUST–113, INCUST–150, INCUST–207
SGM01 to SGM32 keywords, SHFLSGM vector INCUST–397
SGMKEY keyword, SHFLSGM vector INCUST–396
SH1 alert, error by disk read or write PRODET–242
SH1, error by disk read or write
alerts PRODET–242
SH2 alert, file full PRODET–243
SH2, file full
alerts PRODET–243
SHARE program (DOS) SERSYS–136
SHARE, DOS program INCUST–197
SHARE.EXE INTPLA–79
shared DOS directory INTPLA–38, SERSYS–132
shared DOS directory serve
number of entries INCUST–461
shared DOS directory server
configuration definitions INCUST–461
data area size INCUST–462
distributing software INCUST–67, INCUST–70
loading statement (DOS) INCUST–208
shared DOS directory services SERSYS–132
shared DOS directory services
directory tasks SERSYS–132
sharing information SERSYS–132
stop sharing information SERSYS–137
tuning the performance INCUST–245
unloading SERSYS–137
shared DOS directory
software requirements INTPLA–79
shared files, backup SERSYS–98
shared files, restoring SERSYS–99
shared IBM DOS directory server
alerts PRODET–242
SHARED keyword
FORM4748 vector INCUST–346
FORM47X2 vector INCUST–336
shared-file distributed server INTPLA–32
shared-file distributor server PROGREF–258, SERSYS–105
shared-file distributor
configuration definitions INCUST–462
loading statement (OS/2) INCUST–114
statistics file INCUST–462
thread number INCUST–462
shared-file keys SERSYS–79
shared-file profile definition SERSYS–102
shared-file replicator server INTPLA–32, PROGREF–259, SERSYS–107
shared-file replicator
configuration definitions INCUST–464
EHCSFRPC.PCN INCUST–464
loading statement (OS/2) INCUST–114
owner INCUST–464
PCB list file INCUST–464
statistics file INCUST–464
thread number INCUST–464
shared-file server INCUST–390, INTPLA–31
shared-file server
alerts PRODET–244
alternate collating sequence table INCUST–392

shared-file server *(continued)*
buffers INCUST–466
configuration definitions INCUST–465
database INCUST–392
database description INCUST–390
DBCS mode restrictions SERSYS–87
DBD INCUST–390
external logging replicator (XLR) INTPLA–32
file number INCUST–466
loading statement (DOS) INCUST–208
loading statement (Linux) INCUST–182
loading statement (OS/2) INCUST–114
loading statement (Windows) INCUST–151
lock management SERSYS–87
log management type INCUST–466
migration to LANDP for OS/2 query server SERSYS–238
number of files INCUST–466
owner INCUST–466
PCB INCUST–395
profile INCUST–465
program control block INCUST–395
record length INCUST–392
segmented key INCUST–396
server functions
begin transaction (BT) PROGREF–264
checkpoint (CP) PROGREF–265
close batch (CB) PROGREF–264
close on-line (CO) PROGREF–265
close session (CS) PROGREF–266
delete record (DL) PROGREF–266
enable logging (HL) PROGREF–276
end transaction (ET) PROGREF–267
erase shared-file data (ZD) PROGREF–295
fetch next record (FN) PROGREF–268
fetch previous record (FP) PROGREF–269
fetch unique record (FU) PROGREF–271
get next record (GN) PROGREF–273
get previous record (GP) PROGREF–274
get unique record (GU) PROGREF–275
grant (GF) PROGREF–272
habilitate logging (HL) PROGREF–276
hold next record (HN) PROGREF–276
hold previous record (HP) PROGREF–277
hold unique record (HU) PROGREF–278
inhibit logging (IL) PROGREF–281
initialize DBD (ID) PROGREF–280
initialize pointers (IP) PROGREF–281
shared-file server *(continued)*
server functions *(continued)*
insert record (IS) PROGREF–282
keep next record (KN) PROGREF–283
keep previous record (KP) PROGREF–284
keep unique record (KU) PROGREF–284
open batch (OB) PROGREF–286
open on-line (OO) PROGREF–286
open session (OS) PROGREF–287
query PCB (QP) PROGREF–287
read header (RH) PROGREF–290
replace record (RP) PROGREF–292
request exclusive use (EX) PROGREF–268
revoke (RF) PROGREF–289
rollback (RB) PROGREF–288
statistic request (SR) PROGREF–293
test status (TS) PROGREF–294
sessions INCUST–466
statistics file INCUST–466
tuning the performance INCUST–243
using the server PROGREF–262
utilities SERSYS–92, SERSYS–239
shared-file servers
critical errors, LANDP for DOS PRODET–200
critical errors, LANDP for Linux PRODET–201
critical errors, LANDP for OS/2 PRODET–201
critical errors, LANDP for Windows PRODET–201
primary I/O errors PRODET–202
Shared-file servers
return codes PRODET–193
shared-file statistics SERSYS–100
shared-file utility programs
return codes PRODET–204
sharing information SERSYS–132
sharing programs, files, and applications INTPLA–38, SERSYS–132
SHFILE SERSYS–79
SHFILE ##
return codes PRODET–193
shfile## INCUST–182
SHFILE## (shared-file server) PROGREF–262
SHFILE##.EXE INCUST–114, INCUST–151, INCUST–208
SHFLDBD vector INCUST–390
SHFLDBD vector
example INCUST–394
example, segmented keys INCUST–395
quick reference INCUST–390
SHFLPCB vector INCUST–395
SHFLPCB vector
example INCUST–396
quick reference INCUST–395
SHFLPRF keyword
EJOUPRF vector INCUST–316
SFORWPRF vector INCUST–388
SHFLDBD vector INCUST–391
SHFLSGM vector INCUST–396
SHFLSGM vector
example INCUST–398
quick reference INCUST–396
shift state of keystroke in 3270 emulator PROGREF–603
SHRDIR.EXE INCUST–208
SHRDIRDD.EXE INCUST–208
SHRSHARE command SERSYS–133
SHRSHARE utility SERSYS–132
SI (initiate store) function in store-for-forwarding server PROGREF–417
SI (system status information) supervisor local function PROGREF–18
sign-on (SN) function in system manager server PROGREF–471
sign-on (SO) function in system manager server PROGREF–473
signed-on PC (GP) function in system manager server PROGREF–465
signed-on PC (Year-2000) (GW) function in system manager server PROGREF–466
signed-on user (GI) function in system manager server PROGREF–464
signed-on user (GL) function in system manager server PROGREF–463
signed-on users list, get (GO) function in system manager server PROGREF–470
signed-on users list, retrieve (RO) function in system manager server PROGREF–469
signed-on users, listing SERSYS–141
simplifying RECEIVE use SERSYS–212
simplifying SEND use SERSYS–212
simulate hot-key (EE) supervisor local function PROGREF–10
simultaneous code pages SERSYS–69
single message protocol SERSYS–128
single-byte character set INTPLA–115
size of buffer pool, customization INCUST–427
SL (select current electronic journal) function in electronic journal server PROGREF–401
SM (send message and message header) function in object postbox server PROGREF–584
Smalltalk INTPLA–81
Smalltalk, writing application programs using PROGDE–80
SMG files INCUST–229
smgr INCUST–184
SMGR (system manager server) PROGREF–461
SMGR.EXE INCUST–118, INCUST–154, INCUST–211
SMGRPRF vector INCUST–398
SMGRPRF vector
example INCUST–402
quick reference INCUST–398
SMGRUSER vector INCUST–402
SMGRUSER vector
example INCUST–404
quick reference INCUST–402
SMOP.EXE INCUST–118, INCUST–211

SMOPHK keyword, DEFAULTS vector INCUST–305
SN (sign-on) function in system manager server PROGREF–471
SN1 alert, protocol error PRODET–252
SN1—SNA protocol error
  alerts PRODET–252
SNA compression server, LANDP for DOS PRODET–130
SNA server
  alerts PRODET–252
  BID command INCUST–469
  configuration definitions INCUST–468
  connection type INCUST–472
  correlation table size INCUST–469
  emulation over TCP/IP INCUST–481
  facility code INCUST–473
  identification block INCUST–471, INCUST–472
  identification number INCUST–471, INCUST–472
  loading statement (DOS) INCUST–209
  loading statement (OS/2) INCUST–117
  loading statement (Windows) INCUST–153
  LU pool table INCUST–469
  number of user sessions per workstation INCUST–470
  OS/2
    communications manager INCUST–89, INCUST–93
    cryptography INCUST–93
    cryptography management INCUST–93
    DC function INCUST–93
    installation requirements INCUST–89
    LU pooling support INCUST–90
    LUA interface INCUST–89
    LUA profiles INCUST–90
    QC function INCUST–93
    workstation installation requirements INCUST–89
    X.25 directory entry INCUST–93
  permanent circuit INCUST–471
  PU ID INCUST–473
  return codes PRODET–205
  server-managed cryptography INCUST–469
  session device name INCUST–471
  session ID INCUST–470
  session initialization INCUST–469
  SNA LU number INCUST–470
  SNA LU pool ID INCUST–470
  SNA pool ID INCUST–470
  SNAX25D.CFG INCUST–410
  subscriber address INCUST–472
  user data field INCUST–473
  user sessions per workstation INCUST–470
  virtual circuit ID INCUST–471, INCUST–472
  Windows
    installation requirements INCUST–129
    LU pooling support INCUST–130
SNA server *(continued)*
  Windows *(continued)*
    LUA interface INCUST–129
    LUA profiles INCUST–130
    SNA profiles INCUST–129
    SNA providers INCUST–129
    SNA##.EXE INCUST–153
  wrap selection INCUST–469
  X.25 directory table INCUST–410
SNA trace pages, number of LANDP for DOS PRODET–22
SNA trace, LANDP for DOS PRODET–22
SNA/SDLC, VTAM INCUST–531
SNA/TRDLC, VTAM INCUST–533
SNA/X.25, VTAM INCUST–532
SNA## (SNA server) PROGREF–51
SNA##
  return codes PRODET–205
SNA
  communication INTPLA–20, SERSYS–7
  compression server INTPLA–25, SERSYS–22
  OS/2
    profiles INCUST–89
    SNA##.EXE INCUST–117
  server INTPLA–24, SERSYS–20
  servers INTPLA–20, SERSYS–7
  session encryption INTPLA–22, SERSYS–19
  SNA##.EXE
    DOS INCUST–209
SNAX25D.CFG INCUST–410
SNRM, unexpected command received alert PRODET–247
SO (sign-on) function in system manager server PROGREF–473
SOFTPACK
  keyword, LWSCONF vector INCUST–426
software error, alert PRODET–236
software requirements
  Java INCUST–9
software
  LANDP for DOS INTPLA–78
  LANDP for Linux INTPLA–85
  LANDP for OS/2 INTPLA–81
  LANDP for Windows INTPLA–83
  requirements, alerts INTPLA–86
  selection INTPLA–77
sources, public information INTPLA–19, SERSYS–7
SP (set parameters) function in ODBC query server PROGREF–375
SP (set parameters) function in query server PROGREF–325
SP (start posting events) supervisor local function PROGREF–20
SPACING keyword, FORM4770 vector INCUST–350
SPC files INCUST–38, INCUST–237
SPC files
  backup INCUST–37, INCUST–235
  embedded files INCUST–29
  partial files INCUST–29
SPLIT keyword
  EJOUPRF vector INCUST–316
SPLIT keyword *(continued)*
  SFORWPRF vector INCUST–388
spv INCUST–184
SPV (resource name) PROGDE–52
SPV (supervisor local function server) PROGREF–4
SPV.EXE INCUST–118, INCUST–153, INCUST–209
SPVCPRB exit server PROGDE–113
SQ (structured query) function in ODBC query server PROGREF–376
SQ (structured query) function in query server PROGREF–326
SQL support INTPLA–33
SQL
  support SERSYS–109
SRVINIT call PROGDE–5
SRVINIT call
  used in sample application PROGDE–134, PROGDE–157
SS (suspend service) function in local resource manager PROGREF–537
SSCP-PU session INTPLA–24, SERSYS–20
SSCP–LU session (SNA server) PROGREF–48
SSCP–LU session (SNA server)
  number of user sessions per workstation PROGREF–49
  user sessions per workstation PROGREF–49
START command
  OS/2 INCUST–104
  Windows INCUST–141
start posting events (SP) supervisor local function PROGREF–20
start posting events (SP), supervisor local function
  used in sample application PROGDE–125
start session (IS) function in local resource manager PROGREF–536
start tracing, LANDP for DOS PRODET–37
start transmission (TB) function in store-for-forwarding server PROGREF–418
start X.25 adapter trace, LANDP for DOS PRODET–20
STARTKEY keyword
  FORM4710 vector INCUST–320
  FORM4720 vector INCUST–326
  FORM4748 vector INCUST–346
  FORM47X2 vector INCUST–336
STARTUP.CMD file SERSYS–70
statistics codes
  LANDP for DOS PRODET–36
status functions
  information (SI) supervisor local function PROGREF–18
status indicator codes SERSYS–38
status indicator codes (3270 emulator) PRODET–259, SERSYS–40
STATUS keyword, DISPLATT vector INCUST–314
status settings, LANDP for Linux trace tool PRODET–41

status settings, LANDP for OS/2 trace tool PRODET–41
status settings, LANDP for Windows trace tool PRODET–41
status, get (GS) function in PPC server PROGREF–113
stop posting events (TP) supervisor local function PROGREF–23
stop sending job (batch machine operator) SERSYS–197
stop sharing information SERSYS–137
stop tracing, LANDP for DOS PRODET–37
stop transmission (TE) function in store-for-forwarding server PROGREF–419
stop X.25 adapter trace, LANDP for DOS PRODET–21
stopping LANDP for Linux
  servers INCUST–187
stopping LANDP for Windows
  servers INCUST–160
  services INCUST–142
STOR.PRN INCUST–228
storage requirements
  Java INCUST–10
  LANDP INCUST–10
store initiation (SI) function in store-for-forwarding server PROGREF–417
store-for-forwarding server INTPLA–36, SERSYS–124
store-for-forwarding server
  alerts PRODET–246
  configuration definitions INCUST–475
  data access INCUST–387
  data and index files INCUST–388
  data set INCUST–387
  FF1, unsuccessful call to server PRODET–235
  key definition INCUST–389
  loading statement (DOS) INCUST–209
  loading statement (Linux) INCUST–184
  loading statement (OS/2) INCUST–117
  loading statement (Windows) INCUST–153
  maximum record size INCUST–475
  profile INCUST–386, INCUST–475
  record name INCUST–389
  return codes PRODET–136
  shared-file profile INCUST–388
storing files (batch machine operator) SERSYS–197
storing messages PROGREF–577
structure of this book PRODET–viii, PROGREF–xxv
structure, shared file SERSYS–79
structured query (SQ) function in ODBC query server PROGREF–376
structured query (SQ) function in query server PROGREF–326
structured query language support INTPLA–33, SERSYS–109
SU (update application program data) function in system manager server PROGREF–482
SUBEXT keyword, COLSQTBL vector INCUST–302
SUBSNUMB keyword, X25DIR vector INCUST–411
SUFFIX keyword, LANCONF vector INCUST–419
Sun MicroSystems Java Development Kit for Linux INTPLA–85
supervisor buffer pool, specifying LANDP for DOS PRODET–32
supervisor local functions
  activate and deactivate timers (T0–T8) PROGREF–21
  ask for asychronous events (AA) PROGREF–6
  associate semaphore(AS) PROGREF–7
  asynchronous request—asking for TT request (Z4) PROGREF–29
  asynchronous request—event notification or cancellation (Z5) PROGREF–30
  disconnect an application program (EJ) PROGREF–11
  dissociate semaphore (DS) PROGREF–9
  emulator activation PROGREF–10
  exit LANDP servers PROGREF–11
  extended asynchronous event notification or cancellation (ZN) PROGREF–31
  information (II) supervisor local function PROGREF–17
  initialize (IN) supervisor local function PROGREF–16
  inquire information (II) PROGREF–14
  preventing locking PROGREF–28
  simulate hot-key (EE) PROGREF–10
  start posting events (SP) PROGREF–20
  stop posting events (TP) PROGREF–23
  system status information (SI) PROGREF–18
  timer activation, deactivation (T0–T8) PROGREF–21
  unload LANDP (ES) PROGREF–12
  using PROGREF–4
  using a WM function timeout PROGREF–25
  wait for asynchronous events (WM) PROGREF–24
Supervisor local functions
  return codes PRODET–210
supervisor traces, LANDP for DOS
  display routines active or inactive PRODET–37
  EHCLIP program PRODET–35
  functions PRODET–31
  remote requests included or excluded PRODET–37
  routines PRODET–34
  start PRODET–37
  stop PRODET–37
supervisor
  loading statement (DOS) INCUST–209
supervisor *(continued)*
  loading statement (Linux) INCUST–184
  loading statement (OS/2) INCUST–118
  loading statement (Windows) INCUST–153
  parameters INCUST–303
  time-out INCUST–306
support, requesting IBM PRODET–53
support
  DBCS INTPLA–115
supported data types
  ODBC query server PROGREF–366
supported facilities
  APIs INTPLA–8
  DOS compilers INTPLA–78
  functions, by component INTPLA–71
  OS/2 compilers INTPLA–81
supported I/O devices
  DOS INTPLA–89
  Linux INTPLA–98
  OS/2 INTPLA–94
  Windows INTPLA–96
suspend service (SS) function in local resource manager PROGREF–537
SVPCPRB.EXE PROGDE–107
SVPCPRB.EXE file SERSYS–233
SVPCPRBN.EXE PROGDE–107
SVPCPRBx.EXE programs PROGDE–111
SVRMODEL vector INCUST–525
SVRMODEL vector
  example INCUST–526
  quick reference INCUST–525
SVRNAME keyword, SVRMODEL vector INCUST–525
SVRREQS vector INCUST–293
switch printer mode within an application (Z6 function) PROGREF–671
symbol ?, migration INCUST–233
synchronization of date and time PROGREF–484
synchronized databases SERSYS–107
synchronizing date and time INTPLA–39, SERSYS–140
synchronous data link control server configuration definitions INCUST–475
SYSLVL keyword, LWSCONF vector INCUST–425
system administrators, description of PRODET–vii
system and user LOG management server functions PROGREF–505
system availability manager (SAM) INTPLA–32
system communication, backup INTPLA–19, SERSYS–7
system events PROGDE–43
system files, installing and validating INCUST–229
system generated events INTPLA–10
system log file SERSYS–170
system log file: browse SERSYS–158
system log file: search criteria SERSYS–156
system LOG management PROGREF–505
System log, Linux PRODET–56

system log, managing INTPLA–39, SERSYS–140
system management
servers INTPLA–12, INTPLA–39
support INTPLA–12
system manager operator functions SERSYS–149
system manager operator
audio signal INCUST–477
configuration definitions INCUST–477
loading statement (DOS) INCUST–211
loading statement (OS/2) INCUST–118
messages for the operator SERSYS–175
path INCUST–477
video signal INCUST–477
system manager serve
DDT INCUST–400
debug and trace tools INCUST–400
LOG INCUST–400
log file INCUST–400
system manager server
access to LANDP for DOS trace tools PRODET–10
alerts INCUST–478
alerts functions PRODET–7
authorization level INCUST–400
common data INCUST–479
configuration definitions INCUST–478
loading statement (DOS) INCUST–211
loading statement (Linux) INCUST–184
loading statement (OS/2) INCUST–118
loading statement (Windows) INCUST–154
log file INCUST–480
log record size INCUST–400
Netview operator ID INCUST–481
operator interface, start PROGREF–10
path for alerts INCUST–478
path for common data INCUST–479
path for log file INCUST–480
path for profiles INCUST–479
path for record definition file INCUST–480
profile INCUST–398, INCUST–479
record definition INCUST–480
shared DOS directory INCUST–401
user name INCUST–403
user password INCUST–403
user profile INCUST–402
workgroup ID INCUST–227
System manager server
return codes PRODET–212
system manager
operator INTPLA–40, SERSYS–146
server INTPLA–39, SERSYS–140
system network architecture INTPLA–20, SERSYS–7
system programmers, description of PRODET–vii
system requirements INCUST–9
system resources, names of PROGDE–11
system services control point-physical unit session INTPLA–24, SERSYS–20
system software maintenance INTPLA–41, SERSYS–47
system status and commands SERSYS–149
system status area SERSYS–142
system status information (SI) supervisor local function PROGREF–18
system status, get (GG) function in system manager server PROGREF–487
system verification programs PROGDE–107
System verification programs
defining a test PROGDE–108
system verification utility SERSYS–233
SYSTEM.ADD INCUST–196

T

T0–T8 (activate and deactivate timers) supervisor local function PROGREF–21
table, describe (DT) function in ODBC query server. PROGREF–370
table, describe (DT) function in query server PROGREF–321
TB (begin transmission) function in store-for-forwarding server PROGREF–418
TBLASC.088 INCUST–229
TBLEBC.088 INCUST–229
TBLNAME keyword, X25DIR vector INCUST–410
TBLTAI.088 INCUST–229
TC (terminate conversation) function in DDE access server PROGREF–448
TCP/IP INCUST–527, INCUST–530
TCP/IP server
Wide area communication options SERSYS–7
TCP/IP support
PC/TCP Network Software INTPLA–78
TCP/IP for DOS INTPLA–78
TCP/IP tools and LIP programs
LANDP for DOS PRODET–36
LANDP for OS/2 PRODET–50
TCP/IP wide area communications server SERSYS–26
TCP/IP Wide Area communications server PROGREF–137
TCP/IP wide area communications server
LANDP for DOS SERSYS–9
LANDP for Linux SERSYS–17
LANDP for OS/2 SERSYS–15
LANDP for Windows SERSYS–16
TCP/IP, installation requirements INCUST–164
TCP/IP
communication errors INCUST–530
data interchange INCUST–529
DHCP (dynamic host configuration protocol) INCUST–528, INCUST–529
DOS
installation requirements INCUST–191
interrupts INCUST–193
IntExclude parameter INCUST–193
TCPDOS.INI INCUST–193
UMB INCUST–218
TCP/IP *(continued)*
DOS *(continued)*
upper memory block INCUST–218
with TRDLC server INCUST–194
installation requirements (OS2) INCUST–193
internal communication, LANDP for DOS INTPLA–78
internal communications, LANDP for OS/2 INTPLA–81
internal communications, LANDP for Windows INTPLA–83
LANCONF vector
TCPPORT keyword INCUST–420
XPORT keyword INCUST–419
LIP (LANDP Internet Protocol) INCUST–527
message segmentation INCUST–530
OS/2
installation requirements INCUST–89
X.25 support INCUST–89
PING INCUST–528
port number INCUST–529
session partner availability INCUST–530
UDP (user datagram protocol) INCUST–527
unresolved workstation IDs INCUST–528
verification INCUST–528
wide area communications server
installation requirements for Linux INCUST–164
installation requirements for Windows INCUST–133
loading statement (DOS) INCUST–211
loading statement (Linux) INCUST–185
loading statement (OS/2) INCUST–118
loading statement (Windows) INCUST–154
return codes PRODET–218
Windows installation requirements INCUST–128
workstation ID definition INCUST–527
workstation identification INCUST–529
TCPPORT keyword, LANCONF vector INCUST–420
TE (stop transmission) function in store-for-forwarding server PROGREF–419
terminal, information display system INTPLA–29, SERSYS–31
terminate and stay resident (TSR) program PROGDE–2
terminate conversation (TC) function in DDE access server PROGREF–448
terms, definitions of INCUST–557, INTPLA–123, PRODET–269, PROGDE–197, PROGREF–677, SERSYS–249
test system SERSYS–233

testing LANDP applications PROGDE–107
testing user-developed clients SERSYS–233
text copy (CT) function in DDE access server PROGREF–449
text file distribution SERSYS–49
text paste (PT) function in DDE access server PROGREF–450
threads
  LANDP for Linux PROGDE–71
  LANDP for OS/2 PROGDE–71
  LANDP for Windows PROGDE–71
time synchronization INTPLA–39, SERSYS–140
timeout INCUST–104
TIMEOUT keyword
  DEFAULTS vector INCUST–306
  P3287ATT vector INCUST–377
timeout
  NetBIOS send INCUST–107
  OS/2
    server load INCUST–104
    SQL response INCUST–112
    timeout error (query mode) INCUST–112
  TIMEOUT keyword
    DEFAULTS vector INCUST–306
    P3287ATT vector INCUST–377
  Windows
    server initialization INCUST–142
timeouts PROGDE–8, PROGREF–624
timer activation and deactivation (T0–T8) supervisor local function PROGREF–21
timer events PROGDE–44
timer-generated request (TT) PROGDE–62
Tivoli NetView DM commands SERSYS–55
TLOCKS keyword INCUST–394
TMR0ASC keyword, DEFAULTS vector INCUST–306
TMR0SCC keyword, DEFAULTS vector INCUST–305
token ring
  IEEE 802.2 session INTPLA–88
Token-ring data link control (TRDLC)
  number of buffers SERSYS–12
  server SERSYS–9
token-ring data link control server
  address, host INCUST–487
  address, workstation INCUST–487
  buffers INCUST–487
  configuration definitions INCUST–486
  loading statement (DOS) INCUST–211
  SAP, host INCUST–487
  SAP, workstation INCUST–487
  SNA XID block number INCUST–487
  SNA XID ID number INCUST–488
  SSCP name INCUST–488
token-ring DLC trace, LANDP for DOS PRODET–27
topic lock (LO) function in DDE access server PROGREF–439
topic unlock (UL) function in DDE access server PROGREF–441
TOTS.HST file INCUST–253
TP (stop posting events) supervisor local function PROGREF–23
TR$*xxx*A*n*.DAT file PRODET–13
TR$*xxxx*n.DAT file PRODET–12
TR2CHR0-F keywords, MSRINTBL vector INCUST–373
TR3CHR0-F keywords, MSRINTBL vector INCUST–374
trace pages, number of LANDP for DOS SNA PRODET–22
trace pages, number of LANDP for DOS supervisor functions PRODET–32
trace tool display program, general description of PRODET–4
trace tool server, general description of PRODET–4
trace tools INTPLA–15
trace tools, LANDP for DOS PRODET–9
trace tools, LANDP for DOS
  buffer pool, specifying supervisor PRODET–32
  DCA DLC information PRODET–26
  DCA DLC trace PRODET–24
  display routines trace active or inactive PRODET–37
  displaying trace files PRODET–14
  EHCLIP error codes PRODET–36
  EHCLIP statistics codes PRODET–36
  EHCLIP, description of PRODET–35
  EHCTRALL program, using PRODET–14
  GETTRACE program, using PRODET–14
  loading parameters PRODET–22, PRODET–32
  native X.25 trace PRODET–23
  on-request/on-completion values, functions trace PRODET–32
  panels (screens) PRODET–11
  remote requests included or excluded PRODET–37
  routines trace PRODET–34
  screen contents, saving PRODET–12
  screens, levels and names of PRODET–11
  SDLC trace PRODET–15
  SNA trace PRODET–22
  SNA trace pages, number of PRODET–22
  start PRODET–37
  start X.25 adapter trace PRODET–20
  stop PRODET–37
  stop X.25 adapter trace PRODET–21
  supervisor buffer pool, specifying PRODET–32
  supervisor functions trace PRODET–31
  supervisor functions trace pages, number of PRODET–32
  token-ring DLC trace PRODET–27
  trace buffer contents, saving PRODET–13
  trace files, displaying PRODET–14
  X.25 adapter trace PRODET–20
  X.25 adapter trace (coprocessor) PRODET–19
  X.25 network errors PRODET–18
trace tools, LANDP for Linux PRODET–39
trace tools, LANDP for Linux
  EHCTRACW server, using PRODET–40
  error logging PRODET–40
  event tracing PRODET–40, PRODET–41
  file status setting PRODET–41
  loading parameters PRODET–42
  logging errors PRODET–40
  memory status setting PRODET–41
  status settings PRODET–41
  stop event tracing PRODET–41
trace tools, LANDP for OS/2 PRODET–39
trace tools, LANDP for OS/2
  displaying trace files PRODET–44
  EHCPDT program, using PRODET–44
  EHCTRACW server, using PRODET–40
  error logging PRODET–40
  event tracing PRODET–40, PRODET–41
  file status setting PRODET–41
  loading parameters PRODET–42
  log entries PRODET–41
  logging errors PRODET–40
  memory status setting PRODET–41
  return codes PRODET–40
  status settings PRODET–41
  stop event tracing PRODET–41
  trace files, displaying PRODET–44
trace tools, LANDP for Windows PRODET–39
trace tools, LANDP for Windows
  displaying trace files PRODET–44
  EHCPDT program, using PRODET–44
  EHCTRACW server, using PRODET–40
  error logging PRODET–40
  event tracing PRODET–40, PRODET–41
  file status setting PRODET–41
  loading parameters PRODET–42
  logging errors PRODET–40
  memory status setting PRODET–41
  status settings PRODET–41
  stop event tracing PRODET–41
  trace files, displaying PRODET–44
trace tools, start PROGREF–10, PROGREF–623
trace tools, stop PROGREF–623
trace tools
  description of PRODET–4
  display program, description of PRODET–4
  EHCLIP program, description of PRODET–49
  EHCTRACF program, using PRODET–49
  formatting trace files in ASCII PRODET–49
  LANDP for DOS, using PRODET–9, PRODET–37
  LANDP for Linux, using PRODET–39
  LANDP for OS/2, using PRODET–39

trace tools *(continued)*
LANDP for Windows, using PRODET–39
loading PRODET–4
loading statement (Linux) INCUST–185
loading statement (OS/2) INCUST–119
loading statement (Windows) INCUST–154
trace files, formatting in ASCII PRODET–49
trace server, general description of PRODET–4
trace, on-request/on-completion values, LANDP for DOS supervisor functions PRODET–32
tracing, LANDP for Linux event PRODET–41
tracing, LANDP for OS/2 event PRODET–41
tracing, LANDP for Windows event PRODET–41
tracking resources INTPLA–41, SERSYS–47
trademarks INCUST–554, INTPLA–120, PRODET–266, PROGDE–194, PROGREF–674, SERSYS–246
TRANSACT keyword, FORWDS vector INCUST–352
transaction printer server SERSYS–68
Transaction Security System INTPLA–22, SERSYS–19
Transaction Security System (TSS) PROGREF–75
transactions, saving INTPLA–35
transactions
saving SERSYS–118
transferring files, PC to host INTPLA–29, SERSYS–31
translating data INTPLA–22
translating
data SERSYS–18, SERSYS–51
translation routines (ASCII-EBCDIC, EBCDIC-ASCII) PROGREF–573
translation routines
AE routine PROGREF–573
EA routine PROGREF–573
translation server INTPLA–116
translation server (ASCII-EBCDIC, EBCDIC-ASCII) PROGREF–569
translation table, ASCII/EBCDIC SERSYS–45
transmission begin (TB) function in store-for-forwarding server PROGREF–418
transmission end (TE) function in store-for-forwarding server PROGREF–419
transmission priority SERSYS–129
transmitting records SERSYS–128
transparency INTPLA–7
trap errors PRODET–40
TRDLC INTPLA–20, PRODET–xi
TRDLC (Token-ring data link control) SERSYS–8
TRDLC (Token-ring data link control)
number of buffers SERSYS–12
server SERSYS–9
TRDLC server
installation requirements INCUST–193
loading statement (DOS) INCUST–211
TRDLC.EXE INCUST–211
with TCP/IP INCUST–194
TRKOPER keyword, MSRINTBL vector INCUST–373
TRP files PRODET–40
TSR (terminate and stay resident) program PROGDE–2
TSS INTPLA–22, SERSYS–19
TSS (Transaction Security System) PROGREF–75
TT (timer-generated request) PROGDE–62
TT (timer-generated request)
asynchronous request for (Z4) supervisor local function PROGREF–29
tuning the performance PRODET–xi
tuning the performance
ODBC query server INCUST–245
query server INCUST–244
shared DOS directory services INCUST–245
shared-file server INCUST–243
Windows 3.1 under LANDP for DOS INCUST–246
TURQUOIS keyword, DISPLATT vector INCUST–313
tutorial programming examples PROGDE–119, PROGDE–170
TYPE keyword
DISPLATT vector INCUST–311
FORM4710 vector INCUST–319
FORM4720 vector INCUST–323
FORM4748 vector INCUST–341
FORM4770 vector INCUST–348
FORM47X2 vector INCUST–330
LWSCONF vector INCUST–424
XLATETBL vector INCUST–407
TYPECONF utility SERSYS–102
TYPELOG utility SERSYS–93
TYPELOG2 query server program SERSYS–112
types of events
server generated INTPLA–10
system generated INTPLA–10
types of programs (LANDP for OS/2) PROGDE–16
types, return code PRODET–6
TYPESTAT utility SERSYS–100

U

UA (update alerts status) function in system manager server PROGREF–489
UC (decompress data) function in SNA compression server exit PROGREF–71
UD (update LANDP workgroup common data) function in system manager server PROGREF–490
UDC SERSYS–72
UDP (user datagram protocol), TCP/IP INCUST–527
UI (update LANDP workgroup identification) function in system manager server PROGREF–491
UL (unlock topic) function in DDE access server PROGREF–441
UL (update logging status) function in system manager server PROGREF–491
UM (update operator messages status) function in system manager server PROGREF–492
UMB INCUST–218
UN (resolution notification) function in system manager server PROGREF–503
UN (unadvise) function in DDE access server PROGREF–448
unadvise (UN) function in DDE access server PROGREF–448
unattended startup INCUST–141
uncompress (UC function) PRODET–130
uncompress data (UC) function in SNA compression server exit PROGREF–71
universal banking printer server SERSYS–68
universal financial printer server SERSYS–68
unload LANDP (ES) supervisor local function PROGREF–12
unloading shared DOS directory SERSYS–137
unloading
LANDP for DOS under Microsoft Windows 3.1/3.11 INCUST–215
LANDP for Linux INCUST–187
LANDP for Linux servers INCUST–187
LANDP for OS/2 INCUST–125
LANDP for OS/2 servers INCUST–125
LANDP for Windows INCUST–160
LANDP for Windows servers INCUST–161
unlock topic (UL) function in DDE access server PROGREF–441
UO (update message operator receiver) function in system manager server PROGREF–492
update alerts status (UA) function in system manager server PROGREF–489
update application program data (SU) function in system manager server PROGREF–482
update LANDP workgroup common data (UD) function in system manager server PROGREF–490
update LANDP workgroup identification (UI) function in system manager server PROGREF–491
update logging status (UL) function in system manager server PROGREF–491
update message operator receiver (UO) function in system manager server PROGREF–492
update operator messages status (UM) function in system manager server PROGREF–492
update user profile (UU) function in system manager server PROGREF–483

update user profile (UX) function in system manager server PROGREF–484
updated configuration files, installing INCUST–228
updates (fixes), applying program INCUST–251
updating a shared-file server profile SERSYS–104
UPDTCONF utility SERSYS–104
upper memory block INCUST–218
upper memory blocks, using INTPLA–80
UPSDOWN keyword, FORM4770 vector INCUST–350
use mode of printer port SERSYS–74
user characters download (DU) function in financial printer server PROGREF–155
user datagram protocol (UDP), TCP/IP INCUST–527
user identification, managing INTPLA–39, SERSYS–140
user input, arm operator panel for (AR) function in financial printer server PROGREF–146
user log, managing INTPLA–39, SERSYS–140
user profile data SERSYS–165
user profile, managing INTPLA–39, SERSYS–140
user profile: application data SERSYS–155
user profile: system data SERSYS–153
user servers INCUST–285, INCUST–297
user servers
  definitions INCUST–285
  examples INCUST–294
  expanded memory (DOS) INCUST–218
  LANDP for DOS installation INCUST–20
  LANDP for Linux installation INCUST–20
  LANDP for OS/2 installation INCUST–20
  LANDP for Windows installation INCUST–20
user-defined character SERSYS–72
user-defined character, load (LD) function in 4748 printer server PROGREF–169, PROGREF–182
user-developed clients, testing SERSYS–233
user-written servers
  client/server mechanism requests PROGDE–59
  server-to-server calls PROGDE–68
  structure PROGDE–51
USERID keyword, SMGRUSER vector INCUST–403
users of this book INCUST–xxiii, PRODET–vii, PROGREF–xxv
utilities INTPLA–14, INTPLA–55, SERSYS–92, SERSYS–232
utilities
  APPLYFIX utility SERSYS–232
  displaying server status SERSYS–233
  EJUTIL.EXE SERSYS–122
  electronic journal server SERSYS–122
utilities *(continued)*
  shared-file server SERSYS–92
  system verification utility SERSYS–233
  VERSION utility SERSYS–232
utility program
  LANDP for OS/2 query server SERSYS–111
utility programs, run-time INCUST–223
utility programs
  AE routine PROGREF–573
  EA routine PROGREF–573
utility services in 3270 emulator PROGREF–652
UU (update user profile (Year-2000)) function in system manager server PROGREF–484
UU (update user profile) function in system manager server PROGREF–483

V

VA (verify message authentication code) function in PIN pad server PROGREF–248
validate record (VR) function in system manager server PROGREF–497
validating data with defined record structures (system manager server) PROGREF–497
validation program (EHCVAL), loading messages PRODET–221
validation, data INTPLA–39, SERSYS–140
validation
  command INCUST–57
  common vectors, sample INCUST–279
  customization data INCUST–55
  customization vectors INCUST–55
  editing tool INCUST–58
  LANLIMIT.SPC INCUST–55, INCUST–62, INCUST–77
  objectives INCUST–32
  procedure INCUST–57, INCUST–58
  system files INCUST–229
  tasks INCUST–32
  VALSPEC, validation procedure INCUST–57, INCUST–58
  workgroup vectors, sample INCUST–282
VALSPEC
  editing tool INCUST–58
values, return code PRODET–6
VARDAT.CFG INCUST–223, INCUST–226
VARDAT.EXE INCUST–223, INCUST–226
VARDAT
  file error subcodes PRODET–122
  format I/O error subcodes PRODET–119
  I/O error subcodes PRODET–118
variable data (DOS)
  communication INCUST–223, INCUST–227
  record format INCUST–223
  updating communication configuration records INCUST–226
variable length records SERSYS–49
variable length records (in shared-file server) PROGREF–260
VARPARM.EXE INCUST–227
VARPARM.OLD INCUST–227
VARPARM.SPC INCUST–227
VARPARM
  loading error return subcodes PRODET–116
VARPARMW.EXE INCUST–227
VBIWP.EXE INCUST–20, INCUST–121, INCUST–157, INCUST–158, INCUST–434
VDM PROGDE–47, PROGREF–555, SERSYS–226
VDM (virtual DOS machine) for Windows INCUST–157
VDM
  emulators in Windows INCUST–131
  loading statements for emulators INCUST–121, INCUST–157
  OS/2 INCUST–121
  OS/2 with PC/Integrator INCUST–91
  relay INTPLA–54
  relay
    DEVICE statement INCUST–101
    LOADER statement (OS/2) INCUST–120
    loading statement (Linux) INCUST–186
    loading statement (Windows) INCUST–155
  Windows INCUST–157
vector INCUST–405, INCUST–406
vectors
  editing INCUST–41
  how to specify INCUST–42
  rules INCUST–42
verification utility, system SERSYS–233
verification, component SERSYS–233
verification
  current level of LANDP components INCUST–247
  verification programs INCUST–228, INCUST–229
  VERSION utility INCUST–247
verify message authentication code (VA) function in PIN pad server PROGREF–248
verifying program version level PRODET–59
version number SERSYS–232
VERSION utility SERSYS–232
VERSION utility program INCUST–247
VERSION utility program
  description of PRODET–5
VERSION.TXT file INCUST–247, PRODET–59
video signal SERSYS–159
video signal
  customizing system manager SERSYS–146
  pending message SERSYS–159
viewing files (batch machine operator) SERSYS–197
virtual calls, X.25 INCUST–492, INCUST–493
virtual circuit, maximum SERSYS–11
virtual DOS machine (OS/2 or Windows) PROGREF–555
virtual DOS machine (VDM) PROGDE–47

virtual DOS machine relay INTPLA–54, SERSYS–226
virtual DOS machine
VDM INCUST–121, INCUST–157
virtual file support
configuration definitions INCUST–488
SNA LU number INCUST–488
SNA LU pool ID INCUST–488
SNA pool ID INCUST–488
virtual drive INCUST–489
virtual volume support
configuration definitions INCUST–489
public virtual volume 1 INCUST–490
SNA LU number INCUST–490
SNA LU pool ID INCUST–490
SNA pool ID INCUST–490
visual signal, system manager SERSYS–146
VisualAge C++ web site INCUST–586, INTPLA–152, PRODET–298, PROGDE–226, PROGREF–706, SERSYS–279
VisualAge C++programs
compiling and linking PROGDE–14
VisualAge compilers INTPLA–81
VisualAge for C++ for Windows INTPLA–83
VisualAge for COBOL PROGDE–93
VisualAge for COBOL for OS/2 call RMTREQ PROGDE–32
VisualAge for COBOL for OS/2 programs PROGDE–9
VisualAge generator PROGDE–95
VisualAge Generator books INCUST–586, INTPLA–152, PRODET–298, PROGDE–226, PROGREF–706, SERSYS–279
VisualAge Generator support functions
return codes PRODET–220
VisualAge generator
ASCII/EBCDIC translation PROGDE–98
bit-oriented data PROGDE–97
calling functions within the DLL PROGDE–97
calling LANDP servers PROGDE–96
generating an application PROGDE–102
overview PROGDE–95
return codes PROGDE–101
testing applications PROGDE–102
The LANDP Dynamic Link Library PROGDE–95
VisualAge Smalltalk web site INCUST–587, INTPLA–153, PRODET–299, PROGDE–227, PROGREF–707, SERSYS–279
VR (validate record) function in system manager server PROGREF–497
VRTOFFSI keyword , FORM47X2 vector INCUST–336
VRTOFFSL keyword
FORM4710 vector INCUST–320
FORM4720 vector INCUST–327
FORM4748 vector INCUST–346
FORM4770 vector INCUST–350
FORM47X2 vector INCUST–336
VRTOFFSS keyword
FORM4720 vector INCUST–327
FORM4748 vector INCUST–346
FORM4770 vector INCUST–350
FORM47X2 vector INCUST–337
VSE/ESA and VSE/SP RECEIVE commands SERSYS–210
VSE/ESA and VSE/SP SEND commands SERSYS–206
VTAM INCUST–531
VTAM logon mode table, MODEENT macro in SERSYS–215
VTAM MODETAB INCUST–534

W

wait for asynchronous events (WM)
use of, in a client PROGDE–41
use of, in a server PROGDE–72
WD (write display) function in PIN pad server PROGREF–249
WHITE keyword, DISPLATT vector INCUST–314
wide area communication
books INCUST–584, INTPLA–150, PRODET–296, PROGDE–224, PROGREF–704, SERSYS–277
communication INTPLA–19
server INTPLA–11, SERSYS–7
WIDECHR keyword
FORM4770 vector INCUST–350
FORM47X2 vector INCUST–337
Windows 2000
operating system levels INTPLA–83
Windows 3.1 support (OS/2)
configuration data (LWSCONF) INCUST–425
EHCWIN.DLL INCUST–98
installation requirements (OS/2) INCUST–98
workstation installation requirements INCUST–98
Windows 3.1 support under LANDP for DOS PROGDE–47
Windows 3.1/3.11 applications INCUST–196
Windows 3.1/3.11 support (DOS) INCUST–195
Windows 3.1/3.11 support (DOS)
configuration data (LWSCONF) INCUST–425
considerations INCUST–195
EHCAPLVM.BAT INCUST–196
EHCDOSVM.BAT INCUST–196
EHCDOSVM.PIF INCUST–196
EHCPREV.BAT INCUST–196
SYSTEM.ADD INCUST–196
WINSTART.BAT INCUST–196
Windows 3.1/3.11 support
EHCWVDMI INCUST–196
Windows 3.1/3.11 applications INCUST–196
Windows NT, COBOL programs under VisualAge PROGDE–93
Windows NT
compilers INTPLA–83
operating system levels INTPLA–83
Windows VDM
PAR&VBIW INCUST–434
Windows VDM *(continued)*
SERVER keyword, LWSCONF vector INCUST–434
SERVER keyword, LWSCONF vector
BIWP INCUST–430, INCUST–526
BPP INCUST–430, INCUST–526
LDA7 INCUST–430, INCUST–526
Windows virtual DOS machine PROGREF–555
Windows workstations INCUST–127, INCUST–161
Windows, use of native system functions PROGDE–2
Windows
event log INCUST–143
FBSI restriction INTPLA–15
installation path INCUST–161
path, installation INCUST–161
registry INCUST–140
restrictions INTPLA–15
services INCUST–139
software INTPLA–79
supported releases PROGREF–xxvii
TCP/IP INCUST–128
VDM SERSYS–226
workstation installation requirements INCUST–127
WINFOCUS.EXE INCUST–121
WINSTART.BAT INCUST–196
WL (write LOG record) function in system manager server PROGREF–510
WM (wait for asynchronous events)
use of, in a client PROGDE–41
use of, in a server PROGDE–72
WM (write message data) function in object postbox server PROGREF–585
workgroup configuration data INCUST–26
workgroup configuration data
configuration vectors INCUST–414, INCUST–417, INCUST–521
customization directory structure INCUST–27
LANCONF vector INCUST–417
LWSCONF vector INCUST–423
variable parameters program INCUST–227
workgroup identification, update (UI) function in system manager server PROGREF–491
workgroup suffix, LANDP session INCUST–227
workgroup, definition of PROGDE–1
workgroup
common data maintenance INTPLA–39
LANDP INTPLA–5
workgroups for DBCS users INTPLA–117
workgroups, common data maintenance SERSYS–140
workstation files, identifying SERSYS–49
workstation identification PROGDE–7
workstation identification (LIP) INCUST–527
workstation
ID INTPLA–23, SERSYS–18

workstation *(continued)*
resource tracking INTPLA–41, SERSYS–47
WR (write to IBM 47xx MSR/E device) function in MSR/E server PROGREF–214
write display (WD) function in PIN pad server PROGREF–249
write LOG record (WL) function in system manager server PROGREF–510
write message data (WM) function in object postbox server PROGREF–585
write status, check (CH) function in MSR/E server PROGREF–208
write structured fields in 3270 emulator PROGREF–655
WRNLINE keyword
FORM4710 vector INCUST–321
FORM4720 vector INCUST–327
FORM4748 vector INCUST–346
FORM4770 vector INCUST–351
FORM47X2 vector INCUST–337
WSID keyword, LWSCONF vector INCUST–424
WSMODEL vector INCUST–524
WSMODEL vector
example INCUST–525
quick reference INCUST–524
WSNAMES keyword
LANCONF vector INCUST–421
LANMODEL vector INCUST–523
WSoD INCUST–543, INCUST–547
WSoD
CONFIG.SYS updates INCUST–545
distributing LANDP files INCUST–544
FIT file updates INCUST–545
LANDP customization INCUST–546
multiple workgroup support INCUST–545
run time INCUST–546
WT (write to IBM 47xx MSR/E device) function in MSR/E server PROGREF–215
WTS INCUST–547
WTS
distributing LANDP files INCUST–547

X

X (hexadecimal codes)
ALU PRODET–219
CL1 through CL2 PRODET–159
CN1 through CN4 PRODET–159
CN1 through CN8 PRODET–219
CNP PRODET–219
CNW PRODET–219
GH1 PRODET–159, PRODET–219
IF1 through IF3 PRODET–219
IN1 through IN7 PRODET–159, PRODET–219
INa through INe PRODET–159, PRODET–219
INC PRODET–219
INL PRODET–219
INM PRODET–219
INN PRODET–219
INP PRODET–159, PRODET–219
X (hexadecimal codes) *(continued)*
MX1 PRODET–159, PRODET–219
MX2 PRODET–219
RD1 through RD2 PRODET–219
RD1 through RD3 PRODET–159
SD1 PRODET–159, PRODET–219
TE1 through TE2 PRODET–219
X'00A00004' PRODET–131
X'00A00008' PRODET–131
X'00A0000A' PRODET–131
X'00A0000B' PRODET–131
X'00A0000C' PRODET–131
X'00A00033' PRODET–131
X'00A00034' PRODET–131
X'00A00035' PRODET–131
X'00A00036' PRODET–131
X'00A00050' PRODET–131
X'00A00061' PRODET–131
X'00A05000' PRODET–131
X'00A05001' PRODET–131
X'00A05002' PRODET–131
X'00A05004' PRODET–131
X'00A05005' PRODET–131
X'00A05006' PRODET–131
X'00A05007' PRODET–131
X'00A05008' PRODET–131
X'00A0504C' PRODET–133
X'00A051AC' PRODET–133
X'00A05345' PRODET–133
X'00A05441' PRODET–133
X'00A05445' PRODET–133
X'00A06000' PRODET–131
X'00A06001' PRODET–131
X'00A06002' PRODET–131
X'00A06003' PRODET–131
X'00A07001' PRODET–131
X'00A07002' PRODET–131
X'00A07003' PRODET–131
X'00A07004' PRODET–131
X'0100414E' PRODET–133
X'01004253' (BS) PRODET–127
X'01004345' PRODET–133
X'01004346' PRODET–133
X'0100434C' PRODET–133
X'0100434F' PRODET–133
X'01004454' PRODET–133
X'0100454F' PRODET–133
X'01004844' (HD) PRODET–127
X'01004943' PRODET–133
X'01004946' PRODET–133
X'0100494D' PRODET–133
X'01004950' PRODET–133
X'01004950' (IP) PRODET–127
X'01004954' PRODET–133
X'01004E41' PRODET–133
X'01004E44' PRODET–133
X'01004E46' PRODET–133
X'01004E4C' PRODET–133
X'01004E4D' PRODET–133
X'01004E52' PRODET–133
X'01004E53' (NS) PRODET–127
X'01004F45' PRODET–133
X'01005030' (P0) PRODET–128
X'01005031' (P1) PRODET–128
X'01005032' (P2) PRODET–130
X'01005032'(P2) PRODET–128
X'01005033'(P3) PRODET–128
X (hexadecimal codes) *(continued)*
X'01005034' (P4) PRODET–130
X'01005037'(P7) PRODET–130
X'01005038'(P8) PRODET–128
X'01005059'(PY) PRODET–128
X'0100505A'(PZ) PRODET–128
X'01005539'(U9) PRODET–128
X (hexadecimal) codes
01004144 (AD) PRODET–200
0100424C (BL) PRODET–200
01004345 (CE) PRODET–200
0100434F (CO) PRODET–200
01004441 (DA) PRODET–200
01004442 (DB) PRODET–200
01004448 (DH) PRODET–200
0100444A (DJ) PRODET–200
0100444F (DO) PRODET–200
01004531 (E1) PRODET–200
01004532 (E2) PRODET–200
01004550 (EP) PRODET–200
01004644 (FD) PRODET–200
01004742 (GB) PRODET–200
01004745 (GE) PRODET–200
01004945 (IE) PRODET–200
01004949 (II) PRODET–200
01004C49 (LI) PRODET–200
01004D49 (MI) PRODET–200
01004E41 (NA) PRODET–200
01004E42 (NB) PRODET–200
01004E43 (NC) PRODET–200
01004E4F (NO) PRODET–200
01004E50 (NP) PRODET–200
01004E53 (NS) PRODET–200
01004E54 (NT) PRODET–200
01004F50 (OP) PRODET–200
01005049 (PI) PRODET–200
0100505A (PZ) PRODET–200
0100524C (RL) PRODET–200
0100544C (TL) PRODET–200
0100544F (TO) PRODET–200
01005941 (YA) PRODET–200
01005942 (YB) PRODET–200
0100594F (YO) PRODET–200
01005950 (YP) PRODET–200
082FF001 PRODET–192
082FF004 PRODET–192
0833F001 PRODET–192
328A0108 PRODET–192
32B00001 PRODET–192
32B00002 PRODET–192
32B00202 PRODET–192
32B10001 PRODET–192
32B10002 PRODET–192
32B10101 PRODET–192
32B20001 PRODET–192
32B20002 PRODET–192
32B20104 PRODET–192
32B40204 PRODET–192
32B50001 PRODET–192
32B50002 PRODET–192
32B50003 PRODET–192
32B50201 PRODET–192
32B60001 PRODET–192
32B60002 PRODET–192
32B60105 PRODET–192
32B60201 PRODET–192
32B70001 PRODET–192

X (hexadecimal) codes *(continued)*
32B70002 PRODET–192
32B70003 PRODET–192
32B70004 PRODET–192
32B70005 PRODET–192
32B70007 PRODET–192
32B80001 PRODET–192
32B80002 PRODET–192
32B80003 PRODET–192
32B80004 PRODET–192
32B90001 PRODET–192
32B90002 PRODET–192
32B90003 PRODET–192
32BA0001 PRODET–192
32BA0002 PRODET–192
32BA0003 PRODET–192
32BA0004 PRODET–192
32BA0005 PRODET–192
32BA0006 PRODET–192
32BA0007 PRODET–192
32BA0008 PRODET–192
32BB0001 PRODET–192
32E90002 PRODET–192
32E90201 PRODET–192
32E90202 PRODET–192
32E90203 PRODET–192
32E90204 PRODET–192
32E90205 PRODET–192
32E90206 PRODET–192
X.25 communications support program SERSYS–10
X.25 data link control (DLC)
alerts PRODET–252
X.25 data link control server PRODET–xi
X.25 data link control server
adapter number INCUST–495
both-way virtual calls INCUST–492
buffers INCUST–491, INCUST–494
configuration definitions INCUST–491
country ID INCUST–494, INCUST–495
country subcode INCUST–494, INCUST–495
DEVICE statement (DOS) INCUST–199
incoming virtual calls INCUST–492
interrupt number INCUST–494
loading statement (X25DLC.EXE) INCUST–212
loading statement (X25DLC2.EXE) INCUST–212
logical channel ID INCUST–493
memory pool size INCUST–495
native X.25 INCUST–110
native X.25 server INCUST–206
outgoing virtual calls INCUST–492
X.25 data link control server *(continued)*
permanent virtual circuits INCUST–492
profile INCUST–495
retransmission limit INCUST–494
retransmission time-out INCUST–494
subscriber address INCUST–495
subscriber number INCUST–494
telephone number INCUST–491, INCUST–494
virtual circuits INCUST–492
window size INCUST–494
X25NAT##.EXE INCUST–110, INCUST–206
X.25 network
adapter trace (coprocessor), LANDP for DOS PRODET–19
adapter trace, LANDP for DOS PRODET–20
errors trace, LANDP for DOS PRODET–18
X.25
API INTPLA–21, SERSYS–15
Co-Processor Support Program SERSYS–10
communication INTPLA–20, SERSYS–7
Data Link Control server SERSYS–10
DLC INCUST–19
DLC server SERSYS–10
DLC, number of buffers SERSYS–12
Interface Co-processor/2 SERSYS–10
network communication SERSYS–31
server INTPLA–25, SERSYS–23
speed SERSYS–10
TCP/IP INCUST–527
TCP/IP support (OS/2) INCUST–89
variable data records
network user address INCUST–224
permanent circuits INCUST–224
switched circuits INCUST–224
X25DIR vector INCUST–410
X'7F' API SERSYS–226
X1 alert, invalid or unsupported command received PRODET–253
X2 alert, DCE-originated clear indication received PRODET–254
X2—DCE-Originated clear indication received
alerts PRODET–254
X25DLC INTPLA–20, SERSYS–8
X25NAT## (X.25 communication server) PROGREF–94
X3 alert, reset indication packet sent by the DTE PRODET–255
X3—Reset indication packet sent by the DTE
alerts PRODET–255
X4 alert, clear request packet sent by the DTE PRODET–256
XLAT2TBL vector INCUST–408
XLAT2TBL vector
example INCUST–409
quick reference INCUST–408
XLATETBL vector INCUST–406
XLATETBL vector
example INCUST–408
quick reference INCUST–407
XLR (external logging replicator) INTPLA–32
XLR (external logging replicator)
configuration data, shared-file server INCUST–467, INCUST–468
single ehcsam server, -O parameter shfile## loading statement, Linux INCUST–183
XN (retrieve user profile by record number (Year-2000)) function in system manager server PROGREF–479
XPORT keyword, LANCONF vector INCUST–419
XPORT keyword
LWSCONF vector INCUST–427

Y

year 2000 INTPLA–16
YELLOW keyword, DISPLATT vector INCUST–313

Z

Z4 (asynchronous request—asking for TT request) supervisor local function PROGREF–29
Z5 (asynchronous request—event notification or cancellation) supervisor local function PROGREF–30
Z5 (asynchronous request—event notification or cancellation) supervisor local function
used in sample application PROGDE–136
Z6 (switch printer mode) function, FBSI/2 PROGREF–671
ZI (server information) function in SNA server PROGREF–66
ZN (extended asynchronous event notification or cancellation) supervisor local function PROGREF–31